

HOCO S3

HOCO S3 Nature Active Noise Reduction Bluetooth Headset

INSTRUCTION MANUAL

Introduction

Thank you for choosing the HOCO S3 Nature Active Noise Reduction Bluetooth Headset. This manual provides comprehensive instructions to help you set up, operate, and maintain your new headset, ensuring you get the best possible audio experience with precise sound quality and effective noise reduction.

Safety Information

- Do not expose the headset to extreme temperatures, humidity, or corrosive substances.
- Avoid dropping or subjecting the headset to strong impacts.
- Do not disassemble or attempt to repair the headset yourself. This will void the warranty.
- Clean the headset with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Listen at moderate volume levels to prevent hearing damage.
- Keep out of reach of children.

Package Contents

Please check the package for the following items:

- HOCO S3 Nature Bluetooth Headset
- USB Charging Cable
- Audio Cable (if included)
- Instruction Manual



Image: The HOCO S3 headset neatly packed in its carrying case, alongside the included USB charging cable and audio cable.

Product Overview

The HOCO S3 headset features an over-ear design with comfortable ear cushions and an adjustable headband. It integrates active noise reduction technology for an immersive audio experience.



Image: A front-side view of the HOCO S3 Nature Bluetooth Headset, showcasing its sleek black design and comfortable earcups.



Image: A detailed view of the right ear cup of the HOCO S3 headset, highlighting the control buttons for power, volume, and active noise cancellation.

Setup

Charging the Headset

1. Connect the small end of the USB charging cable to the charging port on the headset.
2. Connect the large end of the USB charging cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will illuminate to show charging status. It will turn off or change color when fully charged.
4. A full charge provides approximately 6 hours of playback time.

Powering On/Off

1. **To Power On:** Press and hold the Power button for approximately 3 seconds until the LED indicator flashes.
2. **To Power Off:** Press and hold the Power button for approximately 3 seconds until the LED indicator turns off.

Bluetooth Pairing

1. Ensure the headset is powered off.
2. Press and hold the Power button for about 5-7 seconds until the LED indicator flashes red and blue alternately, indicating pairing mode.
3. On your Bluetooth-enabled device (smartphone, tablet, laptop), go to the Bluetooth settings and turn on Bluetooth.
4. Search for available devices. Select "HOCO S3" from the list.
5. Once paired, the LED indicator will flash blue slowly, and you may hear a confirmation tone.
6. The headset will automatically reconnect to the last paired device when powered on, if the device's Bluetooth is active and within range.

Operating

Music Playback Controls

- **Play/Pause:** Press the Multi-function button (usually the Power button) once.
- **Next Track:** Press and hold the Volume Up (+) button.
- **Previous Track:** Press and hold the Volume Down (-) button.
- **Volume Up:** Short press the Volume Up (+) button.
- **Volume Down:** Short press the Volume Down (-) button.

Call Management

- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Press and hold the Multi-function button for 2 seconds.
- **Redial Last Number:** Double-press the Multi-function button.

Active Noise Cancellation (ANC)

The HOCO S3 features active noise cancellation to reduce ambient noise, providing a more focused listening experience.

- **Activate ANC:** Locate the ANC switch or button on the headset (refer to product overview image for location). Slide the switch or press the button to turn ANC on. An indicator light may illuminate.
- **Deactivate ANC:** Slide the switch or press the button again to turn ANC off.



Image: A person comfortably wearing the HOCO S3 headset, demonstrating its over-ear fit and suitability for extended use.

Maintenance

Cleaning

- Wipe the headset regularly with a soft, dry, lint-free cloth.
- Do not use liquid cleaners, sprays, or solvents.
- For ear cushions, gently wipe with a slightly damp cloth if necessary, then dry immediately.

Storage

- When not in use, store the headset in its original carrying case or a protective pouch to prevent damage.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid placing heavy objects on top of the headset.



Image: The HOCO S3 headset folded for compact storage, highlighting its portability.

Troubleshooting

Problem	Possible Cause	Solution
Headset won't power on	Low battery	Charge the headset fully.
Cannot pair with device	Headset not in pairing mode / Device Bluetooth off / Too far from device	Ensure headset is in pairing mode (flashing red/blue). Turn on Bluetooth on your device. Move headset closer to device.
No sound	Volume too low / Not connected / Incorrect audio output selected	Increase headset and device volume. Re-pair the headset. Check device's audio output settings.
ANC not working effectively	ANC not activated / Environmental noise too high for full cancellation	Ensure ANC is switched on. ANC is most effective for low-frequency, constant noise.

Specifications

Feature	Detail
Brand	HOCO
Model Name	S3
Connectivity Technology	Wireless (Bluetooth)

Feature	Detail
Noise Control	Active Noise Cancellation
Ear Placement	Over Ear
Form Factor	Over-Ear
Color	Black
Included Components	Headband, Ear Pads
Product Dimensions (Packaging)	22.8 x 20.2 x 7.6 cm; 770 Grams

Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official HOCO website. Keep your proof of purchase for any warranty claims.

© 2024 HOCO. All rights reserved.