**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



### Satisfyer J2018-47-2

# Satisfyer Wand-er Woman Vibrator Instruction Manual

Model: J2018-47-2

## INTRODUCTION

This manual provides essential information for the safe and effective use of your Satisfyer Wand-er Woman Vibrator. Please read these instructions carefully before first use and retain them for future reference.




Image: The Satisfyer Wand-er Woman Vibrator, highlighting its sleek white design and rounded head.

## Safety Information

- **Material Safety:** The device is made from medical-grade silicone. Clean thoroughly before and after each use.
- **Waterproof Rating:** The device has an IPX7 waterproof rating, allowing for immersion in water up to 1 meter deep for up to 30 minutes. Ensure the charging port is dry before charging.
- **Charging:** Use only the provided charging cable. Do not use the device while charging.
- **Storage:** Store in a clean, dry place away from direct sunlight and extreme temperatures. Keep out of reach of children.
- **Disposal:** Dispose of the device and its battery according to local regulations. Do not dispose of with household waste.

## Product Overview

The Satisfyer Wand-er Woman features an ergonomic design with intuitive controls for a customizable experience.




Image: Detailed view of the Satisfyer Wand-er Woman showing the control panel with buttons for power, vibration programs, and intensity adjustment.

### Controls:

- **Power Button:** Press and hold for 2 seconds to turn the device on or off.
- **Program Button:** Press to cycle through 10 different vibration patterns when the device is on.
- **Intensity Up (+):** Press to increase the vibration intensity.
- **Intensity Down (-):** Press to decrease the vibration intensity.

## Setup

### Charging the Device:

1. Ensure the device is dry before charging.
2. Connect the magnetic charging cable to the charging contacts on the device.

3. Plug the USB end of the cable into a suitable USB power source (e.g., computer, USB wall adapter).
4. The indicator light will illuminate during charging and turn off when fully charged.
5. A full charge typically takes approximately 2-3 hours.



Image: Close-up of the magnetic charging cable connecting to the Satisfyer Wand-er Woman.

### First Use:

Before initial use, clean the device thoroughly with warm water and a mild, toy-safe cleaner. Rinse well and dry completely.

## Operating Instructions

1. **Power On:** Press and hold the Power button for 2 seconds. The device will start vibrating.
2. **Adjust Vibration Programs:** Press the Program button to cycle through the 10 available vibration patterns.
3. **Adjust Intensity:** Use the '+' button to increase vibration intensity and the '-' button to decrease it. There are 5 intensity levels for each program, offering 50 total combinations.
4. **Power Off:** Press and hold the Power button for 2 seconds.




Image: The Satisfyer Wand-er Woman with an overlay indicating 50 vibration programs, demonstrating its versatility.

### Usage Tips:

- The rounded head is designed for stimulating full-body massage.
- The device is waterproof (IPX7) and can be used in the shower or bath.

### Official Product Video:

Your browser does not support the video tag.

Video: An official product video demonstrating the features and use of the Satisfyer Wand-er Woman. This video is 36 seconds long and showcases the product's design and functionality.

## Maintenance

### Cleaning:

1. Always clean the device before and after each use.

2. Wash with warm water and a mild, toy-safe soap or specialized toy cleaner.
3. Rinse thoroughly to remove all soap residue.
4. Dry completely with a lint-free cloth before storing.




Image: The Satisfyer Wand-er Woman covered in water droplets, illustrating its waterproof capabilities for easy cleaning and use in wet environments.

## Storage:

Store the device in a clean, dry, and dust-free environment. Avoid direct sunlight and extreme temperatures. Keep separate from other toys made of different materials to prevent material degradation.

## Troubleshooting

- **Device not turning on:**

- Ensure the device is fully charged.
- Press and hold the Power button for the required 2 seconds.

- **Device not charging:**
  - Check that the magnetic charging cable is securely connected to both the device and the power source.
  - Ensure the charging contacts on the device and cable are clean and dry.
  - Try a different USB power source.
- **Vibrations are weak or inconsistent:**
  - The battery may be low; recharge the device.
  - Ensure the device is not damaged.

If problems persist, please contact Satisfyer customer support.

## Specifications

| | |
|---|---|
| **Product Dimensions** | 13.39 x 2.24 x 3.07 inches |
| **Weight** | 1.49 pounds |
| **Model Number** | J2018-47-2 |
| **Battery** | 1 Lithium Ion battery (rechargeable) |
| **Material** | Silicone |
| **Waterproof Rating** | IPX7 |

## Warranty & Support

Satisfyer offers a **15-year product protection** on the Wand-er Woman Vibrator, ensuring long-lasting satisfaction and peace of mind. For warranty claims, technical support, or any inquiries regarding your device, please visit the official Satisfyer website or contact their customer service directly.
You can find more information and contact details on theSatisfyer Store on Amazon or the manufacturer's official website.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B082147GS2**

More documents and user manuals: **https://manuals.plus/**