

WLIVE ASNG100HH

WLIVE Fabric Dresser

USER MANUAL

Product Overview



The WLIVE Fabric Dresser is a versatile storage solution featuring 8 deep drawers and a sturdy design, perfect for organizing items in various rooms.

The WLIVE Fabric Dresser (Model ASNG100HH) is designed to provide ample storage and complement your home decor. This multifunction storage tower is ideal for bedrooms, closets, entryways, dorms, living rooms, and hallways, helping you keep clutter under control. Its robust construction ensures durability and stability for long-term use.

Key Features:

- **Multifunction Storage Tower:** Ideal for various rooms including bedroom, closet, entryway, dorm, living room.
- **Roomy Storage Space:** Features 8 deep drawers for extensive organizational possibilities.

- **Sturdy and Durable:** Constructed with a strong steel frame, wooden top, and high-grade non-woven fabric for stable support.
- **Anti-Tipping Accessories:** Includes safety features to prevent incidents.
- **Adjustable Feet:** Equipped with 4 adjustable feet to protect floors and ensure stability on uneven surfaces.
- **Water-Resistant Wooden Top:** Provides a durable surface for placing frequently used items.



The dresser seamlessly integrates into various home environments, offering both functionality and aesthetic appeal.


Safety Information

Please read and understand all safety information before assembling and using this product. Failure to follow these instructions may result in injury or damage.

- **Anti-Tipping Device:** Always install the included anti-tipping accessories to secure the dresser to a wall. This is crucial to prevent the dresser from tipping over, especially in households with children or pets.
- **Weight Limits:** Do not exceed the maximum weight capacity for the top surface (35 lbs) and individual drawers

(6.6 lbs per drawer). Overloading can compromise stability and cause damage.

- **Even Distribution:** Distribute weight evenly across drawers to maintain balance and prevent tipping.
- **Children Safety:** Do not allow children to climb on or play with the dresser. Keep heavy items in lower drawers.
- **Stable Surface:** Place the dresser on a flat, level, and stable surface. Use the adjustable feet to compensate for uneven flooring.



WALVE DRESSER

ANTI-TILT DEVICE

Prevent incidents

WALVE DRESSER

ADJUSTABLE FEET

Protect Floor
Keep Stable



Ensure the anti-tilt device is properly installed and adjustable feet are used for stability.

Package Contents

Before assembly, please verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Steel Frame Components
- Wooden Top Board
- Fabric Drawers (8 units)

- Drawer Handles
- Adjustable Feet (4 units)
- Anti-Tipping Kit (Wall anchor, screws, strap)
- Assembly Hardware (Screws, Allen wrench, etc.)
- Instruction Manual

Setup and Assembly

Assembly of the WLIVE Fabric Dresser is straightforward and typically takes about 30 minutes. All necessary tools and detailed instructions are included in the package. For visual guidance, an assembly video is available on the product's Amazon page.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Steel Frame:** Follow the step-by-step diagrams in the included instruction manual to connect the steel frame components using the provided hardware. Ensure all connections are secure.
3. **Attach Adjustable Feet:** Screw the adjustable feet into the bottom of the steel frame. Adjust them as needed to ensure the dresser is level.
4. **Place Wooden Top:** Secure the wooden top board onto the assembled steel frame.
5. **Prepare Fabric Drawers:** Unfold each fabric drawer and insert the bottom panel to create a sturdy box. Attach the handles to the front of each drawer.
6. **Insert Drawers:** Slide the assembled fabric drawers into their respective slots in the steel frame.
7. **Install Anti-Tipping Device:** Securely attach the anti-tipping device to the back of the dresser and to a wall stud, following the specific instructions provided. This step is critical for safety.

STURDY STEEL FRAME

✧ With Supporting Bars ✧



The dresser features a sturdy steel frame with supporting bars for enhanced stability.

Operating Instructions

Using your WLIVE Fabric Dresser is simple. Follow these guidelines for optimal performance and longevity.

- **Opening and Closing Drawers:** Use the provided handles to smoothly pull out and push in the fabric drawers. Avoid forcing drawers if they feel stuck.
- **Loading Drawers:** Place items neatly inside the drawers. While the drawers are spacious, avoid overfilling them to prevent strain on the fabric and frame. Each drawer has a weight capacity of 6.6 lbs.
- **Top Surface Use:** The wooden top surface can hold up to 35 lbs. It is suitable for lamps, books, decorative items, or frequently accessed personal belongings.
- **Relocation:** If you need to move the dresser, empty the drawers first to reduce weight and prevent damage during transport.



The deep fabric drawers offer ample space for various items, with a capacity of 6.6 lbs per drawer.

Maintenance

Proper care will help maintain the appearance and functionality of your WLIVE Fabric Dresser.

- **Cleaning:** Wipe the wooden top and steel frame with a dry, soft cloth. For the fabric drawers, spot clean with a damp cloth and mild detergent if necessary, then air dry completely. Avoid harsh chemicals or abrasive cleaners.
- **Dusting:** Regularly dust all surfaces to prevent buildup.
- **Avoid Moisture:** Keep the dresser away from excessive moisture or direct sunlight to prevent warping or fading of materials.
- **Check Connections:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

Troubleshooting

If you encounter any issues with your dresser, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Dresser is wobbly/unstable.	Uneven floor; loose connections.	Adjust the leveling feet at the bottom of the frame. Check and tighten all screws.
Drawers do not slide smoothly.	Drawer not properly inserted; overloaded drawer.	Ensure the drawer is fully unfolded and the bottom panel is flat. Reduce the weight in the drawer.
Missing parts during assembly.	Packaging error.	Double-check all packaging materials. If still missing, contact WLIVE customer support.
Fabric drawers appear deformed.	Improper setup of drawer bottom.	Ensure the MDF board is correctly inserted into the bottom of the fabric drawer to maintain its shape.

Specifications

Attribute	Detail
Product Care Instructions	Wipe with Dry Cloth
Assembly Required	Yes
Item Weight	23.2 Pounds
Number of Pieces	1
Date First Available	December 3, 2019

Warranty and Support

WLIVE is committed to providing high-quality products and customer satisfaction. While specific warranty details are not provided in this manual, please refer to the product listing on Amazon or contact WLIVE customer support for information regarding warranty coverage and assistance.

For further support, product inquiries, or to report any issues, please visit the official WLIVE Store on Amazon or contact their customer service directly. You can find contact information on the WLIVE brand store page:

[Visit the WLIVE Store](#)