

[Manuals.plus](#) /

› [Digitek](#) /

› Digitek DSBH-055 Soft Box Instruction Manual

Digitek DSBH-055

Digitek DSBH-055 Soft Box Instruction Manual

Model: DSBH-055

1. INTRODUCTION

The Digitek DSBH-055 Soft Box is a lightweight and portable lighting accessory designed to provide soft, diffused light for various photography applications. It is compatible with all flash speedlights and includes an S2 type bracket and two diffuser sheets to enhance light quality. This manual provides detailed instructions for the proper setup, operation, and maintenance of your soft box.



Figure 1: Digitek DSBH-055 Soft Box assembled on a light stand.

Package Contents

Please verify that all items listed below are included in your package:

- 1 x Digitek DSBH-055 Soft Box (55 cm)
- 1 x S2 Type Bracket
- 2 x Diffuser Sheets (Inner and Outer)
- 1 x Carrying Case

2. SETUP INSTRUCTIONS

Follow these steps to correctly assemble your Digitek DSBH-055 Soft Box.

2.1 Unfolding the Soft Box

1. Remove the soft box from its carrying case.

2. Gently unfold the soft box. It is designed for quick opening and folding. Apply even pressure to extend the rods until the soft box takes its octagonal shape.



Figure 2: Soft box in folded state with carrying case, demonstrating portability.

2.2 Attaching the S2 Type Bracket

3. Locate the S2 Type Bracket. This bracket is designed to securely hold your flash speedlight and attach to a light stand.
4. Insert the soft box's mounting ring into the S2 Type Bracket. Ensure it clicks into place or is securely fastened according to the bracket's mechanism.
5. Mount the assembled soft box and bracket onto a compatible light stand. Tighten the locking knob on the bracket to secure it to the light stand.

S2 TYPE BRACKET



It can fix with the regular flashes as well as with round shaped flashes.



Figure 3: The S2 Type Bracket allows attachment of various flash types to the soft box.

Ease of setup



*Speedlight not included

Figure 4: Visual guide for attaching the speedlight and bracket to the soft box.

2.3 Installing the Flash Speedlight

6. Open the clamp on the S2 Type Bracket.
7. Slide your flash speedlight into the bracket's mounting area. The S2 bracket is compatible with both regular and round-shaped flashes.
8. Secure the flash by tightening the clamp on the S2 Type Bracket. Ensure the flash is firmly held to prevent accidental dislodgement.

2.4 Attaching Diffuser Sheets

9. The soft box comes with two diffuser sheets: an inner diffuser and an outer diffuser. These are attached via Velcro strips inside the soft box.
10. Attach the inner diffuser first, aligning its Velcro edges with the corresponding strips inside the soft box.
11. Next, attach the outer diffuser to the front opening of the soft box, ensuring it is taut and evenly spread.



Figure 5: The soft box features an octagonal shape and a highly reflective silver lining, with diffuser cloth for softer light.

3. OPERATING INSTRUCTIONS

Once assembled, the Digitek DSBH-055 Soft Box is ready for use to create professional lighting for your photography.

3.1 Basic Operation

- **Positioning:** Place the soft box on a light stand at the desired height and angle relative to your subject. Experiment with different positions to achieve the desired lighting effect.
- **Flash Settings:** Adjust your flash speedlight's power output and zoom settings as needed for your shooting environment and subject. The soft box will diffuse the light, making it softer and more even.
- **Using Diffusers:** The two diffuser sheets work together to soften the flash light and reduce harsh shadows. You can experiment with using only one diffuser (inner or outer) or both to control the level of diffusion.




With Soft Cloth



Without Soft Cloth



**2 diffuser sheets
included**



Soft Light



High
Reflective

Figure 6: Demonstrates the effect of using diffuser sheets for softer light.

Multifunctional



*image for representation purpose

Figure 7: Illustrates the difference between single and double diffuser configurations.

3.2 Applications


The Digitek DSBH-055 Soft Box is versatile and suitable for various photography scenarios:

- **Portrait Photography:** Creates flattering, soft light for subjects.
- **Event Photography:** Ideal for weddings, proms, and corporate events where soft, even lighting is crucial.
- **Product Photography:** Helps eliminate harsh reflections and shadows on products.
- **Fashion Photography:** Provides controlled and aesthetic lighting for models.
- **Indoor Photography:** Enhances ambient light for better exposure and mood.

Ideal for



Interview



Wedding Photography



Fashion Photography



Indoor Photography

Figure 8: The soft box is ideal for various applications including interviews, wedding, fashion, and indoor photography.

Perfect for your needs

Comes with two white diffusers that will aid in improving the lighting and softening the flash for your photographs.



Single Diffuser



Double Diffuser

Figure 9: The soft box offers multifunctional use for various photography needs.

4. MAINTENANCE

Proper care and maintenance will extend the lifespan of your Digitek DSBH-055 Soft Box.

4.1 Cleaning

- **Soft Box Fabric:** Use a soft, dry cloth to wipe down the exterior of the soft box. For stubborn marks, a slightly damp cloth with mild soap can be used, followed by a dry wipe. Ensure the fabric is completely dry before folding and storing.
- **Diffuser Sheets:** The diffuser sheets can be gently hand-washed with mild soap and water if they become dirty. Rinse thoroughly and air dry completely before reattaching or storing.
- **S2 Type Bracket:** Wipe the bracket with a dry or slightly damp cloth to remove dust and grime. Avoid using harsh chemicals that may damage the finish.

4.2 Storage

- To fold the soft box, gently reverse the unfolding process. Ensure all rods are collapsed and the fabric is neatly folded to prevent creasing.
- Store the soft box, S2 bracket, diffuser sheets, and any other accessories in the provided carrying case.
- Keep the carrying case in a cool, dry place away from direct sunlight and extreme temperatures.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your Digitek DSBH-055 Soft Box.

5.1 Uneven Light Output

- **Issue:** Light appears uneven or has hot spots.

- **Solution:**
 - Ensure both inner and outer diffuser sheets are properly installed and taut.
 - Check that the flash speedlight is centered within the S2 Type Bracket and facing directly into the soft box.
 - Verify that the flash's zoom setting is appropriate for the soft box size (usually a wider setting is preferred).

5.2 Difficulty Folding/Unfolding

- **Issue:** The soft box is difficult to open or close.
- **Solution:**
 - Apply gentle, even pressure when opening or closing. Avoid forcing the mechanism.
 - Ensure no fabric is caught in the folding mechanism.
 - If the mechanism feels stiff, check for any obstructions or damage to the rods.

5.3 Soft Box Not Secure on Light Stand

- **Issue:** The soft box wobbles or feels unstable on the light stand.
- **Solution:**
 - Ensure the S2 Type Bracket is fully inserted onto the light stand's spigot.
 - Tighten all locking knobs on the S2 Type Bracket and the light stand securely.
 - Verify that the light stand itself is stable and its legs are fully extended.

6. SPECIFICATIONS

Feature	Detail
Model Number	DSBH-055
Brand	Digitex
Type	Soft Box
Size	55 cm
Material	Nylon
Compatible Devices	All flash speedlights
Product Dimensions (D x W x H)	100D x 40W x 50H Millimeters (folded/packaged)
Item Weight	1300 Grams
Features	Lightweight, Portable, Foldable, High Reflective Silver Lining, S2 Type Bracket

7. WARRANTY AND SUPPORT

7.1 Warranty Information

The Digitex DSBH-055 Soft Box comes with a **1-Year Warranty** from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use. Please retain your purchase receipt as proof of warranty.

The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

7.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact Digitek Customer Support:

- **Toll-Free Number:** 1800-123-544-444
- **Email:** support@digitek.net.in
- **Manufacturer:** IMS Mercantiles Limited
- **Address:** 704, 7th Floor, Ring Road Mall, Sector - 3, Rohini New Delhi - 110085