

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Philips](#) /
- › [Philips PH805 Active Noise Canceling Wireless Headphones User Manual](#)

Philips TAPH805BK

Philips PH805 Active Noise Canceling Wireless Headphones User Manual

Model: TAPH805BK

INTRODUCTION

The Philips PH805 Active Noise Canceling (ANC) Over-Ear Wireless Bluetooth Performance Headphones are designed to deliver high-quality audio with advanced noise cancellation. Enjoy your music without distractions, whether you're traveling or in a busy environment. These headphones offer a comfortable fit, long battery life, and intuitive controls for an enhanced listening experience.

WHAT'S IN THE BOX

- Philips PH805 Wireless Headphones
- Protective Case
- Audio Cable (2.5 mm to 3.5 mm)
- USB Charging Cable
- Aircraft Adapter
- User Manual

PRODUCT OVERVIEW

Familiarize yourself with the key components and features of your Philips PH805 headphones.



Figure 1: Philips PH805 Active Noise Canceling Wireless Headphones.

Comfort and Design

- **Soft Ear-Cup Cushions:** Designed with soft leatherette padding for comfortable wearing and superior noise isolation.
- **Smooth Adjustable Headband:** Lightweight and easily adjustable to prevent tangling with your hair and ensure a secure fit.
- **Flat and Compact Folding:** The headphones can be folded flat and compactly for easy storage in your desk drawer or the included carrying case, making them ideal for travel.

Perfectly tuned comfort

From playlist to podcast, perfectly tuned neodymium acoustic drivers deliver deep bass and clear midrange frequencies.



Flexible design

Fold the soft ear-cups flat for storing in your drawer or the included carrying pouch, or fold them flat and inwards, creating a compact bundle that fits into coat pockets and bags.

Figure 2: Headphones shown in their flat and compact folded state.

Controls and Ports

The headphones feature intuitive controls for power, volume, track navigation, and Active Noise Canceling (ANC) management.



Figure 3: Close-up view of the control buttons and ports on the ear cup.

- **Power Button:** Used to turn the headphones on/off and initiate Bluetooth pairing mode.
- **ANC/Awareness Mode Button:** Toggles Active Noise Canceling on/off or activates Awareness Mode to hear your surroundings.
- **Touch Control Panel:** Located on the ear-housing, allows swiping up/down for volume control and

tapping for play/pause or call management.

- **USB-C Charging Port:** For charging the headphones.
- **2.5 mm Audio Jack:** For wired connection to audio sources.
- **Built-in Microphone:** Features echo cancellation for clear calls.

SETUP

Charging the Headphones

1. Connect the provided USB charging cable to the USB-C port on the headphone.
2. Connect the other end of the USB cable to a compatible USB power source.
3. A full charge takes approximately 2 hours, providing up to 30 hours of playtime (25 hours with ANC on).

Bluetooth Pairing

1. Ensure the headphones are charged.
2. Press and hold the Power button until the LED indicator flashes, indicating pairing mode.
3. On your Bluetooth-enabled device (phone, tablet, computer), go to Bluetooth settings and select "Philips PH805" from the list of available devices.
4. Once paired, the LED indicator will stop flashing and remain solid. The headphones have a Bluetooth range of up to 10 meters.

Wired Connection

For a wired connection, use the included 2.5 mm to 3.5 mm audio cable. This allows for Hi-Res Audio playback when connected to a compatible source, providing lossless audio quality.

OPERATING INSTRUCTIONS

Active Noise Canceling (ANC) and Awareness Mode

Control your listening environment with the dedicated ANC/Awareness Mode button.

- **Activate ANC:** Press the ANC button to reduce ambient noise, ideal for travel or noisy offices.
- **Activate Awareness Mode:** Press the ANC button again to allow some ambient sound to pass through, keeping you aware of your surroundings while still enjoying your audio.
- **Deactivate ANC:** Press the ANC button a third time to turn off both ANC and Awareness Mode.





Figure 4: Active Noise Canceling (ANC) in action, blocking out external noise.

Touch Controls

Manage your audio and calls with simple gestures on the ear cup.

- **Volume Control:** Swipe up or down on the right ear cup to adjust the volume.
- **Play/Pause:** Tap the center of the right ear cup to play or pause music.
- **Answer/End Call:** Tap the center of the right ear cup to answer or end a phone call.
- **Skip Track:** Swipe forward or backward on the right ear cup to skip tracks.



Touch control. Swipe, tap, and press for easy control

Control volume by swiping up or down on the ear-housing touch control panel. You can activate or deactivate Active Noise Canceling with a single press of a button. Or engage Awareness Mode to hear more of the world around you while the music keeps playing.

Built-in mic with echo cancellation

No more of those annoying echoes when you are talking on the phone. With our acoustic echo cancellation, you always get a clear, undisturbed connection.

Figure 5: Demonstrating the touch control functionality on the ear cup.

MAINTENANCE

- Clean the headphones regularly with a soft, dry cloth.
- Avoid exposing the headphones to extreme temperatures, moisture, or dust.
- Store the headphones in their protective case when not in use to prevent damage.
- Do not attempt to disassemble or repair the headphones yourself. Contact customer support for assistance.

TROUBLESHOOTING

Problem	Solution
Headphones do not power on	Ensure the headphones are fully charged.
Cannot pair via Bluetooth	Ensure headphones are in pairing mode (flashing LED). Check your device's Bluetooth settings and try re-pairing. Ensure headphones are within 10 meters of the device.
No sound	Check volume levels on both headphones and connected device. Ensure headphones are properly paired or wired.
ANC not working effectively	Ensure ear cups fit snugly over your ears. Check if ANC is activated.

SPECIFICATIONS

- **Model:** TAPH805BK/00
- **Noise Control:** Active Noise Cancellation
- **Connectivity:** Bluetooth 5.0
- **Bluetooth Range:** 10 Meters
- **Audio Drivers:** 40mm Neodymium Acoustic Drivers
- **Battery Life:** Up to 30 hours (25 hours with ANC on)
- **Charging Time:** Approximately 2 hours
- **Headphones Jack:** 2.5 mm Jack
- **Control Type:** Touch, Physical Buttons
- **Special Features:** Foldable, Lightweight, Microphone Included, Hi-Res Audio (wired mode)
- **Item Weight:** 9.8 Ounces
- **Product Dimensions:** 10.67 x 10.63 x 3.39 inches

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video 1: An overview of the Philips 8000 series noise canceling headphones (TAPH805BK) by Envision Peripherals. This video highlights key features and design aspects of the product.

WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the official Philips Audio website or contact their customer service directly. Details can typically be found in the warranty card included with your product or on the manufacturer's support pages.