

GARNET 9015

GARNET Evolution Napkin Dispenser

Model: 9015 | Brand: GARNET

INTRODUCTION

Thank you for choosing the GARNET Evolution Napkin Dispenser. This manual provides essential information for the proper setup, operation, and maintenance of your new napkin holders. Designed for efficiency and durability, these dispensers are ideal for various settings, from bars to home use.

This product is a set of six plastic napkin dispensers, proudly **Made in Italy**, ensuring quality and design excellence.


PRODUCT OVERVIEW

The GARNET Evolution Napkin Dispenser is crafted from shock-resistant plastic, designed for longevity and ease of use. Each dispenser features a double exit mechanism and a plastic pusher plate to ensure smooth napkin dispensing.

- **Capacity:** Holds approximately 200 standard 17x17 cm bar napkins.
- **Material:** High-quality, shock-resistant plastic.
- **Color:** Black.
- **Dimensions:** 9 cm (Depth) x 9.5 cm (Width) x 14 cm (Height).
- **Weight:** 1.3 Kilograms (for the set of 6).
- **Features:** Double napkin exit with pusher plate.
- **Safety:** BPA Free.



**Creati per i professionisti,
perfetti per la casa**



Produzione 100% Italiana



Eco-Friendly

**Garnet Europe srl
Via Emilia 7/9/11
27050 Torrazza Coste (PV)
Tel 0383.364320**



www.garneteurope.com

Image: The GARNET Evolution Napkin Dispenser in black, shown next to a coffee cup, illustrating its compact size and design. Labels indicate 'Capiente' (Capacious), 'Doppia Apertura' (Double Opening), and 'Design Unico' (Unique Design).



Image: Front view of the GARNET Evolution Napkin Dispenser, showcasing its sleek black design and the napkin opening.



Image: A close-up view of the napkin dispenser, highlighting the double entry design for napkins.

SETUP

The GARNET Evolution Napkin Dispenser is designed for simple assembly. During transport, the top part may detach from the bottom part. This is not a defect, as it is intentionally designed to fit together. To reassemble:

1. Remove the napkin pusher spring.
2. Align and firmly press the top part onto the bottom part until it clicks into place.
3. Reinsert the napkin pusher spring.



Image: A detailed view of the top section of the napkin dispenser, showing its curved design.




Image: A detailed view of the base of the napkin dispenser, illustrating its sturdy construction.

OPERATING INSTRUCTIONS

To load napkins into your GARNET Evolution dispenser, follow these steps:

1. **Do not remove the top cover.** The dispenser is designed for loading without detaching the top.
2. Place the napkin holder on a flat, stable surface.
3. Gently push the stack of napkins into the opening until the holder is completely filled. The internal pusher plate will compress the napkins.



ISTRUZIONI INSERIMENTO TOVAGLIOLI

- **NON rimuovete la copertura superiore**
- **Adagiare il portatovagliolo su una superficie piana**
- **Delicatamente spingere i tovaglioli nell'apertura sino a caricamento completo del portatovagliolo**

Image: Visual instructions demonstrating the correct method for inserting napkins into the dispenser. It shows to gently push napkins into the opening without removing the top cover.

Instructional Video

Video: A demonstration of how to load napkins into a similar napkin dispenser. This video illustrates the process of inserting napkins into the holder for proper use.

MAINTENANCE

To ensure the longevity and hygiene of your GARNET Evolution Napkin Dispenser, follow these simple maintenance guidelines:

- **Cleaning:** The plastic material is easy to clean. Use a soft, damp cloth with mild soap and water to wipe down the exterior. Avoid abrasive cleaners or harsh chemicals that could damage the plastic.
- **Drying:** After cleaning, dry the dispenser thoroughly with a clean, dry cloth to prevent water spots.
- **Inspection:** Periodically check the napkin pusher spring for proper function. If it feels stiff initially, continued use will typically improve its flexibility.

TROUBLESHOOTING

Here are solutions to common issues you might encounter with your napkin dispenser:

Issue: Top part detaches during transport or handling.

Solution: This is a common occurrence due to the design. Simply reattach the top part by aligning it with the bottom and pressing firmly until it snaps into place. Ensure the napkin pusher spring is correctly positioned before reattaching.

Issue: Napkins do not dispense smoothly or the spring feels weak.

Solution: Ensure you are using standard 17x17 cm bar napkins. Overfilling the dispenser can sometimes hinder smooth operation. If the plastic spring feels stiff, it may soften with continued use. If the spring is broken, contact customer support for assistance.

Issue: Lid does not stay attached after some use.

Solution: While the product is made from durable plastic, repeated forceful handling or impacts can affect the fit of the lid. Ensure the dispenser is handled gently, especially when loading napkins. If the issue persists, consider contacting customer support.

SPECIFICATIONS

Feature	Detail
Brand	GARNET
Model Number	9015
Material	Plastic
Color	Black
Product Dimensions (D x W x H)	9 cm x 9.5 cm x 14 cm
Item Weight (Set of 6)	1.3 Kilograms
Capacity	Approx. 200 standard 17x17 cm napkins
Special Features	Double napkin exit, Plastic pusher plate, Shock-resistant, BPA Free
Country of Origin	Italy

WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your GARNET Evolution Napkin Dispenser, please contact the seller, **Garnet Italia**, directly through your purchase platform. While specific warranty details are not provided, customer satisfaction is important.

You can also visit the official GARNET Europe website for more information: www.garneteurope.com