

[Manuals.plus](#) /

› [Kircuit](#) /

› Kircuit AC Power Adapter for Conair BMS2RTR Seat Cushion Massager Instruction Manual

## Kircuit Kircuit AC Power Adapter

# Kircuit AC Power Adapter for Conair BMS2RTR Seat Cushion Massager Instruction Manual

## 1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Kircuit AC Power Adapter. This adapter is specifically designed to provide power to the Conair BMS2RTR Seat Cushion Massager. Please read this manual thoroughly before use and retain it for future reference.

## 2. SAFETY INFORMATION

**WARNING:** Failure to follow these safety instructions could result in fire, electric shock, or injury.

- Ensure the adapter's voltage and current ratings match the requirements of your device (Conair BMS2RTR Seat Cushion Massager).
- Do not expose the adapter to water, rain, or excessive moisture.
- Do not use the adapter if the cord is damaged or frayed.
- Avoid placing the adapter in direct sunlight or near heat sources.
- Always unplug the adapter from the wall outlet before cleaning or when not in use for extended periods.
- Keep out of reach of children.
- This adapter is for indoor use only.

## 3. PRODUCT OVERVIEW

The Kircuit AC Power Adapter is a replacement or backup power supply for compatible devices. It features a standard AC input plug and a DC output connector.



Figure 1: Kircuit AC Power Adapter. This image shows the main body of the adapter with its two-prong US plug and the coiled output cable

ending in a barrel connector.



Figure 2: Adapter with cord length indication. The image highlights the approximate 6.5 ft length of the power cord.

- The plugs on the power cable also well-made and designed to provide a secure and stable connection.
- The plugs can handle high electrical loads without overheating or causing a fire hazard.




Figure 3: Plug Design Comparison. This graphic illustrates the robust and secure design of the Kircuit adapter's plug compared to less stable alternatives.

## 4. SETUP INSTRUCTIONS

1. **Verify Compatibility:** Ensure your device, such as the Conair BMS2RTR Seat Cushion Massager, requires an AC adapter with the specifications provided by this Kircuit adapter.
2. **Connect to Device:** Insert the DC output connector of the Kircuit adapter firmly into the power input port of your Conair BMS2RTR Seat Cushion Massager.
3. **Connect to Power Outlet:** Plug the AC input prongs of the adapter into a standard 100V-240V AC wall outlet.
4. **Power On:** Once connected, your device should be ready for operation.



Figure 4: Adapter connected to a power strip. This image demonstrates the adapter plugged into a multi-outlet power strip on a desk, ready for use.

## 5. OPERATING INSTRUCTIONS

Once the Kircuit AC Power Adapter is correctly connected to both the power outlet and your Conair BMS2RTR Seat Cushion Massager, operate your device according to its own instruction manual. The adapter provides continuous power for the device's functions.

- Ensure the adapter is not covered during operation to allow for proper ventilation.
- If the device does not power on, check all connections.

## 6. MAINTENANCE AND CARE

- **Cleaning:** Disconnect the adapter from the power outlet and the device. Wipe the adapter with a dry, soft cloth. Do not use liquid cleaners or abrasive materials.

- **Storage:** Store the adapter in a cool, dry place when not in use. Avoid tightly coiling the cord to prevent damage.
- **Inspection:** Periodically inspect the adapter and cord for any signs of damage, such as cuts, fraying, or exposed wires. Discontinue use if damage is found.

## Durable design



Figure 5: Durable design features. This graphic illustrates the robust construction of the power cable with thick insulation and the secure, stable design of the plug.

## 7. TROUBLESHOOTING

| Problem                            | Possible Cause                                                                                                                    | Solution                                                                                                                                                                                      |
|------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Device not powering on.            | Adapter not fully plugged in.<br>Device not properly connected.<br>Wall outlet not functioning.<br>Adapter or device malfunction. | Ensure adapter is securely plugged into wall outlet.<br>Ensure DC connector is firmly inserted into device.<br>Test wall outlet with another appliance.<br>Contact support if issues persist. |
| Adapter feels warm during use.     | Normal operation.<br>Poor ventilation.                                                                                            | A slight warmth is normal. Ensure adapter is in a well-ventilated area and not covered. If excessively hot, discontinue use and unplug.                                                       |
| Visible damage to cord or adapter. | Physical damage.                                                                                                                  | Discontinue use immediately. Do not attempt to repair. Replace the adapter.                                                                                                                   |

## 8. SPECIFICATIONS

- **Input:** 100V-240V AC, 50/60Hz, 0.3A
- **Output:** Matches device requirements (specific voltage/current not explicitly provided on adapter label)
- **Cord Length:** Approximately 6.5 feet (1.98 meters)
- **Weight:** 8 ounces (approximately 227 grams)
- **Safety Features:** Built-in Dynamic IC, Charger IC, Power fuse for rapid charging and overcharge protection. Includes short circuit protection, excess voltage protection, over temperature protection, and overcurrent protection.

## Built Safety Protections




Figure 6: Built-in Safety Protections. This graphic details the adapter's safety features including short circuit, excess voltage, over temperature, and overcurrent protection.

## 9. WARRANTY AND SUPPORT

Kircuit products are designed for reliability and performance. For warranty information or technical support, please refer to the contact information provided with your purchase or visit the official Kircuit website. Please have your product model and purchase details ready when contacting support.

Kircuit AC Power Adapter Instruction Manual

Model: Kircuit AC Power Adapter (Compatible with Conair BMS2RTR)

© 2023 Kircuit. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**<https://manuals.plus/asin/B0823PJPQT>**

More documents and user manuals: **<https://manuals.plus/>**