

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [INTERGREAT](#) /

› [INTERGREAT 6-Door Metal Employee Locker Instruction Manual](#)

INTERGREAT 6doorb

INTERGREAT 6-Door Metal Employee Locker Instruction Manual

Model: 6doorb

1. IMPORTANT SAFETY INFORMATION

Please ensure the lock is properly secured. Do not overload the lockers as this may cause damage or injury. Be cautious when using the lock mechanism to avoid pinching fingers.

Always inspect the product for any damage upon arrival. If any parts appear damaged or misaligned, contact customer support before proceeding with assembly.

2. PRODUCT OVERVIEW

The INTERGREAT 6-Door Metal Employee Locker is designed for secure storage in various environments such as offices, schools, and gyms. This unit features six individual compartments, each equipped with a locking mechanism for personal security.

- **High Security:** Each door is equipped with a recessed hasp, compatible with integrated lock and keys for secure storage.
- **Durable Construction:** Made from high-thickness cold-rolled steel, with an electrostatic paint layer and phosphorus-free conversion film for rust, corrosion, and moisture prevention.
- **Ventilation:** Louvered doors promote air circulation to prevent moisture and odors.
- **Versatile Use:** Suitable for storing shoes, sports gear, bags, backpacks, homework supplies, office supplies, and cleaning supplies.
- **Capacity:** Each shelf is designed to hold up to 50 pounds.



Figure 1: Front view of the INTERGREAT 6-Door Metal Employee Locker.

3. ASSEMBLY INSTRUCTIONS

Assembly of the INTERGREAT 6-Door Metal Employee Locker is required. It is recommended to have two people for easier assembly. The package includes necessary tools and gloves.

3.1. Preparation

- Unpack all components and verify against the parts list (refer to the included manual for a detailed list).
- Ensure you have a clear, flat workspace.
- Wear the provided safety gloves during assembly.

3.2. Assembly Tip

Important: Do not fully tighten any bolts until all bolts are fixed into their corresponding positions. Once all components are aligned and bolts are in place, then proceed to tighten them securely.




Figure 2: Visual guide for assembly, indicating tools and estimated time.

3.3. Dimensions

The assembled locker unit measures approximately 17 inches deep, 15 inches wide, and 72 inches high. Each individual compartment has internal dimensions of approximately 16.5 inches high, 14.5 inches deep, and 11 inches wide.



Figure 3: Detailed product dimensions for the 6-door locker.

4. OPERATING INSTRUCTIONS

4.1. Locking and Unlocking

Each door is equipped with a recessed hasp and comes with a set of keys. To lock a compartment, close the door and insert the key into the lock. Turn the key clockwise to secure the door. To unlock, insert the key and turn counter-clockwise.

LONG-LIFE TO USE

we selected high-thickness cold-rolled steel, electric painted with environmental protection, easy to clean and maintain, great for indoor or outdoor using



rust
prevention



corrosion
prevention



Moisture
proof




Figure 4: Details of the locking mechanism, handle, name tag slot, and louvered ventilation.

4.2. Storage Capacity

Each individual compartment is designed to hold various items. The maximum weight capacity for each shelf is 50 pounds. Avoid exceeding this limit to prevent damage to the locker or its contents.



Figure 5: Examples of suitable items for storage within the locker compartments.


5. MAINTENANCE

5.1. Cleaning

To clean the locker, simply use a soft cloth dampened with water. Avoid abrasive cleaners or harsh chemicals, as these may damage the powder-coated finish.

5.2. Rust and Corrosion Prevention

The locker is constructed with high-thickness cold-rolled steel, featuring an electrostatic paint layer and phosphorus-free conversion film to resist rust, corrosion, and moisture. Regular cleaning and ensuring the locker is not exposed to excessive moisture will help maintain its condition.



**STORE ANYTHING IN
72 "" H METAL LOCKER**


Tidy Up Your Home, Garage, Office, Gym or More



Hardware Tool



Clothes and Shoes



School Supplies



Sports Supplies

50 LBS

Each Shelf Can Hold Up to 50LBS

Figure 6: Material layers contributing to the locker's durability and protective properties.

6. TROUBLESHOOTING

- **Difficulty during assembly:** Ensure all parts are correctly oriented according to the diagrams in the included manual. Remember the assembly tip: do not fully tighten bolts until all are in place.
- **Doors not closing properly:** Check for any obstructions within the compartment or along the door frame. Verify that the locker is assembled squarely and is on a level surface.
- **Lock mechanism issues:** Ensure the key is fully inserted and turned correctly. Avoid forcing the lock. If a lock is stiff, a small amount of graphite lubricant can be applied to the keyhole.
- **Dents or damage upon arrival:** If the product arrives with significant dents or damage, document it with photographs and contact INTERGREAT customer service immediately for assistance.

7. SPECIFICATIONS

Feature	Detail
Brand	INTERGREAT

Feature	Detail
Model Number	6doorb
Color	Black
Product Dimensions (Overall)	17"D x 15"W x 72"H
Compartment Dimensions (Approx.)	16.5"H x 14.5"D x 11"W
Special Feature	Lockable
Mounting Type	Floor Mount
Material	Metal, Alloy Steel
Finish Type	Powder Coated
Number of Doors/Compartments	6
Weight Limit (Per Shelf)	50 Pounds
Item Weight (Total)	50 Pounds
Included Components	Key Box (contains keys)
Assembly Required	Yes

8. WARRANTY AND SUPPORT

8.1. Warranty Information

For detailed warranty information regarding your INTERGREAT 6-Door Metal Employee Locker, please refer to the documentation included with your purchase or contact INTERGREAT directly. Protection plans may be available for purchase separately.

8.2. Customer Support

If you encounter any issues, have questions about assembly, or require replacement parts, please contact INTERGREAT customer support. Contact details can typically be found on the product packaging, the included manual, or the official INTERGREAT website.

You can also visit the [INTERGREAT Store on Amazon](#) for more information.