OMOTON 80-2N1J-LVR5

OMOTON Bluetooth Wireless Keyboard and Mouse Instruction Manual

Model: 80-2N1J-LVR5

1. INTRODUCTION

This manual provides detailed instructions for setting up and operating your OMOTON Bluetooth Wireless Keyboard and Mouse combo. This cable-free solution connects directly to your Bluetooth-enabled devices, offering convenience and portability.

The keyboard features a QWERTY layout with hotkeys customized for iPads, including volume, music control, and brightness. The mouse is designed for ergonomic comfort with quiet clicks. Both devices are lightweight and slim, making them ideal for on-the-go use.


Image: OMOTON Bluetooth Wireless Keyboard and Mouse combo in a typical desktop setup with an iPad.

2. SPECIFICATIONS

- **Keyboard Bluetooth Version:** Bluetooth 3.0
- **Mouse Bluetooth Version:** Bluetooth 5.0

- **Keyboard Dimensions:** 285 x 120 x 6 mm (11.2 x 4.7 x 0.2 inches)
- **Mouse Dimensions:** 110 x 62 x 30 mm (4.33 x 2.44 x 1.18 inches)
- **Keyboard Weight:** 282g (11.7 ounces)
- **Mouse Weight:** 50g
- **Operating Distance:** Up to 10 meters (33 feet)
- **Keyboard Battery:** 2 x AAA batteries (not included)
- **Mouse Battery:** 1 x AA battery (not included)
- **Keyboard Battery Life:** Up to 120 days
- **Mouse Battery Life:** Up to 60 days
- **Special Feature:** Ergonomic design, mute clicks

Image: Detailed dimensions of the OMOTON Bluetooth Wireless Keyboard and Mouse.

3. SETUP

3.1 Battery Installation

1. **For the Keyboard:**

   a. Locate the battery compartment on the back of the keyboard.

   b. Slide open the battery cover.

   c. Insert 2 AAA batteries, ensuring correct polarity.

   d. Close the battery cover securely.

2. **For the Mouse:**

   a. Gently lift the top cover of the mouse to reveal the battery compartment.

   b. Insert 1 AA battery, ensuring correct polarity.

   c. Align the cover and press it back into place until it clicks securely.

Image: Back view of the keyboard with the battery cover open, and the mouse with its top cover removed for battery insertion.

BATTERY INSTALLATION STEPS

① Open the cover

② Insert the battery

③ Cover the cover

Image: Visual guide demonstrating the three steps to install the AA battery in the OMOTON mouse.

3.2 Pairing Instructions

Before pairing, ensure your device's operating system is updated to iPadOS 13.1 / iOS 13 or above. For mouse functionality on iOS/iPadOS, you must enable 'AssistiveTouch' in your device settings.

1. **Enable AssistiveTouch (for iOS/iPadOS devices):**
   a. Go to your device's **Settings**.
   b. Select **Accessibility**.
   c. Tap on **Touch**.
   d. Turn on **AssistiveTouch**.

2. **Turn on the Keyboard:**
   a. Slide the power switch on the back of the keyboard from OFF to ON.
   b. The battery indicator light will flash briefly.

3. **Activate Keyboard Pairing Mode:**
   a. Press the 'Connect' button on the back of the keyboard for 2-3 seconds.
   b. The battery indicator will flash continuously, indicating it's in pairing mode.

4. **Turn on the Mouse:**
   a. Slide the power switch on the bottom of the mouse from OFF to ON.
   b. A blue light will appear briefly.

5. **Activate Mouse Pairing Mode:**
   a. Long press the 'Connect' button on the bottom of the mouse for more than 5 seconds until the

indicator light flashes.

6. **Connect via Bluetooth on Your Device:**

a. On your iPad, iPhone, or other Bluetooth-enabled device, go to **Settings** > **Bluetooth**.

b. Ensure Bluetooth is turned ON.

c. Look for 'Bluetooth Keyboard' and 'BT5.0 Mouse' in the list of available devices.

d. Tap on each device name to connect. You may be prompted to enter a PIN code for the keyboard; type the code displayed on your screen into the OMOTON keyboard and press 'Enter'.

Image: Steps to enable AssistiveTouch on an iPad, crucial for mouse functionality.

Your browser does not support the video tag.

Video: Official OMOTON guide demonstrating the pairing process for the Bluetooth Keyboard and Mouse combo with an iPad.

4. OPERATING INSTRUCTIONS

4.1 Keyboard Usage

- **Typing:** The keyboard provides a comfortable and responsive typing experience.
- **Hotkeys:** Utilize the dedicated hotkeys for quick access to functions like volume control, media playback, and screen brightness (functionality may vary slightly depending on the connected device and OS).
- **Power Saving:** The keyboard automatically enters power-saving mode after 10 minutes of inactivity. Press any key and wait 2-3 seconds to wake it up.
- **Note:** This keyboard does not include an Escape key.

4.2 Mouse Usage

- **Clicking:** The mouse features quiet left and right clicks.
- **Scrolling:** Use the scroll wheel for navigation.
- **Ergonomic Design:** The mouse is designed to provide all-day comfort for work and

5. COMPATIBILITY

The OMOTON Bluetooth Wireless Keyboard and Mouse are compatible with a wide range of Bluetooth-enabled devices:

- **iPad Series:** Requires iPadOS 13.1 or above. Includes iPad 10.9 (10th/9th/8th Gen), iPad Pro 13/11 inch M4 2024, iPad Air 13/11 inch M2 2024, iPad Air 5, iPad mini 6, iPad Pro 12.9/11/10.5/9.7, iPad Air 2, iPad mini 5/4.
- **iPhone Series:** Requires iOS 13 or above. Includes iPhone SE (2020, 2nd Gen), iPhone 11 Pro Max/11 Pro/11, iPhone Xs Max/Xs/X/8/8 Plus, iPhone 7/7 Plus, iPhone 6S/6S Plus.
- **Other Devices:** Android tablets, MacBooks, MacBook Pros, and Bluetooth-enabled PCs or Laptops with Windows XP/Vista/7/8/10 (hotkeys may not work 100% on Windows).

Important Note: Not compatible with iPad 1/2/3/4, iPad mini 1/2/3, and iPhone 4s/5s or lower editions that cannot be updated to iPadOS 13 or iOS 13.

Image: The OMOTON keyboard and mouse are shown with various compatible Apple devices, including iPads and iPhones.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the keyboard and mouse. Avoid using harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when performance degrades. Ensure correct battery type (AAA for keyboard, AA for mouse) and polarity.
- **Storage:** Store the devices in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.

7. TROUBLESHOOTING

- **Device Not Connecting:**
  a. Ensure both the keyboard and mouse are powered on and in pairing mode.
  b. Check that Bluetooth is enabled on your host device.
  c. Make sure your device's operating system is updated to the required version (iPadOS 13.1 / iOS 13 or above).
  d. Try restarting your host device and repeating the pairing steps.
- **Mouse Cursor Issues (iOS/iPadOS):**
  If number keys or letter keys move the cursor instead of typing characters on your iPad or iPhone, navigate to **Settings** > **Accessibility** > **Touch** > **AssistiveTouch** and turn off 'Mouse Keys'.
- **Lag or Disconnection:**
  a. Ensure the devices are within the 10-meter operating range of your host device.
  b. Check for interference from other wireless devices.
  c. Replace batteries if they are low.
- **Keyboard Not Waking Up:**
  If the keyboard is in power-saving mode, press any key and wait 2-3 seconds for it to reconnect.

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact OMOTON customer service directly. Keep your purchase receipt for any warranty claims.