



[Manuals.plus](#) /

> [LipiWorld](#) /

> LipiWorld FD-SPK013 Home Theater System Remote Control User Manual

## LipiWorld FD-SPK013 Home Theater Remote for F & D

# LipiWorld FD-SPK013 Home Theater System Remote Control User Manual

Model: FD-SPK013 Home Theater Remote for F & D

## INTRODUCTION

---

This user manual provides essential information for the proper setup, operation, and maintenance of your LipiWorld FD-SPK013 Home Theater System Remote Control. This remote is designed as a compatible replacement for various F & D Home Theater Systems. Please read this manual thoroughly before use to ensure optimal performance and longevity of your remote control.

## SETUP

---

### 1. Compatibility Check

Before using the remote, it is crucial to verify its compatibility with your existing F & D Home Theater System. The new remote must be **exactly the same** in terms of function-to-function button layout as your original or old remote. If the button layout differs, the remote may not function correctly with your system.



Please check the **OLD (Original)** remote and **NEW ONE (Function to Function)**, It must be exactly same, **BEFORE YOU BUY.**



*Figure 1: Ensure the new remote's button layout matches your original remote for full compatibility.*



*Figure 2: Important notice regarding remote compatibility and the necessity of using fresh batteries.*

## 2. Battery Installation

The LipiWorld FD-SPK013 remote control requires batteries for operation. Please ensure you use **fresh, new batteries** for optimal performance and longevity. The remote uses Alkaline batteries.

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert the required batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely.



LipiWorld

Make sure to use  
**FRESH**  
**BATTERIES.**



*Figure 3: Proper battery installation is essential for the remote's functionality.*

## OPERATING INSTRUCTIONS

---

This remote control is designed for intuitive operation of your F & D Home Theater System. Below are the general functions of the buttons.



Figure 4: Overview of the LipiWorld FD-SPK013 Remote Control.

- **Power Button (Red):** Turns the home theater system on or off.
- **Numeric Keypad (0-9):** For direct input of track numbers, radio frequencies, or other numerical selections.
- **SOURCE:** Selects the audio input source (e.g., AUX, USB, Bluetooth).
- **SOUND:** Adjusts sound modes or equalizer settings.
- **LIGHT:** Controls the system's display or LED lights.
- **RESET:** Resets certain settings to default.
- **Navigation Buttons (TUNE+, TUNE-, Enter, Left/Right/Up/Down):** Used for navigating menus, tuning radio stations, or adjusting settings.
- **SCAN:** Initiates a scan for radio stations.
- **MEM (Memory):** Saves radio stations or other settings.
- **Playback Controls (Previous, Play/Pause, Next):** Controls media playback (e.g., for USB or Bluetooth audio).
- **Volume Controls (FRONT+, FRONT-, CENTER+, CENTER-, REAR+, REAR-):** Adjusts volume levels for individual speaker channels.
- **SW+, SW-:** Adjusts subwoofer volume levels.

For detailed functionality of each button, please refer to your F & D Home Theater System's original user manual, as this remote is a compatible replacement designed to mimic its functions.

## MAINTENANCE

---

### Battery Care

- Always use fresh, high-quality batteries.
- If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote.
- Do not mix old and new batteries, or different types of batteries.

### Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive pads,

or chemical solvents, as these can damage the remote's surface or internal components.

## Storage and Handling

- Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid dropping the remote, as this can cause internal damage or breakage of the plastic casing. Consider using a protective cover for long-term use.
- Keep the remote away from liquids and excessive dust.

## TROUBLESHOOTING

---

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with fresh ones.
  - Ensure there is a clear line of sight between the remote's infrared emitter and the home theater system's receiver. Obstructions can block the signal.
  - Verify that the remote is pointed directly at the home theater system.
- **Some functions not working:**
  - Re-confirm that this remote is an exact functional match to your original F & D remote. If the button layout or internal coding differs, some functions may not be supported.
  - Ensure the home theater system is in the correct mode (e.g., AUX, USB) for the desired function.
- **Remote feels loose or makes noise:**
  - This may indicate internal components have come loose, possibly due to a drop. While the remote is designed to be durable, repeated impacts can cause damage.

## SPECIFICATIONS

---

Feature	Detail
Brand	LipiWorld
Model Name	FD-SPK013
Compatible Devices	Home Theater (F & D Systems)
Connectivity Technology	Infrared
Power Source	Battery Powered
Battery Type	Alkaline (Batteries Not Included)
Material	Plastic
Special Features	Ergonomic, Lightweight
Item Weight	40 g
Country of Origin	China

## WARRANTY AND SUPPORT

---

Specific warranty details for this product are not provided in the available information. For any warranty claims, technical support, or further inquiries, please contact the manufacturer, LipiWorld, directly through their official channels or the retailer from whom the product was purchased.

LipiWorld is a registered trademark brand. For more information, you may refer to their official brand store or contact customer service.

[Visit the LipiWorld Store on Amazon.in](#)

© 2024 LipiWorld. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.