

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [GROOVYPETS](#) /
- › [GROOVYPETS GPT700 Remote Dog Training Collar Replacement Remote Controller User Manual](#)

GROOVYPETS T700

GROOVYPETS GPT700 Remote Dog Training Collar Replacement Remote Controller User Manual

[Introduction](#) [Product Overview](#) [Setup](#) [Operating Instructions](#) [Maintenance](#) [Troubleshooting](#)
[Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides instructions for the GROOVYPETS GPT700 Replacement Remote Controller. This device is designed to function as a spare or replacement remote for your existing GROOVYPETS T700 dog training collar system. Please read these instructions carefully before use to ensure proper operation and to maximize the lifespan of your product.

2. PRODUCT OVERVIEW

The GROOVYPETS GPT700 Replacement Remote Controller is a handheld device used to operate a compatible GROOVYPETS T700 dog training collar receiver. It features an ergonomic design for comfortable handling and includes an antenna for reliable signal transmission.



Image 1: Front view of the GROOVYPETS GPT700 Remote Controller. The remote is black with an orange GROOVYPETS logo and text, and "FCC ID: 2ATOXT700" printed at the bottom. It has a small antenna at the top.

3. SETUP: SYNCING THE REMOTE CONTROLLER

Before using your new replacement remote controller, it must be synced with your existing GROOVYPETS T700 receiver collar. Follow these steps for successful pairing:

1. **Ensure Receiver is Ready:** Make sure your GROOVYPETS T700 receiver collar is charged and powered on. Refer to your original receiver collar manual for specific instructions on powering it on.
2. **Activate Pairing Mode on Receiver:** Typically, this involves pressing and holding a button on the receiver collar until an indicator light begins to flash, signaling it is in pairing mode. Consult your receiver collar's manual for the exact procedure.
3. **Initiate Pairing on Remote:** With the receiver in pairing mode, activate the pairing function on the replacement remote controller. This often involves pressing and holding a specific button or a combination of buttons on the remote. The exact button(s) and duration may vary; refer to the original GROOVYPETS T700 system manual for precise instructions.

4. **Confirm Pairing:** Once successfully paired, the indicator light on the receiver collar will typically stop flashing and remain solid, or emit a confirmation tone. Test the remote's functions (e.g., vibration, tone) to ensure it controls the receiver as expected.

Note: If you encounter difficulties, ensure both devices are sufficiently charged and within range. Repeat the syncing process if necessary. For detailed pairing instructions specific to your GROOVYPETS T700 receiver, please consult the manual that came with your original collar system.

4. OPERATING INSTRUCTIONS

Once the replacement remote controller is successfully synced with your GROOVYPETS T700 receiver collar, you can use it to deliver training commands. The remote is designed to control one receiver collar at a time.

4.1 Basic Functions

The remote controller typically features buttons for various training modes. Common functions include:

- **Tone/Beep:** Emits an audible sound from the receiver collar.
- **Vibration:** Delivers a non-stimulus vibration to the receiver collar.
- **Static Stimulation (Shock):** Provides a static pulse to the receiver collar. This function usually has adjustable intensity levels.

Refer to your original GROOVYPETS T700 system manual for the specific button layout and corresponding functions of your remote controller.

4.2 Power Management

- **Power On/Off:** The remote controller may have a dedicated power button or enter a low-power standby mode automatically.
- **Battery Indicator:** Check the remote for any LED indicators that show battery status. Recharge the remote when the battery is low.

5. MAINTENANCE

Proper care will extend the life of your GROOVYPETS GPT700 Replacement Remote Controller.

- **Cleaning:** Wipe the remote with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the remote in a dry place at room temperature when not in use. Avoid extreme temperatures.
- **Battery Care:** Recharge the remote's battery regularly, even if not in frequent use, to maintain battery health. Avoid fully depleting the battery for extended periods.
- **Water Exposure:** While some remotes may be water-resistant, avoid submerging the device in water unless explicitly stated in the original product manual.

6. TROUBLESHOOTING

If you experience issues with your GROOVYPETS GPT700 Replacement Remote Controller, try the following solutions:

Problem	Possible Solution

Problem	Possible Solution
Remote does not control the receiver collar.	<ul style="list-style-type: none"> Ensure the remote and receiver are both powered on. Check the battery level of both the remote and receiver. Recharge if necessary. Re-sync the remote controller with the receiver collar (refer to Section 3: Setup). Ensure you are within the effective range of the system.
Remote's indicator light is not working.	<ul style="list-style-type: none"> Check the remote's battery level and recharge it. If the remote has been dropped or damaged, internal components may be affected.
Shortened range or intermittent control.	<ul style="list-style-type: none"> Ensure there are no large obstacles (e.g., thick walls, metal structures) between the remote and receiver. Check for sources of radio interference. Ensure both devices are fully charged.

If these steps do not resolve the issue, please contact GROOVYPETS customer support for further assistance.

7. SPECIFICATIONS

Feature	Detail
Model Number	T700
Brand	GROOVYPETS
Compatible Devices	GROOVYPETS T700 Shock Collar Receiver
Max Number of Supported Devices	1 (one receiver collar)
Connectivity Technology	Infrared
Special Feature	Ergonomic design
ASIN	B08265XFJ4

8. WARRANTY & SUPPORT

8.1 Warranty Information

Specific warranty details for the GROOVYPETS GPT700 Replacement Remote Controller are typically provided with the original product purchase or can be obtained directly from the manufacturer. Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact GROOVYPETS customer support. Refer to the packaging or the official GROOVYPETS website for current contact information.

© 2026 GROOVYPETS. All rights reserved.