

[manuals.plus](#) /› [Playmobil](#) /› [Playmobil My Supermarket \(Model 70375\) Instruction Manual](#)

Playmobil 70375

Playmobil My Supermarket (Model 70375) Instruction Manual

Brand: Playmobil | Model: 70375

1. INTRODUCTION

Welcome to the Playmobil My Supermarket playset! This manual provides essential information for the assembly, operation, and care of your new toy. The Playmobil My Supermarket allows children to engage in imaginative play, simulating a grocery shopping experience with various items and figures.

2. SAFETY INFORMATION

Warning: Choking Hazard. Small parts. Not for children under 3 years.

- Always supervise young children during play to prevent accidental ingestion of small parts.
- Keep packaging materials away from children to avoid suffocation risks.
- Inspect all parts regularly for damage. Discontinue use if any part is broken or damaged.

3. PACKAGE CONTENTS

The Playmobil My Supermarket set (Model 70375) includes approximately 100 pieces, designed for a complete play experience. Key components are:

- Two Playmobil figures
- Supermarket counter
- Shelving units
- Stackable shopping baskets
- Assortment of fresh produce (fruits and vegetables)
- Canned goods
- Beverages
- Flowers
- Various other accessories to enhance the supermarket theme.

Please verify all components are present upon opening the package. If any parts are missing or damaged, please contact Playmobil customer support.

4. SETUP AND ASSEMBLY

Assembly of the Playmobil My Supermarket is generally straightforward. Follow the pictorial instructions provided in the box for step-by-step guidance. No tools are typically required for assembly.

1. Carefully unpack all components and lay them out on a clean, flat surface.
2. Assemble the main supermarket structure by connecting the wall and roof pieces as indicated in the instructions.
3. Place the counter and shelving units inside the supermarket.
4. Arrange the various food items, beverages, and flowers on the shelves and in the baskets.
5. Position the Playmobil figures to begin the shopping experience.

This set can be combined with other Playmobil My Town theme world sets (e.g., #70015-70017, 70376) for expanded play scenarios. Refer to the individual manuals for those sets for their specific assembly instructions.

5. OPERATING INSTRUCTIONS (PLAY SCENARIOS)

The Playmobil My Supermarket is designed for imaginative role-play. Here are some suggested ways to interact with the set:

- **Shopping Experience:** Use the Playmobil figures to act out a shopping trip. Select fresh fruits and vegetables, drinks, and sweet treats from the shelves.
- **Basket Use:** Place selected items into the stackable baskets.
- **Checkout:** Bring the items to the counter for checkout.
- **Stocking Shelves:** Role-play stocking the shelves with new inventory.
- **Price Awareness:** Note that prices are clearly marked on each item, adding to the realistic play.

6. MAINTENANCE

To ensure the longevity of your Playmobil My Supermarket set, follow these simple maintenance guidelines:

- **Cleaning:** Wipe down all plastic parts with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the playset in a clean, dry place away from direct sunlight and extreme temperatures to prevent material degradation.
- **Inspection:** Periodically check for any loose or broken parts. Replace or repair as necessary.

7. TROUBLESHOOTING

Most issues with Playmobil sets can be resolved with simple checks:

- **Missing Parts:** If you discover any missing parts upon opening, refer to the "Package Contents" section and contact Playmobil customer support.
- **Assembly Difficulties:** Double-check the pictorial instructions. Ensure all pieces are oriented correctly and snapped firmly into place. Do not force parts together.
- **Damaged Parts:** If a part breaks during play, remove it immediately to prevent injury. Contact customer support for replacement options.

8. SPECIFICATIONS

Feature	Detail
Brand	Playmobil
Model Number	70375
Number of Pieces	Approximately 100
Material Type	Plastic
Product Dimensions (L x W x H)	38.5 x 28.4 x 12.5 cm (10.2 x 13 x 15.7 inches for the assembled supermarket)
Item Weight	200 Grams
Recommended Age	3 years and up (Manufacturer recommended age)
Assembly Required	No (referring to tools, but assembly of parts is needed)
Batteries Required	No

9. WARRANTY AND SUPPORT

For warranty information, replacement parts, or customer support, please visit the official Playmobil website or contact their customer service department. Keep your proof of purchase for any warranty claims.

You can find more information and contact details on the [Playmobil Store on Amazon](#).

10. PRODUCT IMAGES



Image 1: The complete Playmobil My Supermarket playset, showcasing the main building, figures, and accessories.



Image 2: The Playmobil My Supermarket set depicted in a vibrant outdoor scene, highlighting its integration into a larger play world.



Image 3: The retail packaging for the Playmobil My Supermarket, illustrating the set's components and compatibility with other Playmobil City Life products.



Image 4: A view of the Playmobil My Supermarket with key dimensions (length, width, height) marked for reference.

11. PRODUCT VIDEOS

Your browser does not support the video tag.

Video 1: Product Demonstration Video. This video provides a visual overview of the Playmobil My Supermarket set and its features.

Your browser does not support the video tag.

Video 2: A Closer Look. This video offers a detailed examination of the Playmobil My Supermarket, showcasing its various components and play possibilities.

© 2024 Playmobil. All rights reserved. Information subject to change without notice.