

BOB Gear U221947

BOB Gear Revolution Flex 3.0 Jogging Stroller User Manual

Model: U221947 | Brand: BOB Gear

INTRODUCTION

The BOB Gear Revolution Flex 3.0 Jogging Stroller is designed for active parents, offering versatility and comfort for both urban environments and outdoor adventures. Its robust design ensures a smooth ride, while thoughtful features enhance convenience and safety for your child.

KEY FEATURES

- **Versatile Jogging Stroller:** Offers comfort and adaptability for various terrains.
- **Adjustable Handlebar:** Provides a comfortable fit for parents of all heights.
- **Ample Storage:** Features 6 storage pockets, including a cell phone pocket at the handlebar, and an extra-large cargo basket.
- **2-Step Foldable Design:** Designed for easy folding and unfolding, facilitating convenient storage and transportation.
- **Smooth Ride:** Equipped with a suspension system and air-filled tires for an ultra-smooth ride over any terrain.
- **On and Off-Road Use:** Swivel-locking front wheel allows for easy maneuverability in urban settings and stability when jogging off-road.
- **Sun Protection:** Extra-large UPF 50+ canopy shields your child from the sun, with reflective accents for added safety.
- **Peek-a-Boo Window:** Magnetic "peek and chat" window allows you to check on your child without stopping, featuring a quiet magnetic closure.
- **Travel System Ready:** Compatible with most major brand car seats using a BOB infant car seat adapter (sold separately).

SETUP GUIDE

Follow these general steps to set up your BOB Gear Revolution Flex 3.0 Jogging Stroller. For detailed illustrations and specific instructions, please refer to the official user manual PDF linked in the Support section.

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all included components, such as the

stroller frame, wheels, and canopy, are present.

2. **Attach Wheels:** Securely attach the front and rear wheels according to the instructions. Ensure they click into place or are properly fastened.
3. **Unfold Stroller:** Release the folding latch and unfold the stroller frame until it locks into its open position. Confirm all locking mechanisms are engaged.
4. **Install Canopy:** Attach the UPF 50+ canopy to the stroller frame. Ensure it is securely fastened and can be adjusted smoothly.
5. **Adjust Handlebar:** Adjust the handlebar to a comfortable height for pushing.
6. **Safety Check:** Before first use, perform a thorough safety check. Ensure all parts are correctly assembled, wheels are inflated, and brakes are functional.



Image: The BOB Gear Revolution Flex 3.0 Jogging Stroller fully assembled, showcasing its robust design and three-wheel configuration.

OPERATING INSTRUCTIONS

Adjusting the Handlebar

The adjustable handlebar allows for comfortable pushing for users of varying heights. Locate the adjustment buttons or levers on either side of the handlebar. Press or release them to extend or retract the handle, then secure it in your desired position.

Adjustable Handlebar



For More Comfort and Control
on the Hiking Trail or Sidewalks



Image: Close-up of the adjustable handlebar mechanism, demonstrating its range of motion for ergonomic comfort.

Maneuvering and Locking the Front Wheel

The front wheel can swivel for easy maneuverability in crowded areas or lock for stability during jogging or on uneven terrain. Locate the swivel lock mechanism near the front wheel. Engage the lock for straight-line stability and disengage it for full swivel capability.



Image: A detailed diagram highlighting key features, including the 360-degree swivel-locking front wheel for versatile use.

Folding the Stroller

The stroller features a 2-step folding mechanism for compact storage and transport. Consult the official user manual for precise steps, which typically involve engaging a release lever and collapsing the frame. Ensure the stroller is fully collapsed and secured before lifting or storing.

Revolution Flex 3.0

Jogging Stroller



Image: The BOB Gear Revolution Flex 3.0 Stroller in its folded configuration, demonstrating its compact size for transport and storage.

Using the Canopy and Peek-a-Boo Window

The extra-large UPF 50+ canopy provides extensive sun protection. Extend or retract the canopy as needed. The magnetic "peek and chat" window allows you to discreetly check on your child. Simply lift the flap to view and communicate.

Peaceful Peeking

Keep an Eye on Little Ones
While On-The-Go



Image: A hand demonstrating the opening of the magnetic peek-a-boo window on the stroller's canopy, allowing for easy child monitoring.

MAINTENANCE AND CARE

Cleaning Instructions

To clean the fabric and components of your stroller, sponge the affected area with a solution of lukewarm water and mild soap. Rinse thoroughly with clean water to remove all soap residue and allow to air dry completely. **Do not use detergent**, as it may damage the fabric or components.

Tire Care

The stroller features air-filled tires for optimal performance. Regularly check tire pressure and inflate as needed to ensure a smooth ride and proper handling. A tire patch kit is recommended for unexpected punctures, especially during outdoor activities.

General Inspection

Periodically inspect all moving parts, locking mechanisms, and harness components for wear or damage. Ensure all

fasteners are tight. If any issues are found, contact customer support or refer to the detailed user manual for repair guidance.

Troubleshooting Common Issues

Problem	Possible Cause	Solution
Stroller pulls to one side	Uneven tire pressure; Front wheel not properly aligned or locked.	Check and adjust tire pressure. Ensure front wheel is correctly aligned and locked for straight-line travel.
Difficulty folding/unfolding	Folding mechanism not fully disengaged/engaged; Obstruction.	Ensure all latches are released/engaged. Check for any fabric or debris obstructing the mechanism. Refer to the manual for specific folding steps.
Squeaking wheels	Lack of lubrication; Dirt or debris in wheel bearings.	Clean wheels and axles. Apply a silicone-based lubricant to moving parts.

Product Specifications

Specification	Detail
Brand	BOB Gear
Model Number	U221947
Color	Graphite Black
Material	Aluminum (Frame), Polyester (Fabric), Pneumatic (Tires)
Item Weight	28.5 Pounds
Maximum Weight Recommendation	75 Pounds
Item Dimensions (L x W x H)	46"L x 25"W x 45"H
Folded Size	38" x 25" x 16"
Wheel Diameter	16 Inches (Rear), 12 Inches (Front)
Harness Type	5 Point (Adjustable, No-Rethread)
Seating Capacity	1
Included Components	Stroller Cover/Canopy
Age Range Description	Newborn to Toddler
Safety Standard	ASTM

Warranty and Support

Manufacturer's Warranty

The BOB Gear Revolution Flex 3.0 Jogging Stroller comes with a manufacturer's limited warranty:

- **Frame:** 5-year manufacturer limited warranty.
- **Components and Fabric:** 1-year manufacturer limited warranty.

Please retain your proof of purchase for warranty claims. For full terms and conditions, refer to the official warranty documentation provided with your product.

Additional Support

For further assistance, detailed instructions, or to download the complete user manual, please visit the official BOB Gear website or refer to the PDF document provided at the time of purchase.

Official User Manual (PDF): [Download Here](#)

PRODUCT VIDEOS

There are no official seller-provided product videos available for this item at this time.

© 2025 BOB Gear. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question