**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## GSParts 835RX, 850RX, 875RX, 885RX, 895RX

# GSParts Replacement Shaver Heads User Manual

For Philips Norelco Shaver Models: 835RX, 850RX, 875RX, 885RX, 895RX

## Introduction

Thank you for choosing GSParts Replacement Shaver Heads. These replacement heads are designed to restore the optimal shaving performance of your Philips Norelco shaver. For best results, please follow the instructions provided in this manual. This package includes three (3) replacement shaver heads.

## Compatibility

These GSParts replacement shaver heads are compatible with the following Philips Norelco shaver models:

- Philips Norelco 835RX
- Philips Norelco 850RX
- Philips Norelco 875RX
- Philips Norelco 885RX
- Philips Norelco 895RX

Please ensure your shaver model matches one of the listed models for proper fit and performance.

## Setup and Installation

Replacing your shaver heads is a simple process. For optimal performance, it is recommended to replace your shaver heads every 12 months, or sooner if you notice reduced shaving efficiency or discomfort.




Image: Three GSParts replacement shaver heads. These heads feature sharp, balanced cutting elements designed for a smooth shave.

1. **Turn Off and Unplug:** Ensure your Philips Norelco shaver is turned off and unplugged from any power source before beginning.
2. **Open the Shaver Head Unit:** Depending on your specific Norelco model, you will either press a release button or twist the retaining ring to open the shaver head unit. Refer to your original shaver manual if you are unsure.
3. **Remove the Retaining Plate:** Once the head unit is open, locate the retaining plate (often with a central screw or clips) that holds the cutters in place. Carefully remove this plate.
4. **Remove Old Cutters and Guards:** Lift out the old cutters and their corresponding guards. Dispose of them responsibly.
5. **Clean the Shaver:** Take this opportunity to clean any accumulated hair or debris from the shaver's internal components using a small brush or compressed air.
6. **Insert New Cutters and Guards:** Place the new GSParts cutters into their respective guards. Ensure they are seated correctly.
7. **Reattach the Retaining Plate:** Carefully place the retaining plate back over the new cutters and guards. Ensure it clicks or screws into place securely.
8. **Close the Shaver Head Unit:** Close the shaver head unit until it clicks firmly into position.

9. **Initial Run:** Turn on your shaver for a few seconds to ensure the new heads are rotating smoothly and quietly.

**Note:** It is important to handle the new cutters by their edges to avoid dulling them or causing injury.

## Operating Instructions

After installing the new GSParts shaver heads, your shaver is ready for use. For optimal shaving results:

- **Adaptation Period:** Allow a few weeks for your skin to adapt to the new shaver heads. During this period, you may experience slight irritation, which is normal.
- **Shaving Technique:** Use small, circular motions against the direction of hair growth. Apply gentle pressure; excessive pressure does not improve the shave and can cause irritation.
- **Dry or Wet Shave:** Follow the instructions for your specific Philips Norelco shaver model regarding dry or wet shaving.

## Maintenance

Regular cleaning and proper maintenance will extend the life of your GSParts shaver heads and ensure consistent performance.

1. **Daily Cleaning:** After each shave, open the shaver head unit and rinse the cutters and guards under warm running water. Shake off excess water and allow them to air dry completely before closing the unit.
2. **Deep Cleaning (Weekly/Bi-Weekly):** For a more thorough clean, you can remove the cutters and guards as described in the "Setup and Installation" section and rinse them individually. Ensure all hair clippings are removed.
3. **Lubrication (Optional):** Some Philips Norelco shavers benefit from occasional lubrication of the cutting elements. Refer to your original shaver manual for specific recommendations.
4. **Replacement Frequency:** For continued optimal performance, replace your GSParts shaver heads every 12 months.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Shaver not cutting smoothly or pulling hair. | • Heads are not properly seated.<br>• Heads are dirty.<br>• Heads are worn out (if recently replaced, allow adaptation period). | • Re-install heads, ensuring they click into place.<br>• Clean heads thoroughly as per maintenance instructions.<br>• Allow 2-3 weeks for skin to adapt to new heads. |
| Increased noise from shaver. | • Heads not properly seated.<br>• Internal components require cleaning. | • Check installation of heads.<br>• Perform a deep clean of the shaver head unit. |
| Skin irritation after shaving. | • New heads require adaptation.<br>• Incorrect shaving technique.<br>• Heads are dirty. | • Allow adaptation period.<br>• Use gentle, circular motions.<br>• Clean heads thoroughly. |

## Specifications

- **Product Type:** Replacement Shaver Heads / Blade Cutters
- **Quantity:** 3 per package
- **Compatibility:** Philips Norelco 835RX, 850RX, 875RX, 885RX, 895RX

- **Brand:** GSParts
- **Manufacturer:** GSParts-A888
- **GTIN (UPC):** 742089960614
- **ASIN:** B082B7JGKB

## Warranty and Support

Specific warranty information for GSParts products may vary. Please refer to the product packaging or the seller's information at the time of purchase for details regarding warranty coverage.
For product support or inquiries, please contact the seller or manufacturer directly through their official channels. You can often find contact information on the product packaging or the retailer's website where the item was purchased.

© 2023 GSParts. All rights reserved. Philips and Norelco are registered trademarks of Koninklijke Philips N.V.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B082B7JGKB**

More documents and user manuals: **https://manuals.plus/**