

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Klipsch](#) /

› [Klipsch The One Tabletop Wireless Stereo Instruction Manual](#)

Klipsch 123345678

Klipsch The One Tabletop Wireless Stereo Instruction Manual

Model: 123345678 | Brand: Klipsch

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Klipsch The One Tabletop Wireless Stereo. Please read this manual thoroughly before using the product to ensure proper function and longevity.

Package Contents

Upon unpacking, please verify that all items listed below are present and in good condition:

- Klipsch The One Tabletop Stereo Unit
- Power Cable
- User Manual (this document)



Figure 1.1: Klipsch The One Tabletop Wireless Stereo, showcasing its walnut top and grey fabric grille from an angled perspective.

2. IMPORTANT SAFETY INSTRUCTIONS

Always follow these basic safety precautions when using your Klipsch The One Tabletop Wireless Stereo:

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- Unplug this apparatus during lightning storms or when unused for long periods of time.

- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



Figure 2.1: Rear panel of the Klipsch The One, displaying the AC power input and various regulatory compliance markings.

3. SETUP

3.1 Placement

Place the Klipsch The One on a stable, flat surface. Ensure there is adequate ventilation around the unit. Avoid placing it in direct sunlight or near heat sources.



Figure 3.1: Front view of the Klipsch The One, highlighting its compact and elegant design suitable for various placements.

3.2 Power Connection

1. Connect the provided power cable to the AC IN port on the rear of the Klipsch The One.
2. Plug the other end of the power cable into a suitable wall outlet.
3. The unit will power on automatically or can be turned on using the power button on the top panel.

4. OPERATING INSTRUCTIONS

4.1 Controls Overview

The top panel of the Klipsch The One features intuitive controls for power, input selection, and volume adjustment.



Figure 4.1: Detailed view of the top control panel, showing the tactile metal switches and knobs for power, input, and volume.

- **Power Button:** Turns the unit on or off.
- **Input Selector:** Switches between available audio inputs (e.g., Bluetooth, Auxiliary).
- **Volume Knob:** Adjusts the master volume level.

- **Bluetooth Pairing Button:** Initiates Bluetooth pairing mode.

4.2 Bluetooth Pairing

To connect your device via Bluetooth:

1. Ensure the Klipsch The One is powered on.
2. Press and hold the Bluetooth pairing button on the top panel until the Bluetooth indicator light begins to flash.
3. On your smartphone, tablet, or laptop, navigate to the Bluetooth settings.
4. Select "Klipsch The One" from the list of available devices.
5. Once connected, the Bluetooth indicator light will become solid.

The Klipsch The One supports Bluetooth wireless technology, allowing seamless streaming from compatible devices within a range of approximately 10 meters (33 feet).

4.3 Audio Playback

After successfully pairing your device, you can begin playing audio. Control playback (play/pause, skip tracks) directly from your connected device. Adjust the volume using either the volume knob on the Klipsch The One or your device's volume controls.

5. MAINTENANCE AND CARE

Proper care will ensure the longevity and performance of your Klipsch The One:

- **Cleaning:** Use a soft, dry cloth to clean the exterior surfaces. Do not use liquid cleaners or aerosol sprays.
- **Ventilation:** Ensure that the ventilation openings are not blocked to prevent overheating.
- **Storage:** If storing the unit for an extended period, unplug it from the power outlet and store it in a cool, dry place.

6. TROUBLESHOOTING

This section addresses common issues you might encounter. If the problem persists, please contact customer support.

Problem	Possible Cause	Solution
No power	Power cable not connected; outlet not active.	Ensure power cable is securely connected to the unit and a working wall outlet.
No sound	Volume too low; incorrect input selected; device not paired.	Increase volume; select correct input; re-pair Bluetooth device.
Bluetooth device won't pair	Device too far; pairing mode not active; interference.	Ensure device is within 10 meters; activate pairing mode on Klipsch The One; try pairing again.
Distorted audio	Volume too high; poor source quality.	Reduce volume on both the unit and the source device; try a different audio source.

7. SPECIFICATIONS

Detailed technical specifications for the Klipsch The One Tabletop Wireless Stereo:

Model Name: The One II Bluetooth Ster

Speaker Type: Multi Room

Connectivity Technology: Bluetooth

Audio Output Mode: Stereo

Product Dimensions: 5.83"D x 12.68"W x 5.51"H

Item Weight: 8.98 pounds

Color: Walnut

Power Source: Battery Powered

Wireless Communication Technology: Bluetooth

Bluetooth Range: 10 Meters

Woofer Diameter: 4 Inches

Tweeter Diameter: 1.9 Centimeters

Control Method: Voice

Included Components: Tabletop Stereo

Indoor/Outdoor Usage: Indoor

UPC: 743878041408



Figure 7.1: Dimensions of the Klipsch The One, illustrating its compact size for easy placement.

8. WARRANTY INFORMATION

The Klipsch The One Tabletop Wireless Stereo comes with a Limited Warranty. For specific terms and conditions, please refer to the warranty card included in your product packaging or visit the official Klipsch website. Keep your proof of purchase for warranty claims.

9. CUSTOMER SUPPORT

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Klipsch customer

support:


Website: www.klipsch.com/support

Phone: Refer to the Klipsch website for regional contact numbers.

When contacting support, please have your product model number (123345678) and serial number ready. The serial number is located on the rear panel of the unit.

© 2024 Klipsch. All rights reserved.

Related Documents - 123345678

	<p>Klipsch Detroit Portable Bluetooth Speaker User Guide</p> <p>Explore the features and functionalities of the Klipsch Detroit portable Bluetooth speaker with this comprehensive user guide. Learn about app control, virtual remote, equalizer settings, channel control, battery charging, USB reverse charging, and Bluetooth pairing.</p>
	<p>Klipsch Austin Portable Bluetooth Speaker User Manual</p> <p>Comprehensive user guide for the Klipsch Austin portable Bluetooth speaker (10W RMS, Bluetooth 5.3). Learn about setup, features, the Klipsch Connect Plus app, True Wireless Stereo pairing, technical specifications, and safety instructions.</p>
	<p>Klipsch GIG XL Portable Bluetooth Party Speaker User Manual and Safety Guide</p> <p>Comprehensive guide for the Klipsch GIG XL portable Bluetooth party speaker, covering setup, operation, features like Bluetooth pairing, TWS, USB charging, and essential safety and compliance information.</p>
	<p>Klipsch The Three Plus Smart Speaker User Manual</p> <p>Comprehensive user manual for the Klipsch The Three Plus smart speaker, covering setup, controls, connections, safety, and maintenance.</p>
	<p>Klipsch T5 True Wireless Earphones: Setup, Usage, and Troubleshooting Guide</p> <p>A comprehensive guide to setting up, pairing, using, and troubleshooting your Klipsch T5 True Wireless earphones, including battery life, charging, ear tips, and advanced features.</p>
	<p>Klipsch Heresy IV 3-Way 12" Horn-Loaded Loudspeaker Owner's Manual and Specifications</p> <p>Official owner's manual and specification sheet for the Klipsch Heresy IV 3-way 12-inch horn-loaded loudspeaker. Features include high efficiency, matched pairs, book-matched wood veneer, and robust construction. Details placement, connections, safety, and technical specifications.</p>

