

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [MoJack](#) /

> [MoJack Heavy-Duty Stainless-Steel Lawn Mower Maintenance Deck Scraper Instruction Manual](#)

MoJack MoJack Deck Scraper

MoJack Heavy-Duty Stainless-Steel Lawn Mower Maintenance Deck Scraper Instruction Manual

1. PRODUCT OVERVIEW

The MoJack Heavy-Duty Stainless-Steel Lawn Mower Maintenance Deck Scraper is designed for efficient removal of accumulated grass, dirt, and debris from the underside of lawn mower decks. Its robust construction and ergonomic design facilitate thorough cleaning, contributing to improved mower performance and longevity. This tool is also suitable for various other scraping tasks.





Image 1: The MoJack Heavy-Duty Stainless-Steel Lawn Mower Maintenance Deck Scraper, featuring its stainless-steel blade and rubberized handle.

2. KEY FEATURES

- **Heavy-Duty Stainless Steel Blade:** Features a full-length curved stainless-steel scraping blade, measuring 2 inches wide by 10.25 inches long, designed for durability and effective scraping.
- **Ergonomic Profile:** The curved blade design provides additional clearance from the mower deck, helping to protect knuckles during use while ensuring maximum surface contact for efficient cleaning.
- **Flexible Non-Slip Handle:** Equipped with a sturdy plastic handle and a soft, molded rubber grip for a secure and comfortable hold during operation.
- **Versatile Application:** Ideal for cleaning lawn mower decks, and also effective for other tough scraping tasks such as removing tile, paint, silicone, or wall coverings.



Image 2: Visual representation of the scraper's key features, including heavy-duty steel, non-slip handle, versatility, molded rubber grip, and ergonomic design.

3. SETUP AND SAFETY

3.1 Safety Precautions

- Always ensure the lawn mower engine is turned off and the spark plug wire is disconnected before attempting to clean the deck.
- Wear appropriate personal protective equipment, including gloves and eye protection, to prevent injury from sharp edges or dislodged debris.
- Ensure the mower is stable and cannot tip over while you are working underneath it. Use a lift or secure blocking if necessary.
- Keep hands and feet clear of the mower blades at all times.

3.2 Tool Preparation

The MoJack Deck Scraper requires no assembly. It is ready for immediate use upon removal from its packaging.

4. OPERATING INSTRUCTIONS

4.1 Cleaning a Lawn Mower Deck

1. **Prepare the Mower:** Ensure the lawn mower is completely off, the spark plug wire is disconnected, and the mower is stable. If possible, elevate the mower using a suitable lift or tilt it safely to access the underside of the deck.
2. **Position the Scraper:** Hold the MoJack Deck Scraper firmly by its non-slip handle. Position the curved stainless-steel blade against the accumulated grass and debris on the mower deck.
3. **Scrape Debris:** Apply steady pressure and push or pull the scraper across the deck surface to dislodge and remove caked-on grass, dirt, and mud. The curved blade is designed to conform to the deck's contours for effective cleaning.
4. **Repeat as Necessary:** Continue scraping until the deck surface is clean. For stubborn areas, repeat the scraping motion or apply slightly more pressure.
5. **Dispose of Debris:** Collect and properly dispose of all removed debris.




Image 3: A person demonstrating the use of the MoJack Deck Scraper to remove debris from a lawn mower deck.

4.2 General Scraping Tasks

For other scraping applications (e.g., removing paint, tile adhesive), ensure the surface is appropriate for scraping and apply the same principles of firm grip and steady pressure. Always test on an inconspicuous area first if concerned about surface damage.

5. MAINTENANCE AND CARE

5.1 Cleaning the Scraper

After each use, clean the stainless-steel blade with water and a brush to remove any remaining debris. Dry the blade thoroughly to prevent water spots or mineral buildup.

5.2 Storage

Store the MoJack Deck Scraper in a clean, dry place away from direct sunlight and extreme temperatures. The handle features a hanging hole for convenient storage.



Image 4: The MoJack Deck Scraper stored in a toolbox, demonstrating proper storage practices.

6. SPECIFICATIONS

Attribute	Detail
Brand	MoJack
Model Number	MoJack Deck Scraper
Material	Stainless Steel (Blade), Plastic/Rubber (Handle)
Blade Dimensions	10.25 inches (Length) x 2 inches (Width)
Overall Length	Approximately 10.2 inches (based on package dimensions)
Item Weight	3.2 ounces
Power Source	Manual

Attribute	Detail
Operation Mode	Manual
UPC	859518001401

7. TROUBLESHOOTING

7.1 Ineffective Scraping

- **Issue:** Debris is not easily removed.
- **Solution:** Ensure the blade is making full contact with the surface. Apply consistent, firm pressure. For very dry or hardened debris, a slight wetting of the area might help soften it before scraping.

7.2 Blade Damage

- **Issue:** Blade appears dull or damaged.
- **Solution:** While the stainless-steel blade is durable, avoid using it on extremely hard or abrasive surfaces that could cause excessive wear or damage. Inspect the blade regularly for signs of wear.

8. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or customer support, please refer to the original product packaging or contact MoJack customer service directly through their official website or the retailer where the product was purchased. Please retain your proof of purchase for any warranty claims.