



Manuals.plus /

› **Sweety Fox** /

› Sweety Fox Multi-Position Baby Carrier with Hip Seat (Grey) Instruction Manual

Sweety Fox BACA-001-Gr

Sweety Fox Multi-Position Baby Carrier with Hip Seat (Grey) - Instruction Manual

INTRODUCTION

Thank you for choosing the Sweety Fox Multi-Position Baby Carrier with Hip Seat. This carrier is designed to provide comfort and security for your child while offering convenience for the parent. It is suitable for infants and toddlers from approximately 3 months to 3 years old, supporting various carrying positions as your child grows.



Image: A couple interacting with their baby comfortably seated in the Sweety Fox Multi-Position Baby Carrier. Please read this manual carefully before using the product to ensure proper assembly, usage, and maintenance. Keep these instructions for future reference.

SAFETY INFORMATION

- **Always ensure your child's airway is clear.** Regularly check that your child's face is visible and not pressed against your body or the fabric.
- **Ensure a snug fit.** The carrier should be tight enough to hold your child securely against your body.
- **Support your child's head and neck.** Especially for younger infants who lack head control.
- **Check all buckles and straps.** Before each use, ensure all buckles are securely fastened and straps are properly adjusted.
- **Maintain the "M" position.** Ensure your child's hips are spread, with knees higher than their bottom, forming an "M" shape. This supports healthy hip development.
- **Avoid hazardous activities.** Do not use the carrier during activities such as cooking, cleaning with chemicals, cycling, or any activity that could pose a fall risk.
- **Weight limits:** This carrier is designed for children weighing between 5 kg (11 lbs) and 19 kg (42 lbs). Do not exceed these limits.

- **Regularly inspect the carrier.** Check for any signs of wear, tear, or damage to fabric, stitching, buckles, or straps. Discontinue use if any damage is found.

COMPONENTS

The Sweety Fox Multi-Position Baby Carrier consists of the following main components:

- **Main Carrier Body:** The primary fabric structure that holds the child.
- **Hip Seat:** A padded, ergonomic seat for the child, detachable from the main carrier.
- **Waist Belt:** Adjustable belt that secures around the wearer's waist, supporting the hip seat and carrier.
- **Shoulder Straps:** Padded and adjustable straps for the wearer's shoulders.
- **Chest Strap (Back Strap):** Connects the two shoulder straps across the wearer's back for added security and weight distribution.
- **Adjustable Head Support:** Provides support for the child's head and neck, especially for younger infants.
- **Removable Sun Cover:** Offers protection from sun or light.
- **Breathable Window:** Integrated mesh panel for ventilation.
- **Side Pockets:** Convenient storage for small items.



Image: Overview of the Sweety Fox baby carrier highlighting key features like the removable sun cover, breathable window, foldable headrest, side pocket, and detachable design.

SETUP AND ADJUSTMENT

Proper adjustment is crucial for both your comfort and your child's safety.

1. Adjusting the Waist Belt:

Wrap the waist belt around your natural waist or slightly below, ensuring it is snug and comfortable. Fasten the buckle securely. The hip seat should rest firmly on your hip area.

2. Attaching the Main Carrier (if detached):

If using the full carrier, attach the main body to the hip seat using the designated zippers and buckles. Ensure all connections are secure.

3. Placing Your Child:

With the waist belt and carrier body (if used) securely in place, carefully position your child into the carrier. Ensure their legs are in the ergonomic "M" position, with knees higher than their bottom.

4. Adjusting Shoulder Straps:

Put on the shoulder straps. Pull the straps to tighten them until your child is snug against your body. The child should be close enough to kiss.

5. Securing the Chest Strap:

Reach behind your back and fasten the chest strap (which acts as a back strap in front carry). Adjust its height and tightness for even weight distribution and to prevent shoulder straps from slipping.

6. Head Support:

For infants or sleeping children, raise the adjustable head support to provide adequate neck and head stability.



Image: A baby in the carrier demonstrating the ideal "M" position for hip development, with breathable and padded mesh fabric visible.



GREATER HEADREST

TO TRULY SUPPORT
BABY'S HEAD

Image: Close-up view of the baby carrier's headrest, emphasizing its larger size for enhanced head support for the baby.

OPERATING: CARRYING POSITIONS

The Sweety Fox carrier offers multiple carrying options to adapt to your child's age and developmental stage. Always ensure your child is securely positioned and comfortable in any chosen method.

11
POSITIONS

MULTIFUNCTIONAL & EVOLVING FROM 3 TO 36 MONTHS



Waist Stool



Sling Backpack



Sling Backpack
and Waist Stool



Image: Visual guide illustrating 11 different carrying positions for the Sweet Fox baby carrier, including waist stool only, sling backpack, and combinations, suitable for children from 3 to 36 months.

1. Hip Seat Only (Waist Stool)

This mode is ideal for quick ups and downs, providing a comfortable seat for your child while reducing strain on your arms and back. It can be used for children who have good head and neck control.

- Detach the main carrier body from the hip seat.
- Secure the waist belt around your waist.
- Place your child on the hip seat, supporting them with one arm.

2. Front Carry (Facing In)

Suitable for infants from 3 months (or when they meet minimum weight/height requirements and have good head control). This position promotes bonding and allows your child to feel secure.

- Ensure the main carrier body is attached to the hip seat.
- Wear the carrier with the hip seat and waist belt secured.
- Place your child facing towards you, ensuring their bottom is deep in the seat and their legs are in the "M" position.
- Put on and adjust the shoulder straps and chest strap.

3. Front Carry (Facing Out)

Recommended for children who have strong head and neck control and are actively curious about their surroundings (typically 6+ months). Use for shorter periods to avoid overstimulation.

- Ensure the main carrier body is attached to the hip seat.
- Wear the carrier with the hip seat and waist belt secured.
- Place your child facing away from you, ensuring their bottom is deep in the seat and their legs are in the "M" position.
- Put on and adjust the shoulder straps and chest strap.

4. Back Carry

Ideal for older infants and toddlers who can sit unassisted (typically 6+ months). This position offers a different perspective for your child and can be more comfortable for the wearer during longer periods.

- Ensure the main carrier body is attached to the hip seat.
- Secure the waist belt around your waist.
- Carefully transfer your child to your back, ensuring they are seated properly in the carrier. This may require assistance until you are comfortable with the technique.
- Put on and adjust the shoulder straps. The chest strap will now be across your front.

MAINTENANCE AND CARE

To prolong the life of your Sweet Fox baby carrier and maintain hygiene:

- **Washing:** Hand wash with mild detergent in cold water. Do not bleach.
- **Drying:** Air dry only. Do not tumble dry. Avoid direct sunlight to prevent fading.
- **Spot Cleaning:** For minor spills, spot clean with a damp cloth and mild soap.
- **Storage:** Store the carrier in a clean, dry place away from direct sunlight when not in use.
- **Inspection:** Regularly check all buckles, straps, and stitching for wear or damage.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Discomfort for wearer (shoulder/back pain)	Straps too loose, weight not evenly distributed, waist belt too low.	Tighten shoulder straps, ensure waist belt is snug and high enough, adjust chest strap for better weight distribution.
Child seems uncomfortable or slumps	Carrier too loose, incorrect positioning (e.g., legs not in "M" position), head support not used for infants.	Ensure carrier is snug, reposition child to achieve "M" shape, use head support for infants.
Buckles are difficult to fasten/unfasten	Buckle mechanism is stiff or misaligned.	Ensure buckles are clean. If consistently difficult, contact customer support. Do not force.
Carrier feels too hot for child	Lack of ventilation, child overdressed.	Utilize the breathable window. Dress child in lighter clothing. Ensure adequate airflow.

SPECIFICATIONS

- **Model Number:** BACA-001-Gr
- **Brand:** Sweety Fox
- **Color:** Grey
- **Material:** Cotton, Breathable Mesh
- **Recommended Minimum Weight:** 5 Kilograms (11 lbs)
- **Recommended Maximum Weight:** 19 Kilograms (42 lbs)
- **Recommended Age Range:** Baby (approx. 3 months to 3 years)
- **Carrying Positions:** Front (facing in/out), Back, Hip Seat only
- **Package Dimensions:** 28.4 x 27.41 x 19 cm
- **Item Weight:** 948 grams
- **Manufacturer:** BMS International

WARRANTY AND SUPPORT

The Sweety Fox Multi-Position Baby Carrier comes with a **12-month manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, product support, or any questions regarding your carrier, please contact Sweety Fox customer service through your retailer or the official Sweety Fox website. Please have your model number (BACA-001-Gr) and proof of purchase ready.

For more information, visit: www.sweetyfox.com