

[manuals.plus](#) /

› [VIZIO](#) /

› [VIZIO D32f-G1 32-inch Full HD 1080p Smart TV User Manual](#)

## VIZIO D32f-G1

# VIZIO D32f-G1 32-inch Full HD 1080p Smart TV User Manual

Model: D32f-G1

## 1. INTRODUCTION

This manual provides instructions for the setup, operation, and maintenance of your VIZIO D32f-G1 32-inch Full HD 1080p Smart TV. Please read this manual thoroughly before using your TV and retain it for future reference.



Image: VIZIO D32f-G1 32-inch Smart TV on a media console.

## 2. WHAT'S IN THE Box

Verify that all items are included in your package:

- VIZIO D32f-G1 32-inch Full HD Smart TV
- Power Cable
- Remote Control
- TV Stand (2 pieces)
- Quick Start Guide (not included in this digital manual)

## 3. SETUP

### 3.1 Attaching the TV Stand

1. Carefully place the TV screen-down on a soft, clean surface to prevent damage.
2. Align each stand piece with the corresponding slots on the bottom of the TV.
3. Secure the stands using the provided screws. Ensure they are tightened firmly.



Image: VIZIO D32f-G1 TV with stand attached.

### 3.2 Connecting Power

Connect the power cable to the AC IN port on the back of the TV, then plug the other end into a wall outlet. The TV will automatically power on or enter standby mode.

### 3.3 Initial Setup Wizard

Upon first power-on, the TV will guide you through an initial setup process. Follow the on-screen prompts to:

- Select your language.
- Connect to a Wi-Fi network.
- Scan for channels (if using an antenna).

- Agree to terms and conditions.

## 4. OPERATING YOUR TV

### 4.1 Remote Control Overview

The included remote control provides access to all TV functions. Insert two AAA batteries (not included) into the remote.





Image: VIZIO Smart TV Remote Control.

- **Power Button:** Turns the TV on or off.
- **Input Button:** Cycles through available input sources (HDMI, Composite, etc.).
- **Volume +/-:** Adjusts the sound level.
- **Channel +/-:** Changes TV channels (for antenna/cable input).
- **Navigation Pad (Up/Down/Left/Right/OK):** Navigates menus and selects options.
- **App Shortcut Buttons:** Direct access to popular streaming services like Netflix, Prime Video, Hulu, etc.
- **WatchFree Button:** Launches VIZIO WatchFree.

## 4.2 Accessing SmartCast Home

Press the **Home** button on your remote to access the SmartCast Home screen, where you can find apps, inputs, and settings.




Image: VIZIO SmartCast Home Screen.


## 5. SMARTCAST FEATURES

VIZIO SmartCast provides instant access to a wide selection of streaming apps and content. Use the SmartCast Mobile app on your smartphone or the included remote to navigate.

### 5.1 Apple AirPlay 2 & Chromecast Built-in

Stream and share content directly from your Apple or Android devices to your VIZIO TV. This includes movies, shows, music, photos, and mirroring your device's screen.

# Use your voice to control your TV.



© 2019 VIZIO, Inc. All rights reserved. Apple and AirPlay 2 are trademarks of Apple Inc., registered in the U.S. and other countries. HomeKit is a trademark of Apple Inc. Google Home is a trademark of Google LLC. Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates. Screen images simulated. Devices sold separately.

**VIZIO**

Image: Streaming content via Apple AirPlay to the VIZIO TV.

## 5.2 VIZIO WatchFree

Access over 150 free streaming channels, including news, movies, sports, and more, without any subscriptions or logins. Press the dedicated **WatchFree** button on your remote.

## 6. VOICE CONTROL

Your VIZIO Smart TV supports voice control through popular assistants like Siri, Google Assistant, and Amazon Alexa. Connect your TV to your smart home ecosystem to use voice commands for power, app launching, and more.

# Stream and share directly to the big screen.



© 2019 VIZIO, Inc. All rights reserved. Apple and AirPlay 2 are trademarks of Apple Inc., registered in the U.S. and other countries. HomeKit is a trademark of Apple Inc. Google Home, Chromecast Built-in and other related marks and logos are trademarks of Google LLC. Screen images simulated. Devices sold separately.

**VIZIO**

Image: Voice control integration with smart home assistants.

## 7. CONNECTIVITY

The VIZIO D32f-G1 TV offers various ports for connecting external devices.



Image: Rear panel connectivity ports.

- **HDMI Ports:** Connect high-definition devices like Blu-ray players, game consoles, or cable boxes. One HDMI port supports Audio Return Channel (ARC).
- **Ethernet Port:** For a wired internet connection.
- **Composite Input:** For older devices using RCA cables (red, white, yellow).
- **Cable/Antenna Input:** Connect an antenna for over-the-air broadcasts or a cable TV connection.
- **USB 2.0 Port:** For connecting USB storage devices to view photos or play media files.

## 8. MAINTENANCE

### 8.1 Cleaning Your TV

- Always unplug the TV before cleaning.
- Use a soft, lint-free cloth to gently wipe the screen and cabinet.
- For stubborn marks, lightly dampen the cloth with water or a mild, non-abrasive screen cleaner. Do not spray cleaner directly onto the screen.
- Avoid using harsh chemicals, solvents, or abrasive materials.

### 8.2 General Care

- Do not block ventilation openings on the back of the TV.
- Keep the TV away from direct sunlight, heat sources, and excessive moisture.
- Protect the power cord from being walked on or pinched.

## 9. TROUBLESHOOTING

If you encounter issues with your VIZIO TV, refer to the following common solutions before contacting support.

| Problem                   | Solution  |
|---------------------------|---|
| No Power                  | Ensure the power cable is securely connected to both the TV and a working electrical outlet. Try a different outlet.          |
| No Picture / Black Screen | Verify the correct input source is selected. Check all cable connections (HDMI, Composite). Try restarting connected devices. |
| No Sound                  | Check the volume level and ensure the TV is not muted. Verify audio settings and external audio device connections.           |
| Remote Not Responding     | Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor.      |
| Network Connection Issues | Check your Wi-Fi password. Restart your router and modem. Try connecting via an Ethernet cable if available.                  |

## 10. SPECIFICATIONS

| Feature                         | Detail   |
|---------------------------------|--|
| Brand                           | VIZIO  |
| Model Number                    | D32f-G1  |
| Screen Size                     | 32 inches (31.50" Diag.)   |
| Display Technology              | LCD with Full Array LED Backlighting                                   |
| Resolution                      | 1080p Full HD  |
| Refresh Rate                    | 60 Hz  |
| Aspect Ratio                    | 16:9   |
| Smart Features                  | VIZIO SmartCast, Apple AirPlay 2, Chromecast Built-in, VIZIO WatchFree |
| Voice Control Support           | Siri, Google Assistant, Amazon Alexa                                   |
| Connectivity                    | HDMI, Ethernet, Composite, USB 2.0, Wi-Fi                              |
| Product Dimensions (with stand) | 28.66 x 7.83 x 18.98 inches  |
| Item Weight                     | 12.56 pounds   |
| Voltage                         | 127 Volts  |
| Wattage                         | 39.77 watts  |

## 11. WARRANTY AND SUPPORT

For detailed warranty information, product registration, and technical support, please visit the official VIZIO website or contact VIZIO customer service directly.

**Online Support:** [www.vizio.com/support](http://www.vizio.com/support)

Keep your purchase receipt and TV serial number handy when contacting support.

© 2024 VIZIO Inc. All rights reserved. Information in this manual is subject to change without notice.