

Inateck KB06001-W-UK

Inateck Foldable Compact Keyboard User Manual

Model: KB06001-W-UK

Brand: Inateck

1. INTRODUCTION

The Inateck Foldable Compact Keyboard is designed for portability and multi-device connectivity, making it an ideal companion for users on the go. Weighing only 185g, its compact and dual-fold design allows it to be easily carried in a pocket or bag, saving valuable desktop space.

This keyboard supports simultaneous connection to up to three devices across various operating systems including iPadOS, iOS, Android, and Windows, enabling seamless switching for enhanced productivity. It features a long battery life with quick charging via a Type-C cable, and multimedia shortcut keys for efficient workflow.



Figure 1: The Inateck Foldable Compact Keyboard in both its unfolded, ready-to-use state and its compact, folded state, demonstrating its portability.

2. SETUP

2.1 Charging the Keyboard

Before initial use, ensure the keyboard is fully charged. Connect the included USB-C cable to the charging port on the keyboard and the other end to a power source. The keyboard fully charges in approximately 2 hours. The battery status can be monitored via the indicator lights.



Figure 2: The keyboard connected via USB-C for charging, showing the battery indicator lights. Red indicates low battery, green indicates fully charged.

2.2 Bluetooth Pairing

The Inateck keyboard supports connection to three different devices. Follow these steps to pair your device:

1. Unfold the keyboard to power it on.
2. Press and hold **Fn + Q**, **Fn + W**, or **Fn + E** for approximately 3 seconds to enter pairing mode for Channel 1, 2, or 3 respectively. The corresponding indicator light will flash rapidly.
3. On your device (e.g., tablet, smartphone, laptop), go to Bluetooth settings and search for "Inateck KB06001" (or similar).
4. Select the keyboard to connect. The indicator light on the keyboard will stop flashing and remain solid once successfully paired.



Figure 3: Illustration of pressing Fn+Q, Fn+W, or Fn+E to switch between three different paired devices.

3. OPERATING INSTRUCTIONS

3.1 Switching Between Devices

Once paired with multiple devices, you can easily switch between them by short-pressing **Fn + Q**, **Fn + W**, or **Fn + E**. The keyboard will automatically connect to the selected device.

Video 1: Demonstrates the seamless switching between multiple devices using the Inateck Bluetooth Keyboard KB06001.

3.2 Hotkeys and Multimedia Functions

The keyboard includes various hotkeys and multimedia shortcut keys to enhance productivity. These functions are typically accessed by pressing the **Fn** key in combination with the corresponding function key (F1-F12) or other designated keys.

- **Number Inputs:** Simply press the number keys (1-0) to quickly input the corresponding numbers.
- **Function Keys:** Press **Fn** + function key (F1-F12) to perform the respective function (e.g., volume adjustment, screen brightness control).
- **Symbol Input:** Press **Shift** + the symbol key (e.g., !, @, #, etc.).




Figure 4: Detailed layout of the keyboard highlighting the shortcut key instructions for various functions.

3.3 Compatibility and Shortcut Functionality

The keyboard is compatible with a wide range of operating systems. The functionality of certain shortcuts may vary slightly depending on the OS. Refer to the table below for a quick overview:

Systems	Shortcuts								
	Brightness-	Brightness+	Search	Screenshot	Input Method	Play/Pause	Volume-	Volume+	Lock Scree
iPad OS	✓	✓	✓	✓	✓	✓	✓	✓	✓
Windows	✓	✓	✓	✓	✓	✓	✓	✓	✓
Mac OS	✓	✓	✓	✓	✓	✓	✓	✓	✓
Fire OS	✓	✓	✗	✓	✗	✓	✓	✓	✓
Android	✓	✓	✓	✓	✓	✓	✓	✓	✓
iOS	✓	✓	✓	✓	✓	✓	✓	✓	✓

Table 1: Shortcut key compatibility across different operating systems. ✓ indicates full functionality, ✗ indicates limited or no functionality.

4. MAINTENANCE

To ensure the longevity and optimal performance of your Inateck Foldable Compact Keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry, lint-free cloth to wipe the surface of the keyboard. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid excessive moisture.
- **Storage:** When not in use, fold the keyboard to protect the keys and internal components. Store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Liquids:** Do not expose the keyboard to liquids. In case of accidental spills, immediately power off the keyboard and allow it to dry completely before attempting to use it again.
- **Handle with Care:** While designed for portability, avoid dropping the keyboard or subjecting it to strong impacts, as this may damage internal components or the folding mechanism.

Portable and Lightweight

Grab and go, ready to use anytime



Figure 5: The keyboard in its folded state, illustrating its durable design which allows for easy cleaning to maintain its appearance.

5. TROUBLESHOOTING

If you encounter issues with your Inateck Foldable Compact Keyboard, please refer to the following common troubleshooting steps:

- **Keyboard not connecting via Bluetooth:**

- Ensure the keyboard is charged.
 - Make sure the keyboard is unfolded and powered on.
 - Verify Bluetooth is enabled on your device.
 - Ensure the keyboard is in pairing mode (indicator light flashing). If not, long-press Fn + Q/W/E.
 - Forget the device from your device's Bluetooth settings and attempt to re-pair.
 - Try connecting to a different device to rule out device-specific issues.
- **Keys not responding or typing incorrectly:**
 - Check the battery level. A low battery can affect performance.
 - Ensure the keyboard is properly connected to your device.
 - Restart both the keyboard (fold and unfold) and your connected device.
 - Confirm the correct input language and keyboard layout are selected on your device.
 - **Keyboard feels flimsy or doesn't stay flat:**
 - The keyboard is designed to be lightweight and foldable. It requires a flat surface for stable use. It does not have a locking mechanism when unfolded.
 - **Battery life is shorter than expected:**
 - Ensure the keyboard enters sleep mode after 10 minutes of inactivity.
 - Fully charge the keyboard before each use.
 - Environmental factors (e.g., extreme temperatures) can affect battery performance.

6. SPECIFICATIONS

Feature	Detail
Model Number	KB06001-W-UK
Product Dimensions	10.64 x 3.98 x 0.47 inches
Item Weight	6.6 ounces (185g)
Connectivity Technology	Bluetooth
Compatible Devices	Laptop, PC, Tablet, Smartphone, iPadOS/iOS/Android/Windows
Keyboard Layout	QWERTY
Number of Keys	66
Power Source	Battery Powered (1 Lithium Ion battery included)
Charging Time	Approx. 2-3 hours
Standby Time	Over 100 days
Work Time	Up to half a month (typical use)
Special Feature	Foldable/Portable, 3-Device Connectivity

7. WARRANTY AND SUPPORT

Inateck products come with a standard manufacturer's warranty. For detailed warranty information, product registration, or technical support, please visit the official Inateck website or contact their customer service. Keep your purchase receipt for warranty claims.

For further assistance, you may refer to the Inateck Store on Amazon:[Inateck Amazon Store](#).

© 2025 Inateck. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question