Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Anten B082G4RWX1

Anten LED Smart Floor Lamp User Manual

Model: B082G4RWX1

Brand: Anten

1. Introduction

Thank you for choosing the Anten LED Smart Floor Lamp. This intelligent floor lamp offers versatile lighting options, including dimmable RGB and adjustable white light (warm to cool), controlled via Wi-Fi, voice commands, or touch. It is compatible with Amazon Alexa and Google Home, providing a convenient and customizable lighting experience for your living space.

Please read this manual carefully before use to ensure proper installation, operation, and maintenance of your new floor lamp.

2. Safety Information

- Ensure the power supply voltage matches the lamp's requirements (220V).
- Do not disassemble or modify the lamp. Refer all servicing to qualified personnel.
- Keep the lamp away from water and high humidity environments. This product is not water-resistant.
- Place the lamp on a stable, flat surface to prevent tipping. The base weighs 2.2 kg for enhanced stability.
- Unplug the lamp from the power outlet before cleaning or performing any maintenance.
- Avoid direct eye exposure to the LED light for extended periods.

3. Package Contents

Verify that all components are present in the package:

- Anten LED Smart Floor Lamp (with PMMA housing)
- Power Cable

- User Manual

4. Setup and Assembly

Follow these steps to assemble and set up your Anten LED Smart Floor Lamp:

1. **Unpack Components:** Carefully remove all parts from the packaging and place them on a clean, flat surface.
2. **Assemble the Lamp Pole:** Connect the sections of the lamp pole by screwing them clockwise until secure. Ensure all connections are tight.
3. **Attach the Base:** Securely attach the lamp pole to the heavy base.
4. **Position the Lamp:** Place the assembled floor lamp in your desired location, ensuring it is stable and not easily knocked over.
5. **Connect to Power:** Plug the power cable into the lamp and then into a standard 220V electrical outlet.

Initial Power-On

Once connected to power, the lamp should turn on. If not, check the power connection. The lamp is now ready for basic operation or smart control setup.

5. Operating Instructions

The Anten LED Smart Floor Lamp offers multiple control methods for your convenience.

5.1. Smart Life App Control

The Smart Life app allows comprehensive control over your lamp's features. Ensure your Wi-Fi network is 2.4 GHz, as 5.0 GHz networks are not supported.

1. **Download the App:** Download the "Smart Life" app from your smartphone's app store (iOS or Android).
2. **Register/Log In:** Create an account or log in to your existing Smart Life account.
3. **Add Device:** In the app, tap the "+" icon to add a new device. Select "Lighting" then "Light Source (Wi-Fi)" or similar.
4. **Connect to Wi-Fi:** Follow the in-app instructions to connect the lamp to your 2.4 GHz Wi-Fi network. This usually involves putting the lamp into pairing mode (often by cycling power on/off a few times).
5. **Control Features:** Once connected, you can access various controls:
    - **Brightness Adjustment:** Adjust the light intensity from 5% to 100%.
    - **Color Temperature:** Change the white light from warm to cool (2700K-6500K).
    - **RGB Colors:** Select from 16 million colors to create your desired ambiance.
    - **Scene Options:** Choose from pre-set lighting scenes or create custom ones.
    - **Music Mode:** Synchronize the light with music.
    - **Timer Function:** Set schedules for the lamp to turn on/off automatically.



Image: Overview of the four control modes available through the Smart Life app, including color temperature, multicolor, scene options, and music mode.




Image: Demonstrates the lamp's adjustable brightness and color temperature settings, showing light from 6000K to 3000K and dimming from 100% to 5%.



Image: The floor lamp displaying various RGB colors, illustrating the wide range of multicolor lighting options available.

5.2. Voice Control (Amazon Alexa / Google Home)

Integrate your Anten LED Smart Floor Lamp with Amazon Alexa or Google Home for convenient voice commands.

1. **Enable Skill:** In your Alexa or Google Home app, search for and enable the "Smart Life" skill/action.
2. **Link Account:** Link your Smart Life account to your Alexa or Google Home account.
3. **Discover Devices:** Ask Alexa or Google Home to discover new devices. Your floor lamp should appear.
4. **Voice Commands:** Use commands such as:
    - "Alexa/Hey Google, turn on the floor lamp."
    - "Alexa/Hey Google, set the floor lamp to 50% brightness."
    - "Alexa/Hey Google, change the floor lamp to blue."
    - "Alexa/Hey Google, dim the floor lamp."



Image: An Amazon Echo device demonstrating voice control, with speech bubbles showing commands like "Hi Alexa, turn on the floor lamp" and "Hi Alexa, set floor lamp brightness to 50%".

5.3. Touch Control

The lamp may feature a touch-sensitive area for basic control. Refer to the lamp's physical design for the exact location of the touch control. Typically, a single touch can turn the lamp on/off, and a long press might adjust brightness or cycle through modes.

5.4. USB Charging Port

The lamp includes a practical USB charging port (5V/1A) for charging small electronic devices.

- Locate the USB port on the lamp.
- Connect your device's USB charging cable to the lamp's USB port.
- Ensure the lamp is powered on for the USB port to function.



Image: The floor lamp with a 5V/1A USB port, shown charging a mobile phone, highlighting its practical charging capability.

5.5. Adjustable Lamp Head

The LED floor lamp head can be adjusted up and down by 30 degrees, allowing you to direct the light as needed for reading or ambient illumination.

Your browser does not support the video tag.

Video: Demonstrates the Anten LED Smart Floor Lamp's features, including Smart Life app control, voice control via Alexa, up/down lighting design, 5%-100% brightness adjustment, and RGB+CCT 16-million color options.

6. Maintenance

To ensure the longevity and optimal performance of your floor lamp, follow these maintenance guidelines:

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the lamp's surface. Do not use abrasive cleaners, solvents, or harsh chemicals, as they may damage the finish.

- **Dust Removal:** Regularly dust the lamp to prevent accumulation, which can affect light output and aesthetics.
- **Storage:** If storing the lamp for an extended period, unplug it and store it in a cool, dry place.

7. Troubleshooting

If you encounter issues with your Anten LED Smart Floor Lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	No power, loose connection, faulty outlet.	Check if the power cable is securely plugged into both the lamp and the wall outlet. Test the outlet with another device.
Cannot connect to Wi-Fi.	Incorrect Wi-Fi band, wrong password, lamp not in pairing mode.	Ensure your router is broadcasting a 2.4 GHz Wi-Fi signal. Verify the Wi-Fi password. Follow app instructions to put the lamp into pairing mode (usually by cycling power).
Voice control not working.	Smart Life skill not enabled/linked, device not discovered, incorrect commands.	Check if the Smart Life skill is enabled and linked in your Alexa/Google Home app. Redo device discovery. Use the correct voice commands as listed in section 5.2.
Light flickers or changes unexpectedly.	Unstable power, Wi-Fi interference, software glitch.	Ensure stable power supply. Restart the lamp by unplugging and replugging. Check for app updates.
USB charging port not working.	Lamp not powered on, faulty cable, device incompatibility.	Ensure the lamp is turned on. Try a different USB cable or device.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Feature	Specification
Model	B082G4RWX1
Brand	Anten
Dimensions (L x W x H)	25 x 25 x 168 cm
Weight	4.4 kg
Power (Wattage)	25 Watts
Voltage	220 Volts
Light Source Type	LED (63 bulbs)
Color Temperature	Adjustable (Warm to Cool White)
Color Options	RGB (Multicolor)

Feature	Specification
Brightness	Dimmable (5% - 100%)
Control Methods	App (Smart Life), Voice (Alexa, Google Home), Touch
Connectivity	Wi-Fi (2.4 GHz only)
USB Charging Port	5V / 1A
Lamp Head Adjustment	30° (Up/Down)
Base Material	Stainless Steel
Shade Material	PMMA
Material	Acrylic
Usage Environment	Indoor Use Only
Water Resistance	Not Water Resistant
Manufacturer	Damay

9. Warranty and Support

For warranty information, please refer to the documentation included with your product packaging or visit the official Anten website. Keep your purchase receipt as proof of purchase.

If you require technical assistance or have any questions not covered in this manual, please contact Anten customer support through their official website or the contact information provided on your product packaging.

© 2026 Anten. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B082G4RWX1

More documents and user manuals: **https://manuals.plus/**