

## ForeverPRO 00745855

# ForeverPRO 00745855 Appliance Tube: Installation and Maintenance Guide

## 1. INTRODUCTION

---

This manual provides essential information for the proper installation, maintenance, and troubleshooting of the ForeverPRO 00745855 Appliance Tube. This component is designed as a replacement part for various appliances, ensuring continued functionality.

The ForeverPRO 00745855 tube replaces original part numbers 3279215, PS8737035, and 745855. It is crucial to verify compatibility with your specific appliance model before proceeding with installation.

## 2. SAFETY INFORMATION

---

Always prioritize safety when working with appliances. Failure to follow these safety guidelines may result in personal injury or damage to the appliance.

- **Disconnect Power:** Before attempting any installation or maintenance, always disconnect the appliance from its power source (unplug or turn off the circuit breaker).
- **Professional Installation:** If you are not comfortable performing appliance repairs, it is recommended to seek assistance from a qualified technician.
- **Wear Protective Gear:** Use appropriate personal protective equipment, such as gloves and eye protection, to prevent injury.
- **Handle with Care:** Appliance parts can have sharp edges or delicate components. Handle the tube and surrounding parts carefully.
- **Proper Tools:** Use only the correct tools for the job to avoid damaging the part or the appliance.

## 3. COMPATIBILITY

---

The ForeverPRO 00745855 Appliance Tube is compatible with a range of appliances from various manufacturers. It is designed to replace Bosch part number 11018097 and other equivalent tubes.

**Known Compatible Brands:**

- Bosch
- Thermador
- Gaggenau

*Note:* This is not an OEM Bosch product. Any use of manufacturer brand names or model designations is for demonstrating and identifying compatibility only. Always cross-reference the part number with your appliance's specific model number to ensure a correct fit.

## 4. INSTALLATION INSTRUCTIONS

---

The following are general steps for replacing an appliance tube. Specific procedures may vary depending on your appliance model. Refer to your appliance's service manual for detailed instructions.

1. **Prepare Appliance:** Ensure the appliance is completely disconnected from its power source. Move the appliance to an area with adequate space and lighting if necessary.
2. **Access the Tube:** Carefully open or disassemble the necessary panels of your appliance to gain access to the tube that needs replacement. This may involve removing screws, clips, or other fasteners.
3. **Remove Old Tube:** Disconnect any hoses, clamps, or fittings attached to the old tube. Note their orientation and connection points for reassembly. Carefully remove the old tube from its position.
4. **Install New Tube:** Position the ForeverPRO 00745855 tube in the same manner as the old one. Reconnect all hoses, clamps, and fittings securely. Ensure all connections are tight to prevent leaks or disconnections during operation.
5. **Reassemble Appliance:** Reattach any panels or components that were removed during disassembly. Ensure all fasteners are tightened appropriately.
6. **Test Appliance:** Once reassembled, reconnect the appliance to its power source. Perform a test run to ensure the new tube functions correctly and there are no leaks or unusual noises.

## 5. OPERATING INSTRUCTIONS

---

The ForeverPRO 00745855 is a passive component within an appliance system. As such, it does not have specific operating instructions. Its function is to facilitate the flow of liquids or gases as part of the appliance's overall operation. Proper operation is ensured through correct installation and the normal functioning of the appliance itself.

## 6. MAINTENANCE

---

The ForeverPRO 00745855 Appliance Tube is designed for durability and typically requires minimal direct maintenance. However, general appliance care can extend the life of all components, including the tube.

- **Regular Cleaning:** Follow your appliance's manufacturer guidelines for regular cleaning to prevent buildup that could affect the tube or its connections.
- **Inspect Connections:** Periodically inspect the connections to the tube for any signs of wear, cracks, or leaks. Address any issues promptly.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners or harsh chemicals near the tube, as these can degrade the material over time.

## 7. TROUBLESHOOTING

---

If your appliance is experiencing issues after tube replacement, or if you suspect the tube is faulty,

consider the following:

- **Leaks:** If you observe water or fluid leaks, immediately disconnect power. Check all connections to the tube to ensure they are tight and properly sealed. Inspect the tube itself for any visible cracks or damage.
- **Restricted Flow:** If the appliance is not performing as expected (e.g., slow water fill, poor drainage), the tube might be kinked, clogged, or improperly installed. Disconnect power and inspect the tube's path and interior for obstructions.
- **Unusual Noises:** While less common for a tube, if new noises occur after installation, ensure the tube is not vibrating against other components or that all parts are securely fastened.
- **Appliance Error Codes:** If your appliance displays an error code, consult your appliance's user manual or service guide. The error code may indicate a problem related to the tube or its associated systems.

If troubleshooting steps do not resolve the issue, contact a qualified appliance technician.

## 8. SPECIFICATIONS

---

- **Part Number:** 00745855
- **Replaces Part Numbers:** 3279215, PS8737035, 745855
- **Compatible with Bosch Part:** 11018097
- **Included Components:** 1x Tube
- **Quality:** PRO Grade Premium, meets or exceeds OEM specifications.

## 9. WARRANTY AND SUPPORT

---

For information regarding the warranty of your ForeverPRO 00745855 Appliance Tube, please refer to the documentation provided at the time of purchase or contact ForeverPRO customer support directly. Keep your proof of purchase for warranty claims.

For technical assistance or further inquiries, please visit the official ForeverPRO website or contact their customer service department.