

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Shark](#) /
- › [Shark Rotator ZU632 Powered Lift-Away Upright Vacuum User Manual](#)

## Shark ZU632

# Shark Rotator ZU632 Powered Lift-Away Upright Vacuum User Manual

Model: ZU632

## INTRODUCTION

Thank you for choosing the Shark Rotator ZU632 Powered Lift-Away Upright Vacuum. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new vacuum cleaner. The ZU632 model features a self-cleaning brushroll, Powered Lift-Away functionality, and Anti-Allergen Complete Seal Technology with a HEPA filter for thorough cleaning.

## IMPORTANT SAFETY INSTRUCTIONS

When using your vacuum cleaner, basic safety precautions should always be observed. Read all instructions before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always unplug the vacuum cleaner from the electrical outlet before cleaning or servicing.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or vacuum cleaner with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use without dust cup and/or filters in place.
- Turn off all controls before unplugging.

## SETUP

---

Your Shark Rotator ZU632 vacuum comes with several components that require simple assembly. Ensure all parts are present before beginning.

1. Insert the wand into the nozzle.
2. Insert the handle into the wand.
3. Attach the hose to the back of the vacuum pod.
4. Secure the included accessories (Pet Crevice Tool, Pet Multi-Tool) onto the onboard storage posts.





Figure 1: Fully assembled Shark Rotator ZU632 vacuum cleaner.

## OPERATING THE VACUUM

---

The Shark Rotator ZU632 offers versatile cleaning modes and features for different surfaces and tasks.

### Fingertip Controls

Easily switch between cleaning modes using the fingertip controls located on the handle:

- **Hard Floor Setting:** Ideal for bare floors and delicate area rugs. The brushroll will not spin in this mode.
- **Carpet Setting:** Engages the brushroll for deep cleaning carpets and rugs.

### Powered Lift-Away Mode

Detach the main pod from the nozzle to clean hard-to-reach areas with motorized power. This mode is perfect for cleaning under furniture, stairs, and other elevated surfaces.



# POWERED LIFT-AWAY<sup>®</sup>

Lift away the pod for motorized cleaning under furniture or powerful above-floor cleaning.

Figure 2: Using the Powered Lift-Away mode to clean under furniture.



Figure 3: Cleaning stairs effectively with the Powered Lift-Away pod.



Figure 4: Extending reach for high-area cleaning using the wand.

### **LED Headlights**

The vacuum nozzle is equipped with powerful LED headlights that illuminate hidden debris, dust, and pet hair on your floors, ensuring a thorough clean.

# LED LIGHTS

Reveal hidden debris.



Figure 5: LED headlights highlight debris for improved visibility during cleaning.

## Suction Control

The vacuum features adjustable suction control, allowing you to reduce suction for cleaning delicate fabrics or thick, high-pile carpets where full suction might be too strong.

## MAINTENANCE

---

Regular maintenance ensures optimal performance and longevity of your Shark Rotator ZU632 vacuum.

### Emptying the Dust Cup

The large-capacity dust cup minimizes interruptions during cleaning. Empty the dust cup when debris reaches the MAX FILL line.

1. Press the dust cup release latch and lift the dust cup off the vacuum pod.
2. Hold the dust cup over a trash bin and press the bottom release latch to open the bottom flap.
3. Close the bottom flap until it clicks securely.

4. For deeper cleaning, you can also open the top of the dust cup by pressing the top release latch.



Figure 6: The large capacity dust cup for extended cleaning sessions.

### Cleaning Filters

Your vacuum is equipped with washable foam, felt, and HEPA filters. Rinse filters with cold water only. Allow all filters to air-dry completely for at least 24 hours before reinstalling them to prevent liquid from being drawn into electric parts.

- **Pre-Motor Filters (Foam & Felt):** Located above the dust cup. Rinse every 3 months.
- **Post-Motor HEPA Filter:** Located at the bottom of the vacuum. Rinse once a year.

### Self-Cleaning Brushroll

The self-cleaning brushroll actively removes long hair and pet hair as you vacuum, preventing hair wrap and maintaining consistent cleaning performance.



Figure 7: The self-cleaning brushroll effectively removes hair without tangling.

### **Anti-Allergen Complete Seal Technology**

This technology, combined with a HEPA filter, traps 99.9% of dust and allergens inside the vacuum, keeping them out of the air you breathe.

# SELF-CLEANING BRUSHROLL



PET HAIR • LONG HAIR



Figure 8: The Anti-Allergen Complete Seal ensures dust and allergens are contained.

## TROUBLESHOOTING

If you encounter any issues with your Shark Rotator ZU632, refer to the following common troubleshooting tips:

- **Vacuum not picking up debris:** Check for blockages in the hose, nozzle, or filters. Ensure the dust cup is not full and filters are clean and dry.
- **Brushroll not spinning:** Ensure the vacuum is in Carpet mode. Check for blockages in the brushroll area.
- **Vacuum tipping over in Lift-Away mode:** Ensure the main pod is securely detached and the nozzle is stable on the floor.
- **Loss of suction:** Check and clean all filters. Empty the dust cup. Inspect the hose and connections for any leaks or blockages.

## PRODUCT SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Brand	Shark
Model Name	Rotator ZU632 Powered Lift-Away with Self-Cleaning Brushroll
Item Model Number	ZU632
Color	Blue
Form Factor	Upright
Capacity	2.8 Quarts
Wattage	700 watts
Hose Length	6 Feet
Product Dimensions	15.5"L x 12"W x 46.2"H
Item Weight	16.2 pounds
Noise Level	80 Decibels
Filter Type	Washable HEPA + Foam and Felt Filters
Included Components	Crevice Tool, Pet Multi-Tool
Recommended Uses	Carpet, Hard Floor
Special Feature	Pet vacuum, Upright vacuum cleaner, Upright vacuums

## OFFICIAL PRODUCT VIDEOS

---

Watch these videos for demonstrations of the Shark Rotator ZU632's features and cleaning capabilities.

### Honest Review of Shark Powered Lift-Away Vacuum

Your browser does not support the video tag.

Video 1: A detailed review showcasing the Shark Powered Lift-Away vacuum's features and performance.

### In-depth Review of All the Different Features and Demos

Your browser does not support the video tag.

Video 2: An extensive demonstration of the vacuum's various features and how to use them.

### Heavy Duty Vacuum that Gets the Job Done Right!

Your browser does not support the video tag.

Video 3: See the Shark Rotator ZU632 in action, demonstrating its powerful cleaning performance.

## WARRANTY & SUPPORT

---

For warranty information and customer support, please refer to the documentation included with your product or visit the official Shark website. Keep your purchase receipt as proof of purchase.

---

