

[Manuals.plus](#) /

› [Devoko](#) /

› Devoko Zero Gravity Recliner Chair Instruction Manual

Devoko Zero Gravity

Devoko Zero Gravity Recliner Chair Instruction Manual

1. INTRODUCTION

Thank you for choosing the Devoko Zero Gravity Recliner Chair. This manual provides essential information for the safe and effective use, setup, operation, and maintenance of your new chair. Designed for ultimate relaxation, this oversized folding lounge chair is suitable for various outdoor settings such as poolside, patios, yards, and camping. The chair features a robust steel frame and breathable fabric, engineered to provide a stress-free reclining experience by cradling your spine in a zero-gravity position. Its foldable design ensures easy storage and portability.



Image: Two Devoko Zero Gravity Recliner Chairs positioned next to a swimming pool, ready for use.

2. SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum weight capacity of 420 pounds (approximately 190 kg). Overloading can cause damage to the chair and potential injury.
- **Stable Surface:** Always place the chair on a flat, stable, and level surface to prevent tipping.
- **Children and Pets:** Keep children and pets away from the chair during setup and adjustment to prevent pinching or other injuries.
- **Moving Parts:** Be cautious of moving parts when folding or unfolding the chair to avoid pinching fingers or hands.
- **Inspection:** Before each use, inspect the chair for any signs of damage, loose parts, or wear. Do not use if damaged.

- **Outdoor Use:** While designed for outdoor use, prolonged exposure to extreme weather conditions (heavy rain, strong winds, intense sun) can reduce the chair's lifespan. Consider storing indoors or covering when not in use.

3. PACKAGE CONTENTS

Your Devoko Zero Gravity Recliner Chair comes fully assembled and folded. The package includes:

- 1 x Devoko Zero Gravity Recliner Chair (Light Black)
- 1 x Adjustable Headrest Pillow

4. SETUP

The Devoko Zero Gravity Recliner Chair requires no assembly. Follow these simple steps to set up your chair:

1. **Unpack:** Carefully remove the chair from its packaging.
2. **Unfold:** Gently pull the chair's frame apart until it fully extends into the upright seating position. Ensure all legs are firmly on the ground.
3. **Position Headrest:** Adjust the removable headrest pillow to your desired height for optimal neck and head support.

Your chair is now ready for use.

5. OPERATING INSTRUCTIONS

The Devoko Zero Gravity Recliner Chair offers multiple reclining positions for personalized comfort. Follow these steps to adjust and lock your desired position:

1. **Sit Down:** Sit comfortably in the chair with your back against the backrest.
2. **Recline:** Gently push back with your body weight while lifting your legs. The chair will smoothly recline to your desired angle. The reclining level can be adjusted freely from 0° (upright) to 168° (fully reclined).
3. **Lock Position:** Once you find a comfortable position, locate the locking levers on both armrests. Push the levers downwards to engage the locking mechanism and secure the chair in place.
4. **Return to Upright:** To return to an upright position, disengage the locking levers by pulling them upwards. Lean forward, and the chair will return to its original seating mode.

Free Control Chair Back

420 lbs Weight Capacity Patio Lounge Chair



Seating mode



Leisure mode



Lying mode



Image: Visual representation of the chair's adjustable reclining positions (seating, leisure, lying) and the locking mechanism on the armrest.

6. MAINTENANCE

Proper care and maintenance will extend the life of your Devoko Zero Gravity Recliner Chair:

- **Cleaning:** Clean the fabric with a mild soap and water solution. Use a soft brush or cloth to gently scrub any soiled areas. Rinse thoroughly with clean water and allow to air dry completely before folding or storing.
- **Frame Care:** Wipe the steel frame with a damp cloth. For stubborn dirt, use a mild detergent. Dry immediately to prevent rust.
- **Storage:** When not in use for extended periods, especially during inclement weather, fold the chair and store it in a dry, protected area. A storage cover is recommended to protect against dust and environmental elements.
- **Hardware:** Periodically check all screws and bolts to ensure they are tight. Tighten if necessary.

7. TROUBLESHOOTING

If you encounter any issues with your Devoko Zero Gravity Recliner Chair, please refer to the following common solutions:

Problem	Possible Cause	Solution
Chair does not recline smoothly.	Locking levers engaged; debris in mechanism; worn bungee cords.	Ensure locking levers are disengaged. Check for obstructions and clean if necessary. Inspect bungee cords for wear and consider replacement if significantly stretched or damaged.
Chair feels unstable or wobbly.	Uneven surface; loose frame connections.	Move the chair to a flat, level surface. Check all bolts and screws and tighten them securely.
Difficulty folding/unfolding.	Mechanism stiff; obstruction.	Apply a small amount of silicone lubricant to pivot points if stiff. Check for any objects obstructing the folding mechanism.

8. SPECIFICATIONS

Detailed specifications for the Devoko Zero Gravity Recliner Chair:

- **Model Name:** Zero Gravity
- **Brand:** Devoko
- **Color:** Light Black
- **Material:** Alloy Steel frame, breathable fabric
- **Maximum Weight Recommendation:** 420 Pounds (190 kg)
- **Fully Opened Dimensions:** Approximately 65" (L) x 21.5" (W) x 29.8" (H)
- **Sitting Dimensions:** Approximately 35" (L) x 21.5" (W) x 43.5" (H)
- **Product Dimensions (Folded/Compact):** 43.5"D x 21.5"W x 35.5"H (Note: This may refer to a compact or upright dimension, refer to diagram for full details)
- **Seat Depth:** 21.5 inches
- **Special Feature:** Lightweight, Folding, Adjustable Reclining
- **Assembly Required:** No




Image: Detailed dimensional drawing of the Devoko Zero Gravity Recliner Chair.



OVERSIZED MODEL

- ✓ Support up to 420 lbs
- ✓ width and length increasing Even accommodate two people seating



ZERO GRAVITY CHAIR



NORMAL MODEL



- ✗ Only Support to 300 lbs
- ✗ width and length Only suitable for single person seating

Image: Comparison of the oversized model with a standard model, emphasizing the larger dimensions and higher weight capacity.

9. WARRANTY AND SUPPORT

For warranty information or customer support regarding your Devoko Zero Gravity Recliner Chair, please contact Devoko customer service directly. Refer to the product packaging or the official Devoko website for the most current contact details.

When contacting support, please have your product model name (Zero Gravity) and purchase details readily available.

© 2026 Devoko. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B082HJ6TGR>

More documents and user manuals: **<https://manuals.plus/>**