

Manuals.plus /

- › Zook /
- › Zook Thunder Buds Truly Wireless Earbuds User Manual

## Zook ZB-THUNDER BUDS

# Zook Thunder Buds Truly Wireless Earbuds User Manual

Model: ZB-THUNDER BUDS

## 1. PRODUCT OVERVIEW

---

The Zook Thunder Buds are truly wireless in-ear earbuds designed for a seamless audio experience. They feature Bluetooth 5.0 connectivity, intuitive touch controls, and an ergonomic design for comfort. The included charging case provides extended battery life, making them suitable for daily use and active lifestyles.



Image: Zook Thunder Buds in their charging case, showcasing the compact design and digital battery display.

## 2. WHAT'S IN THE BOX

---

Please check the package contents upon unboxing:

- 1 x THUNDER BUDS with Charging Case
- 1 x Charging Cable
- 1 x User Manual
- 1 x Warranty Card



Image: The Zook Thunder Buds charging case with one earbud removed, illustrating the components included.

## 3. SETUP AND PAIRING

---

### 3.1 Initial Pairing

1. Ensure the earbuds are fully charged.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for "Zook Thunder Buds" in the list of available Bluetooth devices.
5. Select "Zook Thunder Buds" to connect. A voice prompt will confirm successful pairing.

### 3.2 Using a Single Earbud

Each earbud can be used independently. Simply remove one earbud from the charging case, and it will automatically connect to your paired device. The other earbud can remain in the case or be used separately.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Touch Controls

The Zook Thunder Buds feature intuitive touch controls for managing music playback and calls:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.
- **Activate Voice Assistant (Siri/Google Assistant):** Triple tap on either earbud.

## 4.2 Charging the Earbuds and Case

Place the earbuds back into the charging case to recharge them. The charging case itself can be recharged using the provided USB-C cable. The digital display on the case indicates the battery level.

Your browser does not support the video tag.

Video: An overview of the Zook Thunder Buds features, including touch controls, battery life, and voice assistant compatibility.

## 5. MAINTENANCE

---

To ensure the longevity and optimal performance of your Zook Thunder Buds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry cloth. Avoid using abrasive materials or harsh chemicals.
- **Water Resistance:** The earbuds have an IPX5 rating, offering protection against water splashes, sweat, and dust. However, they are not designed for submersion in water. Avoid exposing them to heavy rain or swimming.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Charging:** Use only the provided charging cable or a certified USB-C cable. Do not attempt to charge with damaged cables or chargers.



Image: Close-up of the earbuds showing water resistance, highlighting their durability for active use.

## 6. TROUBLESHOOTING

---

If you encounter any issues with your Zook Thunder Buds, please refer to the following common solutions:

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on your device's Bluetooth. Place earbuds back in case, close, then reopen to re-enter pairing mode.
Only one earbud working	Place both earbuds back in the charging case, close the lid, wait a few seconds, then open the lid and remove both earbuds simultaneously. This should re-sync them.
Low volume or poor sound quality	Check your device's volume settings. Ensure earbuds are clean and properly seated in your ears. Try different ear tip sizes for a better seal.
Charging case not charging	Verify the charging cable and adapter are working correctly. Ensure the USB-C cable is fully inserted into the charging port.
Voice assistant not responding	Ensure the earbuds are connected to your device. Check your device's settings to confirm voice assistant is enabled and configured correctly.

## 7. SPECIFICATIONS

---

Feature	Detail
Model	ZB-THUNDER BUDS
Connectivity Technology	Wireless (Bluetooth 5.0)
Bluetooth Range	10 Metres
Battery Life (with case)	Up to 100 Hours
Charging Case Capacity	3200mAh (provides 25 recharges for earbuds)
IPX Rating	IPX5 (Water Resistant)
Control Method	Touch Control, Voice Control (Siri, Google Assistant)
Microphone	In-built, Stereo technology
Earpiece Shape	Rounded Tips (In-ear)
Item Weight	20 Grams
Product Dimensions	5 x 2 x 3 cm
Compatible Devices	Android/iOS devices

Your browser does not support the video tag.

Video: A detailed look at the Zook Thunder Buds, highlighting features like touch control, battery backup, voice assistant, heavy bass, sweat-proof design, digital battery indicator, and USB-C fast charging.

## 8. WARRANTY AND SUPPORT

---

Your Zook Thunder Buds come with a 1-year warranty. Please refer to the included Warranty Card for detailed terms and conditions. For technical support or warranty claims, please contact the manufacturer or authorized

service center.

**Manufacturer:** Intellegent Technologies Traders Limited

**Customer Care:** 18001033544