

[Manuals.plus](#) /

› [Hasbro](#) /

› Hasbro STAR WARS The Child Talking Plush Toy (Model F1115) Instruction Manual

Hasbro F1115

Instruction Manual: Hasbro STAR WARS The Child Talking Plush Toy

Model: F1115 | Brand: Hasbro

1. INTRODUCTION

This manual provides essential information for the safe and proper use of your Hasbro STAR WARS The Child Talking Plush Toy. Please read these instructions carefully before use and retain them for future reference. This interactive plush toy features character sounds and includes accessories, bringing the beloved character from The Mandalorian series to life.

2. IMPORTANT SAFETY INFORMATION

WARNING: This product may contain sharp points, small parts that are choking hazards, and other elements that are not suitable for children under 3 years of age. Adult supervision is recommended during play.

3. WHAT'S IN THE BOX

Your package should contain the following items:

- 1 x The Child Talking Plush Toy
- 1 x Bone Broth Bowl accessory
- 1 x Sorgan Frog accessory
- 3 x LR44 Batteries (pre-installed)



Image: The Child Talking Plush Toy with its bone broth bowl and Sorgan frog accessories.

4. SETUP

4.1. Battery Installation

The toy comes with 3 LR44 batteries pre-installed. If replacement is needed:

1. Locate the battery compartment at the back of the plush toy, typically secured with a hook-and-loop fastener.
2. Carefully open the fastener to access the battery pack.
3. Using a small Phillips head screwdriver, open the battery compartment cover.
4. Remove the old batteries and insert 3 new LR44 batteries, ensuring correct polarity (+/-).
5. Secure the battery compartment cover with the screw and close the hook-and-loop fastener.

5. OPERATION

5.1. Activating Sounds

To activate the character sounds, gently squeeze the soft body of The Child Talking Plush Toy. The toy features 10 unique vocal sounds from the character.

Your browser does not support the video tag.

Video: Official demonstration of The Child Talking Plush Toy's sounds by Hasbro Toys.

5.2. Using Accessories

The included bone broth bowl and Sorgan frog accessories can be placed in The Child's hands to recreate iconic

scenes from The Mandalorian series. The toy's posable arms allow for various interactive play scenarios.



Image: The Child Plush Toy interacting with its frog and bowl accessories.

6. MAINTENANCE

6.1. Cleaning Instructions

To clean the plush toy, gently spot clean with a damp cloth and mild soap. Do not immerse the toy in water, as this may damage the electronic components. Allow to air dry completely.

6.2. Battery Replacement

Refer to Section 4.1 for detailed instructions on replacing the batteries.

7. TROUBLESHOOTING

7.1. No Sound

- Ensure the batteries are correctly installed and not depleted. Replace if necessary (refer to Section 4.1).
- Confirm that the toy's body is being squeezed firmly enough to activate the sound mechanism.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions	4 x 10 x 8.25 inches
Item Weight	10.6 ounces
Model Number	F1115
Manufacturer Recommended Age	3 years and up
Batteries	3 LR44 batteries (included)
Sounds	10 character sounds



Image: The Child Plush Toy with height measurement.

9. WARRANTY AND SUPPORT

This product is covered by Hasbro's standard manufacturer warranty. For detailed warranty information, product support, or to inquire about replacement parts, please visit the official Hasbro website or contact their customer service department. Keep your proof of purchase for warranty claims.

For more information, visit the [Hasbro Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B082JJ2QM5>

More documents and user manuals: **<https://manuals.plus/>**