Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kircuit AC Wall Power Charger

Kircuit AC Wall Power Charger User Manual

Model: AC Wall Power Charger | Brand: Kircuit

1. Introduction

Thank you for choosing the Kircuit AC Wall Power Charger. This high-quality power adapter is designed to provide reliable and efficient charging for your compatible devices, such as the MOPO 10000mAh Portable Metal Power Bank. It features a robust design with built-in safety mechanisms to ensure rapid and secure charging.



Image 1.1: The Kircuit AC Wall Power Charger, showcasing its compact design and integrated power cable.

2. Setup

Setting up your Kircuit AC Wall Power Charger is straightforward. Follow these steps to begin charging your device:

1. **Unpack the Charger:** Carefully remove the charger from its packaging.
2. **Locate a Power Outlet:** Find a standard 100V-240V AC wall power outlet.
3. **Plug in the Charger:** Insert the charger's prongs firmly into the wall outlet.
4. **Connect to Device:** Connect the barrel connector end of the charger cable to the charging port of your MOPO 10000mAh Portable Metal Power Bank or other compatible device.



Image 2.1: The Kircuit charger connected to a power strip, ready for use.

3. Operating Instructions

Once connected, the Kircuit AC Wall Power Charger will automatically begin charging your device. The charger is designed for efficient and safe power delivery.

- **Input Voltage:** The charger accepts a wide input voltage range of 100V-240V AC, making it suitable for international travel (with appropriate plug adapters, if needed).
- **Charging Indication:** Refer to your device's manual for specific charging indicators (e.g., LED lights on your power bank) to confirm charging status.
- **Disconnecting:** Once your device is fully charged, disconnect the charger from your device and then from the wall outlet.



Image 3.1: The charger highlighting its 6.5 ft cord length for convenient use.

4. Maintenance

To ensure the longevity and optimal performance of your Kircuit AC Wall Power Charger, follow these simple maintenance guidelines:

- **Cleaning:** Disconnect the charger from the power outlet before cleaning. Use a soft, dry cloth to wipe the exterior.

Do not use liquid cleaners or aerosols.

- **Storage:** Store the charger in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Cable Care:** Avoid sharp bends or kinks in the power cable. Do not pull the cable to disconnect the charger from the outlet; always grasp the plug itself.
- **Inspection:** Periodically inspect the charger and cable for any signs of damage, such as frayed wires or cracked casing. If damage is found, discontinue use immediately.




Image 4.1: Illustration of the durable cable design, emphasizing high-quality materials and insulation.

5. Troubleshooting

If you encounter issues with your Kircuit AC Wall Power Charger, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Charger not providing power.	No power from outlet; loose connection; damaged charger.	• Test the outlet with another device. • Ensure the charger is firmly plugged into the wall and the device. • Inspect the charger and cable for visible damage. If damaged, discontinue use.
Slow charging.	Device issue; high power consumption during charging.	• Ensure your device is compatible with the charger's output. • Avoid using the device for intensive tasks while charging.

Problem	Possible Cause	Solution
Charger feels warm.	Normal operation; excessive load.	• A slight warmth during charging is normal. • If it becomes excessively hot or emits smoke/smell, immediately unplug it and discontinue use.

If the problem persists after trying these solutions, please contact Kircuit customer support.

6. Specifications

Feature	Detail
Brand	Kircuit
Model	AC Wall Power Charger
Input Voltage	100V-240V AC
Output Current	0.3A
Connectivity Technology	USB (for device connection), Barrel Connector (charger output)
Connector Type	Barrel Connector
Compatible Devices	Devices requiring a barrel connector adapter, such as MOPO 10000mAh Portable Metal Power Bank
Special Feature	Portable, Travel
Item Weight	8 ounces
Cord Length	6.5 ft (approx. 1.98 meters)

Note: Specifications are subject to change without notice.

7. Safety Information

Your Kircuit AC Wall Power Charger is designed with multiple safety features to protect both the charger and your connected devices. Please adhere to the following safety guidelines:

Built-in Safety Protections:

- **Short Circuit Protection:** Prevents damage from short circuits.
- **Excess Voltage Protection:** Safeguards against over-voltage conditions.
- **Over Temperature Protection:** Protects against overheating.
- **Overcurrent Protection:** Prevents damage from excessive current flow.




Image 7.1: Overview of the comprehensive safety protections integrated into Kircuit chargers.

General Safety Precautions:

- Do not expose the charger to water, moisture, or extreme temperatures.
- Do not disassemble, modify, or attempt to repair the charger yourself. Refer to qualified service personnel.
- Keep out of reach of children.
- Ensure proper ventilation around the charger during use.
- Unplug the charger during lightning storms or when unused for long periods.




Image 7.2: Comparison highlighting the robust and UL Standard Quality plug design of Kircuit chargers.

8. Warranty and Support

Kircuit products are manufactured to high standards and undergo rigorous testing. While specific warranty details are not provided in this manual, Kircuit is committed to customer satisfaction.

For technical support, troubleshooting assistance, or inquiries regarding your Kircuit AC Wall Power Charger, please contact Kircuit customer service through the retailer where you purchased the product or visit the official Kircuit website for contact information.

© 2024 Kircuit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B082KGCTKL

More documents and user manuals: **https://manuals.plus/**