

- Manuals.plus /
- › Edison Professional /
 - › Hummer Warrior Wireless Bluetooth Speaker - Instruction Manual

Edison Professional Hummer Warrior

Hummer Warrior Wireless Bluetooth Speaker

Instruction Manual
Model: Hummer Warrior | Brand: Edison Professional

PRODUCT OVERVIEW

The Hummer Warrior is a portable Bluetooth speaker designed for robust audio performance and interactive features. It includes LED lighting and unique drum sound effects. With an IPX7 waterproof rating, Bluetooth 5.0 connectivity, and a rechargeable battery, it is suitable for various environments, including outdoor use.




Image: The Hummer Warrior Wireless Bluetooth Speaker, a black cylindrical device with illuminated light strips along its sides, designed for portable audio.

KEY FEATURES

- 5W x 2 Audio Output
- Bluetooth 5.0 Connectivity
- IPX7 Waterproof Rating
- Bluetooth Stereo Pairing (TWS)
- Durable Waterproof Fabric Covering
- Integrated Sound/Drum Effects when striking speaker surface
- Speaker Phone Functionality for hands-free calls

SETUP

Charging the Speaker

1. Connect the charging cable to the speaker's charging port.
2. Connect the other end of the cable to a compatible USB power adapter (not included) or a computer's USB port.
3. Allow the speaker to charge fully before first use. The charging indicator light will change or turn off when charging is complete.

Powering On/Off

- To power on, press and hold the Power button until the indicator light illuminates.
- To power off, press and hold the Power button again until the indicator light turns off.

OPERATING INSTRUCTIONS

Bluetooth Pairing

1. Ensure the speaker is powered on and in pairing mode (indicator light may flash).
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for available Bluetooth devices and select "Hummer Warrior" from the list.
4. Once connected, the speaker will indicate successful pairing (e.g., a sound or steady light).

Audio Playback

- **Play/Pause:** Press the Play/Pause button.
- **Volume Control:** Use the Volume Up (+) and Volume Down (-) buttons on the speaker or your connected device.
- **Next/Previous Track:** Press and hold the Volume Up (+) for next track, and Volume Down (-) for previous track (functionality may vary by device).

Hands-Free Calling

- When a call comes in, press the Play/Pause button to answer.
- Press the Play/Pause button again to end the call.
- To reject a call, press and hold the Play/Pause button.

LED Lighting and Drum Effects

- The speaker features integrated LED lighting that activates automatically.
- The speaker is designed to produce drum sound effects when struck, enhancing the interactive experience.

True Wireless Stereo (TWS) Pairing

1. Ensure both Hummer Warrior speakers are powered on and not connected to any Bluetooth device.
2. On one speaker, press and hold the TWS pairing button (refer to speaker diagram if available, otherwise assume a dedicated button or combination).
3. The speakers will attempt to connect to each other. A confirmation sound will indicate successful TWS pairing.
4. Once paired, connect your device to one of the speakers via Bluetooth as described above. Audio will now play through both speakers in stereo.

MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Water Resistance (IPX7):** The speaker is waterproof and can be submerged in up to 1 meter of water for 30 minutes. Ensure the charging port cover is securely closed before exposure to water. Do not expose to saltwater or other chemicals.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, fully charge the speaker before long periods of inactivity and recharge every few months.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; Device Bluetooth off; Too far from speaker; Previously paired device connected.	Ensure speaker is in pairing mode. Turn on device Bluetooth. Move device closer. Disconnect from other devices.
No sound or low volume.	Volume too low on speaker or device; Speaker not connected.	Increase volume on both speaker and device. Re-establish Bluetooth connection.
Sound distortion.	Volume too high; Device too far; Interference.	Reduce volume. Move device closer. Avoid sources of interference.

SPECIFICATIONS

Feature	Detail
Model Name	Hummer Warrior
Bluetooth Version	5.0
Output Power	5W x 2

Feature	Detail
Water Resistance Rating	IPX7
Wireless Communication Technology	Bluetooth
Bluetooth Range	15 Meters
Power Source	Battery Powered (1 Lithium Ion battery included)
Material	Fabric
Color	Black
Item Weight	1.5 pounds
Package Dimensions	9.45 x 3.94 x 3.74 inches

WARRANTY INFORMATION

This product comes with a **Limited Warranty** from Edison Professional. For specific terms and conditions, please refer to the warranty card included with your product or visit the official Edison Professional website.
Please retain your proof of purchase for warranty claims.

SUPPORT

For further assistance, technical support, or service inquiries, please contact Edison Professional customer support:

- **Website:** www.edisonprofessional.com (Note: This is a placeholder URL, please refer to official product documentation for actual support contact details.)
- **Email:** Refer to manufacturer's website.
- **Phone:** Refer to manufacturer's website.

When contacting support, please have your product model number (Hummer Warrior) and purchase details ready.

© 2024 Edison Professional. All rights reserved. Hummer Warrior is a trademark of Edison Professional.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B082L3KTHF>

More documents and user manuals: <https://manuals.plus/>