

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Samsonite](#) /

› [Samsonite Travel Sentry 3-Dial Combination Lock User Manual](#)

## Samsonite 91160-1041

# Samsonite Travel Sentry 3-Dial Combination Lock User Manual

MODEL: 91160-1041

## Introduction

---

Thank you for choosing the Samsonite Travel Sentry 3-Dial Combination Lock. This lock is designed to provide security for your luggage while complying with Transportation Security Administration (TSA) regulations. Its sturdy zinc alloy construction ensures durability, and the oversized, smooth-turning dials offer ease of use. The triple-dial mechanism allows you to set and reset your personal combination, providing hundreds of possible choices for enhanced protection.

The distinct design and color of this lock also assist in easily identifying your luggage. TSA agents can open and re-lock your luggage without damaging the lock, using a special key, ensuring your belongings remain secure throughout the screening process.



This image displays the Samsonite Travel Sentry 3-dial combination lock. The lock is black with three numerical dials and a metal shackle. The TSA red diamond logo is visible on the front.

## Setup: Setting Your Combination

---

Your lock is factory preset to open at 0-0-0. To set your personal combination, follow these steps:

1. **Open the Lock:** Ensure the lock is set to the current combination (initially 0-0-0) and pull up the shackle.
2. **Locate the Reset Mechanism:** On the bottom or side of the lock body, you will find a small button or lever. Use a pointed object (like a pen tip) to press and hold this button or move the lever to the reset position.
3. **Set Your New Combination:** While holding the reset mechanism, rotate the three dials to your desired personal combination. Choose a memorable sequence of numbers.
4. **Release the Reset Mechanism:** Release the button or return the lever to its original position. Your new combination is now set.
5. **Test Your Combination:** Scramble the dials, then enter your new combination and pull the shackle to confirm it opens.

*Important: Make sure to remember your new combination. There is no master key for the user to reset the*

combination if forgotten.

Your browser does not support the video tag.

This video provides a step-by-step guide on how to set the combination for a 3-digit TSA-approved cable lock, similar to the Samsonite model. It also shows how to lock and unlock the device.

## Operating the Lock

---

### To Lock Your Luggage:

1. Set the dials to your personal 3-digit combination.
2. Insert the shackle through the zipper pulls or designated lock points on your luggage.
3. Push the shackle down until it clicks into place.
4. Scramble the dials to a random set of numbers to secure the lock.

### To Unlock Your Luggage:

1. Rotate the dials to your personal 3-digit combination.
2. Pull the shackle upwards to release the lock.

### TSA Inspection Feature:

This lock is Travel Sentry Approved, meaning TSA security personnel can open your luggage for inspection without damaging the lock or your bag. They use a universal master key to access the lock. After inspection, they will re-lock your bag, ensuring its security.

Some TSA-approved locks feature a red indicator that pops up if the lock has been opened by TSA. This allows you to know if your luggage was inspected during transit.

Your browser does not support the video tag.

This video demonstrates how a TSA indicator padlock works, showing how a red indicator pops up when TSA agents have opened and inspected luggage. This feature is common among TSA-approved locks.

## Maintenance

---

- **Cleaning:** Wipe the lock with a soft, damp cloth to remove dirt and grime. Avoid using harsh chemicals or abrasive cleaners.
- **Lubrication:** If the dials become stiff, apply a small amount of graphite lubricant or silicone spray to the moving parts.
- **Storage:** Store the lock in a dry place when not in use to prevent corrosion.

## Troubleshooting

---

- **Lock will not open:** Ensure you are entering the correct 3-digit combination. Double-check each number. If you have forgotten your combination, there is no factory reset for the user.
- **Dials are stiff:** Apply a small amount of lubricant (e.g., graphite powder or silicone spray) to the dials and work them back and forth to distribute the lubricant.
- **Shackle is stuck:** Check for any debris or foreign objects obstructing the shackle mechanism. Ensure the combination is correctly aligned.

## Specifications

---

Feature	Detail
Brand	Samsonite
Model Name	Travel Sentry 3-dial Combination Lock
Model Number	91160-1041
Lock Type	Combination Lock
Special Feature	Keyless, TSA Approved
Material	Zinc Alloy (Body), Plastic (Dials)
Item Dimensions (L x W x H)	0.75 x 1.25 x 2.5 inches
Item Weight	3.59 ounces
UPC	043202772771

## Warranty Information

---

This Samsonite Travel Sentry 3-Dial Combination Lock is covered by the manufacturer's limited warranty. Please refer to the product packaging or the official Samsonite website for specific details regarding warranty coverage, terms, and conditions.

## Customer Support

---

For further assistance, questions, or to report any issues with your Samsonite Travel Sentry 3-Dial Combination Lock, please contact Samsonite Customer Service. You can find contact information on the official Samsonite website or through the retailer where you purchased the product.