

[Manuals.plus](#) /

› [Uiosmuph](#) /

› Uiosmuph G12 LED Wireless Silent Mouse User Manual

Uiosmuph G12

Uiosmuph G12 LED Wireless Silent Mouse User Manual

Model: G12

1. PRODUCT OVERVIEW

The Uiosmuph G12 is a slim, rechargeable 2.4G wireless optical mouse designed for comfortable and quiet operation. It features LED lighting, silent click buttons, and broad compatibility with various devices.



Image: The Uiosmuph G12 LED Wireless Silent Mouse, showcasing its sleek design and LED light strip.

Package Contents:

- 1 x Uiosmuph G12 LED Wireless Mouse
- 1 x USB Receiver (stored at the mouse bottom)
- 1 x Type C Adapter
- 1 x USB C Charging Cable
- 1 x User Manual

2. SETUP INSTRUCTIONS

Follow these steps to connect your Uiosmuph G12 wireless mouse to your device.

Connecting via USB-A Port:

1. Locate the USB receiver stored in the compartment at the bottom of the mouse.
2. Turn on the mouse using the ON/OFF switch located on the bottom.
3. Plug the USB receiver directly into an available USB-A port on your computer or laptop.
4. The mouse should be automatically recognized and ready for use.

Connecting via USB-C Port:

1. Locate the USB receiver stored in the compartment at the bottom of the mouse.
2. Turn on the mouse using the ON/OFF switch located on the bottom.
3. Connect the USB receiver to the provided Type-C adapter.
4. Plug the Type-C adapter into an available USB-C port on your computer or device.
5. The mouse should be automatically recognized and ready for use.



Image: Visual guide for connecting the mouse using either a USB-A port or a USB-C adapter.

3. OPERATING INSTRUCTIONS

Understand the features and functions of your Uiosmuph G12 mouse.

Power On/Off and LED Control:

- The power switch is located on the bottom of the mouse.
- It has three positions: **ON (with LED)**, **ON (without LED)**, and **OFF**.
- Slide the switch to the desired position to power on the mouse or turn it off.
- The LED light strip will illuminate when set to **ON (with LED)**, cycling through 7 different colors.



Image: The bottom of the mouse, highlighting the LED/ON/OFF switch, battery indicator, and USB receiver storage.

Silent Click Feature:

The left and right mouse buttons are designed for silent clicking, minimizing noise during use. This feature allows for focused work without disturbing others.

LIGHT
CHARGING MOUSE

Noiseless Click

Keep you stay focused on your
work, no disturbing others



Silent



Image: Depiction of the silent click feature on the left and right mouse buttons.

Adjusting DPI (Sensitivity):

The mouse features adjustable DPI settings to change cursor sensitivity. Press the DPI button (usually located behind the scroll wheel) to cycle through the available DPI levels: 1000, 1200, and 1600 DPI.




Image: Illustration of the three adjustable DPI settings (1000, 1200, 1600) for cursor sensitivity.

Energy Saving Mode:

To conserve battery life, the mouse will automatically enter sleep mode after 8 minutes of inactivity. To reactivate, simply move the mouse or click any button.

4. MAINTENANCE AND CHARGING

Proper care and charging ensure optimal performance and longevity of your mouse.

Charging the Mouse:

The Uiosmuph G12 mouse has a built-in rechargeable battery. When the battery is low, the LED indicator on the bottom of the mouse may signal a low charge, or performance may degrade.

1. Connect the provided USB-C charging cable to the USB-C charging port located at the front of the mouse.
2. Plug the other end of the charging cable into a USB power source (e.g., computer USB port, USB wall adapter).
3. The LED lights may indicate charging status (refer to product specifications for exact behavior).
4. Once fully charged, disconnect the charging cable.

RECHARGEABLE WIRELESS MOUSE

No extra batteries needed



Image: The Uiosmuph G12 mouse being charged via its USB-C port.

Cleaning:

- Use a soft, dry cloth to wipe the exterior of the mouse.
- For stubborn dirt, a slightly damp cloth can be used, ensuring no moisture enters the device.
- Avoid using harsh chemicals or abrasive cleaners.

5. TROUBLESHOOTING

If you encounter issues with your Uiosmuph G12 mouse, refer to the following common solutions.

Mouse Not Responding:

- **Check Power:** Ensure the mouse is turned ON using the switch on the bottom.
- **Check Battery:** Recharge the mouse if the battery is low.
- **Check Receiver:** Ensure the USB receiver is securely plugged into a working USB-A or USB-C port on your device.

Try a different port if available.

- **Re-pair:** In some cases, removing and re-inserting the USB receiver can re-establish the connection.
- **Interference:** Move the mouse closer to the receiver or away from other wireless devices that might cause interference.

LED Lights Not Working:

- Ensure the power switch on the bottom of the mouse is set to the **ON (with LED)** position.
- Check battery level; low battery might affect LED functionality.

Cursor Movement is Erratic or Slow:

- **Surface:** Use the mouse on a clean, non-reflective surface.
- **DPI Setting:** Adjust the DPI setting to a higher level if the cursor is too slow.
- **Obstructions:** Ensure the optical sensor on the bottom of the mouse is clean and free from debris.

6. SPECIFICATIONS

Feature	Specification
Model Number	G12
Connectivity Technology	2.4G Wireless (USB Receiver)
Movement Detection	Optical
DPI Levels	1000 / 1200 / 1600 DPI
Special Features	LED Lights, Portable, Rechargeable, Silent Click
Battery	Built-in Rechargeable Battery (1 included)
Product Dimensions	4.4 x 2.22 x 0.79 inches (11.18 x 5.64 x 2.01 cm)
Item Weight	2.4 ounces (68 grams)
Compatibility	Windows 7/8/10/XP, Vista, Linux, Mac OS, Chrome OS, etc.



Image: The Uiosmuph G12 mouse with its length (122mm) and width (57mm) indicated.

7. WARRANTY AND SUPPORT

Warranty Information:

Please refer to the product packaging or the official Uiosmuph website for specific warranty terms and conditions. Typically, products are covered against manufacturing defects for a defined period from the date of purchase.

Customer Support:

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Uiosmuph customer support through their official website or the contact information provided with your purchase.

You can visit the [Uiosmuph Store on Amazon](#) for more information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question