

## Amazon Renewed MK-1631

# SEGA Genesis 2 Slim MK-1631 Video Game System User Manual

Model: MK-1631

## INTRODUCTION

---

This manual provides comprehensive instructions for the setup, operation, and maintenance of your SEGA Genesis 2 Slim MK-1631 video game system. Please read this manual thoroughly before use to ensure proper functionality and enjoyment of your classic gaming experience.

## PACKAGE CONTENTS

---

Verify that all items listed below are included in your package:

- Original SEGA Genesis 2nd Generation 16-Bit Console
- Two (2) Aftermarket Controllers
- Aftermarket Power Adapter
- A/V Cables for television hook-up



Image: The SEGA Genesis 2 Slim MK-1631 console, accompanied by two black controllers, a power adapter, and a set of red, white, and yellow AV cables, laid out on a white surface.

## SETUP INSTRUCTIONS

---

1. **Connect the A/V Cables:** Locate the A/V output port on the back of the SEGA Genesis console. Connect the multi-pin end of the A/V cable to this port. Connect the red (audio right), white (audio left), and yellow (video) RCA plugs to the corresponding input jacks on your television. Ensure a secure connection for all cables.
2. **Connect the Power Adapter:** Insert the small barrel connector of the power adapter into the DC IN port on the back of the console. Plug the other end of the power adapter into a standard electrical outlet.
3. **Connect the Controllers:** Plug the controller cables into the controller ports on the front of the console. Controller Port 1 is typically on the left, and Controller Port 2 is on the right.
4. **Insert a Game Cartridge:** Gently insert a SEGA Genesis game cartridge into the cartridge slot on top of the console, ensuring it is fully seated.
5. **Power On:** Turn on your television and select the correct A/V input channel. Press the POWER button on the SEGA Genesis console to turn it on.

## OPERATING INSTRUCTIONS

---

### Basic Operation

- **Power On/Off:** Use the POWER button located on the console to turn the system on or off.
- **Reset:** The RESET button on the console will restart the currently inserted game.
- **Playing Games:** Once the console is powered on with a game cartridge inserted and the correct TV input selected, the game should automatically start.

## Controller Functions

The included controllers feature a D-pad for movement, A, B, C buttons for actions, and a START button for pausing or menu navigation. Specific button functions may vary by game.

## MAINTENANCE

- **Cleaning the Console:** Use a soft, dry cloth to wipe down the exterior of the console. Avoid using liquid cleaners directly on the console.
- **Cleaning Game Cartridges:** If a game is not loading, gently clean the gold contacts on the bottom of the game cartridge with a cotton swab lightly dampened with isopropyl alcohol. Allow to dry completely before reinserting.
- **Storage:** Store the console and accessories in a cool, dry place away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

Problem	Solution
No Power / Console Not Turning On	<ul style="list-style-type: none"><li>◦ Ensure the power adapter is securely connected to both the console and a working electrical outlet.</li><li>◦ Verify the power outlet is functional by testing it with another device.</li></ul>
No Video or Audio on TV (Black Screen)	<ul style="list-style-type: none"><li>◦ Confirm the A/V cables (red, white, yellow) are correctly and securely plugged into the console and the corresponding input jacks on your TV.</li><li>◦ Ensure your TV is set to the correct A/V input channel (e.g., AV1, Video 1, Input).</li><li>◦ Try cleaning the game cartridge contacts as described in the Maintenance section.</li><li>◦ Ensure the game cartridge is fully inserted into the console.</li></ul>
Controllers Not Responding	<ul style="list-style-type: none"><li>◦ Check that the controller cables are firmly plugged into the console's controller ports.</li><li>◦ Test with the second controller to determine if the issue is with a specific controller or the console port.</li></ul>

## SPECIFICATIONS

- **Model Number:** MK-1631
- **Console Type:** SEGA Genesis 2nd Generation 16-Bit
- **Package Dimensions:** 11.42 x 11.42 x 5.83 inches
- **Item Weight:** Approximately 3.45 pounds
- **Manufacturer:** Sony (*Note: This information may refer to a component supplier, as SEGA is the console manufacturer.*)
- **Date First Available:** December 11, 2019





## WARRANTY AND SUPPORT

This product is offered as an Amazon Renewed item. Amazon Renewed products are professionally inspected and tested to work and look like new. If you are not satisfied with your purchase, renewed products are eligible for replacement or refund under the [Amazon Renewed Guarantee](#). Please refer to the Amazon Renewed Guarantee for specific terms and conditions regarding returns and replacements.

For further assistance, please contact Amazon customer support or the seller, RetroRefresh, directly.

© 2025 Amazon Renewed. All rights reserved.

Related Documents - MK-1631

	<p><a href="#">Sega Genesis Nomad Instruction Manual</a></p> <p>Official instruction manual for the Sega Genesis Nomad portable video game console, covering setup, operation, care, troubleshooting, and specifications. Includes warnings, precautions, and connection guides.</p>
	<p><a href="#">Sega Genesis Instruction Manual</a></p> <p>Official instruction manual for the Sega Genesis video game console, covering setup, operation, troubleshooting, and warranty information. Learn how to connect your system, play games, and resolve common issues.</p>
	<p><a href="#">Sega Saturn Instruction Manual: Setup, Operation, and Troubleshooting Guide</a></p> <p>Comprehensive instruction manual for the Sega Saturn video game console, covering setup, connecting to your TV, operating the system, playing games and audio CDs, troubleshooting, and hardware specifications.</p>
	<p><a href="#">Sega Saturn Instruction Manual</a></p> <p>Official instruction manual for the Sega Saturn video game console, covering setup, operation, safety precautions, troubleshooting, and hardware specifications.</p>



### [Sega Saturn Instruction Manual: Setup, Operation, and Troubleshooting Guide](#)

The official instruction manual for the Sega Saturn gaming console. Learn how to set up your system, connect it to your TV, play games and audio CDs, manage settings, troubleshoot issues, and understand hardware specifications and warranty details.



### [Sega Saturn Instruction Manual: Setup, Operation, and Troubleshooting](#)

Comprehensive instruction manual for the Sega Saturn video game console, covering setup, connecting peripherals, gameplay, audio CD functions, system settings, troubleshooting, hardware specifications, and warranty information.