

SupplySource PFEL55913.0

SupplySource AC Adapter User Manual

FOR PROFORM SMART STRIDER ELLIPTICAL (MODEL PFEL55913.0)

Introduction

This manual provides essential instructions for the safe and effective use of your SupplySource AC Adapter, specifically designed for the Proform Smart Strider Elliptical, Model PFEL55913.0. Please read this manual thoroughly before using the product and retain it for future reference.

Safety Information and Important Notices

- **Compatibility:** Ensure the DC output and tip size of this AC adapter are compatible with your device before connecting. Incompatible adapters can cause damage.
- **Ventilation:** When using the adapter for extended periods, ensure adequate ventilation. Avoid placing it on soft surfaces or in enclosed spaces that could restrict airflow.
- **Environmental Conditions:** Do not expose the adapter to excessive humidity or extreme temperatures. Avoid placing it on or near heat-sensitive materials.
- **Safety Features:** This SupplySource AC Adapter is manufactured with built-in safety features to protect against incorrect voltage (IV), short circuits (SC), and internal overheating (IO). It is certified with CE and FCC standards.
- **Handling:** Do not attempt to open, modify, or repair the adapter. Refer all servicing to qualified personnel.
- **Children:** Keep the adapter out of reach of children.

BUILT IN WITH SAFETY ELECTRONICS



Over Charge
Protection



Over Voltage
Protection



Short-circuit
Protection



Over Current
Protection



Over Temp
Protection



24 Months
Warranty



Image: The SupplySource AC Adapter highlighting its built-in safety electronics, including protections against overcharge, over voltage, short-circuit, over current, and over temperature. It also mentions a 24-month warranty.

Setup and Connection

1. **Verify Compatibility:** Before connecting, confirm that the voltage and current requirements of your Proform Smart Strider Elliptical (Model PFEL55913.0) match the specifications of this SupplySource AC Adapter. Also, ensure the connector tip is the correct size and type.
2. **Connect to Device:** Insert the DC output connector of the AC adapter firmly into the power input port of your Proform Smart Strider Elliptical.
3. **Connect to Power Outlet:** Plug the AC input plug of the adapter into a standard 100-240V wall power outlet.
4. **Power On:** Once connected, your elliptical should receive power. Refer to your elliptical's manual for specific power-on procedures.



Image: The SupplySource AC Adapter, a black rectangular power brick with a two-prong US plug, connected to a coiled black power cord with a barrel connector. This illustrates the main components of the adapter.

Operating Instructions

The SupplySource AC Adapter is designed for continuous operation within its specified parameters. Once properly connected, it will provide stable power to your Proform Smart Strider Elliptical.

- Ensure the adapter is not covered during operation to allow for proper heat dissipation.
- Avoid bending or crimping the power cable excessively, as this can damage internal wires.
- If the adapter feels unusually hot to the touch, disconnect it immediately and check for obstructions or ventilation issues.

- Prevent Leakage and Breakdown
- Ensure Efficient Stable Current
- Strong Power Output



Image: A close-up view of the adapter’s power cable, emphasizing its length (1.2 meters or approximately 4 feet) and features designed to prevent leakage and breakdown, ensure efficient stable current, and provide strong power output.

Maintenance and Storage

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a dry, soft cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Cable Care:** Regularly inspect the power cable for any signs of damage, such as fraying, cuts, or exposed wires. If damage is found, discontinue use and replace the adapter.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.

Troubleshooting

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Device not powering on	◦ Adapter not properly connected ◦ Power outlet not active ◦ Incompatible adapter ◦ Damaged adapter or cable	◦ Ensure all connections are secure. ◦ Test the power outlet with another device. ◦ Verify adapter specifications match device requirements. ◦ Inspect adapter and cable for damage; replace if necessary.
Adapter is hot	◦ Poor ventilation ◦ Overload or internal fault	◦ Ensure adapter is in a well-ventilated area. ◦ Disconnect immediately. If problem persists, discontinue use.

Specifications

- **Model:** PFEL55913.0 (Compatible Device)
- **Input Voltage Range:** 100-240V AC
- **Input Frequency:** 50-60Hz
- **Cable Length:** Approximately 4 feet (1.2 meters)
- **Connector Type:** Barrel Connector
- **Material:** Metal, Plastic
- **Certifications:** CE, FCC
- **Included Components:** 1 x AC Adapter

Warranty and Support

This SupplySource AC Adapter comes with a **24-month warranty** against manufacturing defects. For warranty claims or technical support, please contact SupplySource customer service.

If you have any further questions or concerns regarding the product, please do not hesitate to contact us. We are committed to providing assistance.



On a business trip



Travel vacation



in the car



in the office



Exquisite and compact body,
carry it with you to meet your needs

Image: The compact SupplySource AC Adapter shown in a hand, emphasizing its portable design. Surrounding images depict its use in various settings: on a business trip, during travel vacation, in a car, and in an office, illustrating its versatility.

© 2025 SupplySource. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question