

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [WLIVE](#) /

› [WLIVE TV Stand Instruction Manual for S-Shaped Lowboard Model B082NT59RW](#)

WLIVE B082NT59RW

WLIVE TV Stand Instruction Manual

Model: B082NT59RW

INTRODUCTION

Thank you for purchasing the WLIVE S-shaped TV Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new TV stand. Please read these instructions carefully before assembly and retain them for future reference.

This TV stand is designed to accommodate televisions ranging from 24 to 37 inches and has a maximum load capacity of 25 kg (55 lbs). Its compact design and integrated casters offer flexibility and convenience for various living spaces.



各テレビサイズに対応



テレビの種類やメーカーによって
重量や外寸が異なりますので、目安としてご利用ください。

Image: The WLIVE TV stand supporting a television, illustrating its design and suitable TV sizes (24V-37V) and load capacity (25kg).

SAFETY INFORMATION

- Always follow the assembly instructions carefully. Incorrect assembly can lead to instability and potential injury.
- Do not exceed the maximum load capacity of 25 kg (55 lbs). Overloading can cause the stand to collapse.
- Ensure the TV stand is placed on a flat, stable surface to prevent tipping.
- Keep small parts and assembly tools out of reach of children during assembly.
- Regularly check all fasteners to ensure they remain tight.
- Do not allow children to climb on or play with the TV stand.

PACKAGE CONTENTS

Before beginning assembly, please verify that all parts are present and undamaged. If any parts are missing

or damaged, please contact customer support.

- Wooden panels (various sizes for S-shaped structure)
- Casters (wheels) - 4 units
- Assembly hardware (screws, dowels, etc.)
- Assembly tools (basic wrench, Allen key if applicable)

A Phillips screwdriver is recommended for easier assembly (not included).

SETUP AND ASSEMBLY

Follow these steps to assemble your WLIVE TV Stand. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

1. **Identify Components:** Unpack all components and identify them against the parts list (usually provided in a separate diagram).
2. **Attach Casters (Optional):** If you wish to use the casters, attach them to the designated holes on the bottom panel. Ensure the two front casters with locking mechanisms are placed at the front. Tighten securely.
3. **Assemble S-Shaped Structure:** Begin by connecting the side panels to the bottom and middle shelves according to the S-shaped design. Use the provided screws and dowels. Ensure all connections are firm.
4. **Install Top Panel:** Secure the top panel to the assembled S-shaped structure.
5. **Final Tightening:** Once all panels are in place, gently tighten all screws to ensure stability. Avoid overtightening to prevent damage to the wood.



Image: Detailed dimensional diagram of the TV stand, useful for assembly and understanding the structure.

OPERATING INSTRUCTIONS

Using the Casters

The WLIVE TV Stand is equipped with four casters for easy mobility. Two of the front casters include a locking mechanism to secure the stand in place.

- **To Move:** Unlock the front casters by flipping the lever upwards. Gently push the stand to its desired location.
- **To Secure:** Once the stand is in position, lock the front casters by flipping the lever downwards. This prevents unintended movement.

キャスター付きでお掃除らくらく！



お掃除の際や模様替えの時も、キャスター付きで移動は楽に行える。

Image: A detailed view of a castor, highlighting its locking function for stability.

Removing Casters (Lowboard Configuration)

For a lower profile, the casters can be removed. This will reduce the overall height of the stand to approximately 33.5 cm (13.2 inches).

- Carefully turn the TV stand upside down.
- Unscrew and remove each castor from the bottom panel.
- Place the stand directly on the floor. Ensure the floor is protected if necessary.

Storage Capacity

The S-shaped design provides two wide open spaces for storing various media devices and accessories.

- Each main storage space measures approximately 62.5 cm (W) x 30 cm (D) x 14 cm (H).
- These spaces are suitable for AV devices such as HDD players, gaming consoles (e.g., PS4), and other media equipment.
- The open design facilitates easy wiring and ventilation for electronic devices.



コンパクトだけど収納たっぷり



Image: The TV stand's storage compartments, demonstrating how various AV devices and decorative items can be organized.

MAINTENANCE

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Dusting:** Regularly dust the stand to prevent accumulation.
- **Fasteners:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.
- **Avoid Moisture:** Protect the stand from excessive moisture and direct sunlight to prevent warping or discoloration.

TROUBLESHOOTING

- **Stand is Wobbly:**
 - Ensure all screws are securely tightened.
 - Verify that the stand is placed on a level surface.
 - If casters are used, ensure they are all properly installed and locked if stationary.

- **Missing Parts:**

- Carefully check all packaging materials.
- Contact WLIVE customer support with your purchase details if parts are genuinely missing.

- **Difficulty Assembling:**

- Review the assembly instructions step-by-step.
- Ensure you are using the correct hardware for each step.
- Do not force parts together; if they don't fit, re-check the orientation.

SPECIFICATIONS

Model Number	B082NT59RW
Brand	WLIVE
Material	Wood (E1 Grade Particle Board)
Color	Natural
Overall Dimensions (W x D x H)	80 cm x 30 cm x 39 cm (31.5 in x 11.8 in x 15.4 in)
Height (without casters)	33.5 cm (13.2 in)
Item Weight	9.4 kg (20.7 lbs)
Load Capacity	25 kg (55 lbs)
Board Thickness	1.5 cm (0.6 in)
Compatible TV Sizes	24-37 inches
Assembly Required	Yes

WARRANTY AND SUPPORT

WLIVE products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official WLIVE website.

If you encounter any issues or have questions not covered in this manual, please contact WLIVE customer support for assistance. Please have your model number (B082NT59RW) and purchase details ready when contacting support.

Note: Product specifications and design are subject to change without notice for product improvement.