

[Manuals.plus](#) /

› [IKONIC](#) /

› IKONIC Curl Me Up- 19mm Hair Curler Instruction Manual

IKONIC IK-850-19MM

IKONIC Curl Me Up- 19mm Hair Curler

Model: IK-850-19MM

INTRODUCTION

Thank you for choosing the IKONIC Curl Me Up- 19mm Hair Curler. This manual provides essential information for the safe and effective use of your new styling tool. Please read all instructions carefully before use and retain this manual for future reference.

Important Safety Instructions

- Always unplug the appliance immediately after use.
- Do not use while bathing or in a shower.
- Do not place or store the appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water.
- Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.
- This appliance is hot when in use. Do not let eyes or bare skin touch heated surfaces.
- Do not place the heated appliance directly on any surface while it is operating or cooling down. Use the integrated safety stand.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your IKONIC Curl Me Up curler:

- **Ceramic Shine Infused Barrel:** The heating element responsible for curling hair.
- **Cool Tip:** A non-heated tip for safe handling during use.
- **Integrated Safety Stand:** Allows the hot curler to rest safely on a surface without direct contact.
- **Comfort Grip Rubber Handle:** Provides a secure and comfortable hold.
- **Power Cord with 360° Swivel:** A 3-meter cord designed to prevent tangling.
- **Heat Ready Indicator System:** Visual indicator for when the curler has reached its operating temperature.



Image: Overview of the IKONIC Curl Me Up Hair Curler, highlighting key features such as the cool tip, ceramic coated barrel, integrated safety stand, and swivel cord.

SETUP AND PREPARATION

1. **Unpack:** Carefully remove the curler from its packaging. Ensure all components listed in the "Product Components" section are present.
2. **Inspect:** Before first use, inspect the curler and power cord for any signs of damage. Do not use if damaged.
3. **Placement:** Place the curler on a heat-resistant, flat surface. Ensure there is enough space around the curler and that it is away from flammable materials. Utilize the integrated safety stand to prevent the hot barrel from touching surfaces.
4. **Power Connection:** Plug the power cord into a suitable electrical outlet. Ensure the voltage matches the specifications of the appliance.
5. **Pre-heating:** Allow the curler to heat up. The infrared technology ensures instant heat-up, typically less than 60 seconds. The heat-ready indicator system will signal when the desired temperature is reached.



Image: The curler heating up, demonstrating its rapid heat-up capability via infrared technology.

OPERATING INSTRUCTIONS

Follow these steps for effective hair curling:

1. **Prepare Hair:** Ensure hair is clean, dry, and detangled. For best results, apply a heat protectant spray.
2. **Section Hair:** Divide your hair into manageable sections, typically 1-2 inches wide, depending on the desired curl size.
3. **Position Curler:** Open the clamp of the curler and place a section of hair between the clamp and the barrel, starting near the roots or mid-length. Close the clamp gently.
4. **Wrap Hair:** Carefully wrap the hair section around the ceramic barrel, moving towards the cool tip. Ensure the hair is evenly distributed around the barrel.
5. **Hold:** Hold the curler in place for a few seconds. The exact time will vary based on hair type and desired curl intensity. Start with shorter times and adjust as needed.
6. **Release Curl:** Open the clamp and gently slide the curler out of the curled section of hair. Allow the curl to cool completely before styling to set the shape.
7. **Repeat:** Continue this process for all sections of hair.
8. **Finish:** Once all hair is curled and cooled, gently run your fingers through the curls or brush lightly to achieve your desired style.




Image: Demonstrating the creation of small curls using the 19mm barrel of the IKONIC Curl Me Up curler.

MAINTENANCE AND CARE

Proper maintenance ensures the longevity and performance of your curler:

- **Cleaning:** Ensure the appliance is unplugged and completely cool before cleaning. Wipe the barrel and handle with a soft, damp cloth. Do not use abrasive cleaners or immerse the appliance in water.
- **Storage:** Store the curler in a cool, dry place. Do not wrap the cord around the appliance, as this can cause damage.
- **Cord Care:** Regularly check the power cord for any signs of damage. If the cord becomes twisted, untwist it before use.

TROUBLESHOOTING

Refer to this section for common issues and their solutions:

Problem	Possible Cause	Solution
Curler does not heat up.	Not plugged in, power outlet issue, or internal fault.	Ensure the curler is securely plugged into a working outlet. Check the power switch. If the issue persists, contact customer support.
Curls are not holding.	Hair not completely dry, insufficient holding time, or hair not properly sectioned.	Ensure hair is completely dry. Increase holding time slightly. Section hair into smaller, more manageable pieces. Allow curls to cool before styling.
Curler feels too hot.	Normal operation, or prolonged contact with skin.	The barrel gets hot during use. Always use the cool tip and integrated safety stand. Avoid direct contact with skin. The curler has overheat protection.
Automatic shut-off activated.	Safety feature activated after a period of inactivity.	This is a normal safety feature. Unplug and plug back in to reset and restart the curler.

PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	IK-850-19MM
Barrel Size	19mm
Material	Ceramic
Power Source	Corded Electric
Cord Length	3 meters (360° Swivel Cord)
Heat-up Time	Less than 60 seconds (Infrared technology)
Safety Features	Auto shut-off, Overheat protection, Integrated Safety Stand, Cool Tip
Product Dimensions	5 x 4 x 38 cm
Item Weight	1 kg (1000 Grams)
Country of Origin	China

WARRANTY AND SUPPORT

Manufacturer's Warranty: This product comes with a 1-year warranty provided by the manufacturer from the date of purchase. Please retain your purchase receipt as proof of purchase for warranty claims.

Contact Information: For warranty service, technical support, or any inquiries regarding your IKONIC Curl Me Up curler, please contact:

SSIZ International Pvt Ltd
323/3rd floor, Umrigar Building,
Opp Crawford market, Mumbai-400003,
Maharashtra INDIA
Customer Service: 18001209959

