

[Manuals.plus](#) /

› [UpStart Components](#) /

› UpStart Components 5301EL1001J Dryer Heating Element Replacement Manual for LG DLEX4270V Dryer

UpStart Components 5301EL1001J

UpStart Components 5301EL1001J Dryer Heating Element Replacement Manual

FOR LG DLEX4270V DRYER AND COMPATIBLE MODELS

Model: 5301EL1001J | Brand: UpStart Components

1. Introduction

This manual provides essential information and instructions for the UpStart Components 5301EL1001J Dryer Heating Element. This component is designed as a compatible replacement for the original heating element in LG DLEX4270V dryers and other models that utilize the 5301EL1001G heater assembly. Please read this manual thoroughly before attempting installation or maintenance to ensure safe and correct usage.

The heating element is a critical component responsible for generating the heat required for drying clothes. A malfunctioning heating element can result in a dryer that runs but does not heat, or heats insufficiently.

2. Safety Information

WARNING: Disconnect power to the dryer before servicing. Failure to do so may result in electrical shock, personal injury, or death.

- Always unplug the dryer from the electrical outlet or turn off the circuit breaker before beginning any repair or maintenance.
- Wear appropriate personal protective equipment, such as gloves, to prevent injury.
- If you are unsure about any step, consult a qualified appliance repair technician.
- Ensure all connections are secure and properly insulated after installation.
- Keep children and pets away from the work area.

3. Product Overview

The UpStart Components 5301EL1001J Dryer Heating Element is a durable replacement part designed to restore heating functionality to your dryer. It includes the heating coils and associated thermal components within a metal housing.



Image 1: Main view of the UpStart Components 5301EL1001J Dryer Heating Element assembly.




Image 2: Angled view of the heating element, highlighting the wiring and thermal components.




Image 3: Side view of the heating element housing.




Image 4: Internal view showing the heating coils within the element assembly.

4. Installation Instructions

Note: These are general instructions. Specific dryer models may vary. Always refer to your dryer's service manual for detailed, model-specific instructions. Professional installation is recommended.

1. **Disconnect Power:** Unplug the dryer from the wall outlet or turn off the circuit breaker supplying power to the dryer.
2. **Access the Heating Element:** Depending on your dryer model, you may need to remove the back panel, front panel, or top panel to access the heating element housing. This often involves removing screws and possibly disconnecting wire harnesses.
3. **Locate the Old Element:** Identify the existing heating element assembly. It is typically housed in a metal duct or chamber.
4. **Disconnect Wiring:** Carefully disconnect all electrical wires connected to the old heating element. Note their positions or take a photo for reassembly.
5. **Remove Old Element:** Unscrew or unclip the old heating element assembly from its mounting brackets. Carefully slide it out of the dryer.
6. **Install New Element:** Insert the new UpStart Components 5301EL1001J heating element into the dryer, ensuring it seats correctly in the mounting brackets. Secure it with screws or clips.
7. **Reconnect Wiring:** Reconnect all electrical wires to the new heating element, matching them to their original positions. Ensure all connections are tight and secure.

8. **Reassemble Dryer:** Reattach any panels or components that were removed to access the heating element. Ensure all screws are tightened and panels are securely in place.
9. **Restore Power and Test:** Plug the dryer back into the electrical outlet or turn on the circuit breaker. Run a short cycle with no load to verify that the dryer heats properly. Check for any unusual noises or smells.

5. Operating Information

The UpStart Components 5301EL1001J Dryer Heating Element operates automatically in conjunction with your dryer's control system. Once installed, it will generate heat as directed by the dryer's selected cycle and temperature settings. No direct user interaction with the heating element itself is required during normal operation.

6. Maintenance

Proper maintenance of your dryer can extend the life of all its components, including the heating element.

- **Clean Lint Filter:** Always clean the lint filter before or after every load to ensure proper airflow and prevent overheating.
- **Inspect Dryer Vent:** Regularly inspect and clean the dryer's exhaust vent system (from the dryer to the outside) to prevent lint buildup, which can restrict airflow and cause the heating element to overwork or overheat.
- **Avoid Overloading:** Do not overload the dryer, as this can also restrict airflow and lead to inefficient drying and increased strain on the heating element.

7. Troubleshooting

If your dryer is experiencing issues related to heating after installing the new element, consider the following:

- **Dryer Not Heating:**
 - Check if the circuit breaker for the dryer has tripped.
 - Ensure all electrical connections to the heating element are secure.
 - Inspect other thermal components (thermostats, thermal fuses) in the dryer, as they may have failed and are preventing the element from receiving power.
- **Insufficient Heat:**
 - Verify that the dryer vent is clear and not obstructed. Restricted airflow can significantly reduce drying efficiency.
 - Ensure the dryer is not overloaded.
- **Burning Smell:**
 - Immediately disconnect power. A burning smell can indicate lint buildup or a faulty component. Inspect the dryer's interior and vent for lint.

If troubleshooting steps do not resolve the issue, it is recommended to contact a qualified appliance repair technician.

8. Specifications

Part Number	5301EL1001J (UpStart Components: AP-5301EL1001J-DL79)
Compatible Dryer Models	LG DLEX4270V and other models using 5301EL1001G heater assembly
Compatible Heater Assembly Part Numbers	5301EL1001G, AP4439759, 1377645, 5301EL1001E, AEG72910301, AH3527791, EA3527791, PS3527791
Material	Metal housing with heating coils and plastic insulators
Brand	UpStart Components

9. Warranty and Support

Any warranties for this UpStart Components product are offered solely by UpStart Components. This product is a replacement part and is not affiliated with or covered under any warranties offered by the original dryer manufacturers.

For warranty claims or technical support, please contact UpStart Components directly through their official customer service channels.