



[Manuals.plus](#) /

› [Hemudu](#) /

› Hemudu HT07B-002P Universal Swivel Tabletop TV Stand Instruction Manual

Hemudu HT07B-002P

Hemudu HT07B-002P Universal Swivel Tabletop TV Stand Instruction Manual

Model: HT07B-002P

1. INTRODUCTION AND PRODUCT OVERVIEW

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Hemudu HT07B-002P Universal Swivel Tabletop TV Stand. This stand is designed to securely hold televisions ranging from 19 to 39 inches, with a maximum weight capacity of 35 kg (77 lbs). It features a 90-degree swivel capability (45 degrees left and 45 degrees right) and 4 levels of height adjustment to optimize your viewing experience. The robust construction includes a durable steel elliptical panel and an 8mm tempered glass base, ensuring stability and safety for your television.



Figure 1: Hemudu HT07B-002P Universal Swivel Tabletop TV Stand.

2. SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum weight capacity of 35 kg (77 lbs). Ensure your TV's weight is within this limit.
- **TV Size Compatibility:** This stand is suitable for TVs between 19 and 39 inches. Verify your TV's screen size and VESA mounting pattern before assembly.
- **VESA Compatibility:** The stand supports VESA patterns from 75x75mm to 200x200mm. Check your TV's VESA pattern.
- **Stable Surface:** Always place the TV stand on a flat, stable, and level surface to prevent tipping.
- **Children and Pets:** Keep children and pets away from the TV stand during assembly and ensure the TV is securely mounted to prevent accidents.
- **Proper Assembly:** Follow all assembly instructions carefully. Incorrect assembly can lead to product failure and injury.

- **Tighten Fasteners:** Ensure all screws and fasteners are securely tightened. Do not overtighten.
- **Cable Management:** Utilize the integrated cable management system to prevent tripping hazards and maintain a tidy setup.

3. PACKAGE CONTENTS

Please verify that all components are present and undamaged before proceeding with assembly. If any parts are missing or damaged, contact customer support.

- Tempered Glass Base
- Main Support Column
- VESA Mounting Plate
- VESA Extension Arms (if applicable for larger VESA patterns)
- Hardware Kit (various screws, washers, spacers for TV mounting)
- Assembly Tools (e.g., Allen wrench)
- Anti-slip Rubber Feet for Base
- Cable Management Clips/Ties

Multiple Features

Made of High-quality Materials, with Cable Management System & Anti-slip Feet



Figure 2: Key components of the TV stand, including the polished tempered glass base, safety lock, integrated cable management, and anti-slip rubber feet.

4. SETUP AND ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your Hemudu HT07B-002P TV Stand. It is recommended to have a second person assist with mounting the TV.

1. Attach the Main Support Column to the Base:

Place the tempered glass base (A) on a soft, clean surface to prevent scratches. Align the main support column (B) with the holes on the base. Secure it using the provided screws and washers. Ensure the column is oriented correctly for cable management access.




Figure 3: Illustration of attaching the main support column to the tempered glass base.

2. Assemble the VESA Mounting Plate:

Attach the VESA arms to the central VESA plate using the designated screws. Ensure the arms are configured to match your TV's VESA pattern (e.g., 75x75mm, 100x100mm, 200x100mm, 200x200mm). The stand supports various VESA patterns.

Will This Mount Fit My TV?

VESA Patterns					
W x h (mm)	200x200 100x200	150x150	200x100 100x100	75x75	50x50
H	<10.9"	<11.9"	<12.9"	<13.4"	<13.9"

Make sure the distance H < below Listed, depend on different h size.

Figure 4: Different configurations for the VESA mounting plate to accommodate various VESA patterns.

3. Attach the VESA Mounting Plate to Your TV:

Carefully place your TV face down on a soft, clean surface. Align the assembled VESA mounting plate with the mounting holes on the back of your TV. Select the appropriate screws, washers, and spacers from the hardware kit that fit your TV's specific requirements. Securely fasten the VESA plate to the TV. Do not overtighten.

4. Mount the TV onto the Stand:

With assistance, carefully lift the TV with the attached VESA plate. Hook the VESA plate onto the main support column. Ensure it is properly seated and engaged. Secure the TV to the column using the safety lock mechanism (typically a screw or knob) to prevent accidental dislodgement.

5. Cable Management:

Route your TV cables through the integrated cable management system on the main support column. Use the provided clips or ties to keep cables neat and organized, preventing tangles and improving aesthetics.

5. OPERATING INSTRUCTIONS

• Height Adjustment:

The stand offers 4 levels of height adjustment. To adjust the height, loosen the screws on the VESA mounting plate that secure it to the main column. Carefully raise or lower the TV to the desired height, then re-tighten the screws securely. Ensure the TV is level after adjustment.



Figure 5: Illustration showing the 4 adjustable height levels of the TV stand.

• Swivel Function:

The TV stand allows for a 90-degree swivel (45 degrees left and 45 degrees right). Gently rotate the TV to achieve your preferred viewing angle. No locking mechanism is typically required for the swivel function; it operates smoothly on its pivot.



Figure 6: Diagram illustrating the $\pm 45^\circ$ swivel adjustment capability of the TV stand.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the stand. For the tempered glass base, a glass cleaner can be used. Avoid abrasive cleaners or solvents that may damage the finish.
- **Regular Checks:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary, but do not over-tighten.

- **Cable Management:** Ensure cables remain neatly organized and are not pinched or stressed.
- **Avoid Overloading:** Do not place items heavier than the specified weight capacity on the stand or TV.

7. TROUBLESHOOTING


Problem	Possible Cause	Solution
TV is not stable or wobbles.	Loose fasteners; uneven surface; TV weight exceeds capacity.	Check and tighten all screws. Ensure the stand is on a level surface. Verify TV weight is within limits.
Difficulty adjusting TV height.	Screws securing the VESA plate to the column are too tight.	Loosen the height adjustment screws slightly before attempting to adjust. Re-tighten securely after adjustment.
VESA mounting plate does not fit TV.	Incorrect VESA pattern selected; wrong screws/spacers used.	Verify your TV's VESA pattern and ensure the mounting arms are configured correctly. Use the appropriate screws and spacers from the hardware kit.
Cables are messy or tangled.	Cable management not utilized or insufficient.	Route cables through the integrated cable management channel. Use additional cable ties if needed.

8. SPECIFICATIONS

- **Model:** HT07B-002P
- **Brand:** Hemudu
- **Material:** Steel, Tempered Glass
- **Color:** Black
- **TV Size Compatibility:** 19 - 39 inches
- **Maximum Weight Capacity:** 35 kg (77 lbs)
- **VESA Compatibility:** 75x75mm, 100x100mm, 200x100mm, 200x200mm
- **Swivel Angle:** ±45 degrees (90 degrees total)
- **Height Adjustment:** 4 levels
- **Mounting Type:** Tabletop
- **GTIN/UPC:** 742089097501

Product Description

Product Size & Maximum Compatibility



VESA (mm)	200x200 100x200	150x150	200x100 100x100	75x75	50x50
H	<10.9"	<11.9"	<12.9"	<13.4"	<13.9"

Make sure the distance **H** < below Listed, depend on different **h** size.

Figure 7: Detailed product dimensions and VESA compatibility chart for the TV stand.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Hemudu customer service directly. Keep your purchase receipt as proof of purchase.

Contact Information: Please visit the official Hemudu website or refer to the contact details provided with your product for support.