

[Manuals.plus](#) /

› [Kircuit](#) /

› Kircuit Charger for Innoo Tech 4-in-1 Portable Bluetooth Karaoke Power Supply User Manual

Kircuit AC Wall Power Charger

Kircuit Charger for Innoo Tech 4-in-1 Portable Bluetooth Karaoke Power Supply User Manual

Model: AC Wall Power Charger

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your Kircuit AC Wall Power Charger. This power supply is designed to provide reliable power for compatible devices, such as the Innoo Tech 4-in-1 Portable Bluetooth Karaoke system. Please read this manual thoroughly before use and retain it for future reference.



Figure 1: Kircuit AC Wall Power Charger. This image shows the main body of the charger with its specifications label and the two-prong plug.

2. SAFETY INFORMATION

To ensure safe operation and prevent damage, observe the following safety precautions:

- Use only with devices that match the charger's output specifications.
- Do not expose the charger to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the charger to strong impacts.
- Do not attempt to open or modify the charger. Refer all servicing to qualified personnel.
- Unplug the charger from the power outlet when not in use or during electrical storms.
- Ensure the power outlet is easily accessible for quick disconnection.
- The charger features built-in protections against short circuits, excess voltage, over-temperature, and overcurrent to ensure safe operation.

Built Safety Protections




Figure 2: Built-in Safety Protections. This diagram highlights the charger's protective features against common electrical issues.

3. SETUP

1. **Inspect the Charger:** Before first use, visually inspect the charger and its cable for any signs of damage. Do not use if damaged.
2. **Connect to Device:** Plug the DC output connector of the Kircuit charger into the power input port of your Innoo Tech 4-in-1 Portable Bluetooth Karaoke device. Ensure a firm connection.
3. **Connect to Power Outlet:** Insert the two-prong AC plug of the charger into a standard 100V-240V AC wall power outlet.
4. **Verify Connection:** Once connected, your device should begin charging or power on, depending on its design.



Figure 3: Charger in Use. This image demonstrates the charger connected to a power strip, ready to supply power to a device.

4. OPERATING INSTRUCTIONS

The Kircuit AC Wall Power Charger is designed for straightforward operation:

- Once properly connected to both the power outlet and your device, the charger will automatically begin supplying power.
- Monitor your device's charging indicator (if available) to confirm it is receiving power.
- When your device is fully charged or no longer requires power, disconnect the charger from both the device and the wall outlet.



Figure 4: Charger with Cord. This image displays the charger and its 6.5 ft power cord, indicating its reach.

5. MAINTENANCE

Proper care will extend the life of your Kircuit charger:

- **Cleaning:** Disconnect the charger from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the charger in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Cable Care:** The power cable is designed with high-quality materials and thick insulation for durability. Avoid bending, twisting, or pulling the cable excessively, especially near the connectors.
- **Plug Integrity:** The plugs are designed for secure and stable connections and can handle electrical loads without overheating. Ensure the plug is fully inserted into the outlet and not loose.

Durable design




Figure 5: Durable Cable Design. This image highlights the robust construction of the charger's power cable.




Figure 6: Secure Plug Design. This image compares the quality of Kircuit's plug design for safety and stability.

6. TROUBLESHOOTING

If you encounter issues with your Kircuit charger, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Device not charging/powering on.	Charger not properly connected. Power outlet is not active. Device is incompatible or damaged. Charger is damaged.	Ensure both ends of the charger are firmly connected. Test the power outlet with another device. Verify device compatibility with charger specifications. If suspected damage, discontinue use and replace.
Charger feels warm during use.	Normal operation. Overload or poor ventilation.	A slight warmth is normal. Ensure the charger is in a well-ventilated area. If it becomes excessively hot, disconnect immediately.

7. SPECIFICATIONS

Feature	Specification
Brand	Kircuit
Input Voltage	100V-240V AC
Input Frequency	50/60Hz
Output	Compatible with Innoo Tech 4-in-1 Portable Bluetooth Karaoke Power Supply requirements.
Special Feature	Portable, Travel
Power Source	Corded Electric
Item Weight	8 Ounces
Main Power Connector Type	2 Pin (US Standard)
Cord Length	Approximately 6.5 ft (2 meters)

8. WARRANTY AND SUPPORT

Kircuit products are designed for reliability and performance. This charger comes with a **3-year warranty** against manufacturing defects. For warranty claims or technical support, please refer to the contact information provided with your purchase or visit the official Kircuit website.



Figure 7: 3-Year Warranty. This image indicates the product's warranty period.