

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [MOJOGEAR](#) /

› [MOJOGEAR 177cm 2-in-1 Tripod - Tripod + Monopod with Premium Phone Holder - Aluminum, 3-Way Ball Head, Quick Release Plate, Bag, for DSLR Camera, Smartphone Video SAB264 177 cm](#)

MOJOGEAR MG-35-T

MOJOGEAR 177cm 2-in-1 Tripod

USER MANUAL

This manual provides comprehensive instructions for the MOJOGEAR 177cm 2-in-1 Tripod, featuring a detachable monopod, 3-way ball head, and premium phone holder. Please read carefully before use.

1. SAFETY INFORMATION

- Do not exceed the maximum load capacity of 4 kg.
- Ensure all locks and adjustments are securely tightened before use to prevent equipment damage.
- Keep the tripod away from extreme temperatures, moisture, and corrosive substances.
- Do not leave the tripod unattended in windy conditions, especially with equipment mounted.
- Keep out of reach of children.

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- MOJOGEAR 177cm 2-in-1 Tripod (with detachable monopod)
- Premium Phone Holder with Cold Shoe Mount
- Quick Release Plate
- Carry Bag

3. PRODUCT OVERVIEW

Familiarize yourself with the main components of your MOJOGEAR tripod.



Figure 3.1: Overview of the MOJOGEAR 2-in-1 Tripod, demonstrating its versatility as both a tripod and a monopod, along with the included phone holder.





Figure 3.2: The MOJOGEAR Tripod in its compact, folded state, highlighting the integrated carry handle for easy transport.






Figure 3.3: A detailed view of the premium phone holder, designed to securely grip smartphones.







Figure 3.4: The tripod shown with a DSLR camera mounted, demonstrating its compatibility with professional camera equipment.



Figure 3.5: The phone holder in use with a smartphone, featuring an attached LED light via the cold shoe mount, illustrating accessory integration.



Figure 3.6: The durable carry bag included with the tripod, providing convenient storage and transport.



Figure 3.7: A visual representation of the monopod's adjustable height, ranging from 45cm to 165cm.



Figure 3.8: A close-up view of the tripod head, illustrating its ability to tilt for various shooting angles.

4. SETUP INSTRUCTIONS

4.1 Unfolding the Tripod

1. Place the tripod on a flat, stable surface.
2. Release the leg locks on each leg and extend them outwards until fully spread.
3. Adjust the leg sections to your desired height by opening the flip locks, extending the sections, and then closing the locks securely.

4.2 Attaching the Quick Release Plate

1. Locate the quick release plate on the tripod head.
2. Press the release lever or button to detach the plate from the tripod head.
3. Screw the quick release plate onto the bottom of your camera or the phone holder using the 1/4-inch screw. Ensure it is tightened firmly.
4. Slide the quick release plate with your device back into the tripod head until it clicks securely into place.

4.3 Converting to Monopod

1. Identify the central leg of the tripod, which is designed to detach.
2. Unscrew the central column from the tripod body.
3. The detached central column can now be used as a standalone monopod. You can attach the tripod head or directly mount your camera/phone holder to its top screw.
4. Extend the monopod sections by opening the flip locks and securing them at your desired height (up to 165 cm).

5. OPERATING INSTRUCTIONS

5.1 Adjusting the 3-Way Pan/Tilt Head

- **Pan Adjustment:** Loosen the horizontal locking knob to rotate the head 360 degrees horizontally. Tighten to secure.
- **Tilt Adjustment:** Use the handle to tilt the camera up or down. Loosen the tilt locking knob to adjust the angle, then tighten to secure.
- **Portrait/Landscape Mode:** The quick release plate platform can be tilted 90 degrees for vertical shooting. Loosen the side knob, adjust, and tighten.

5.2 Using the Phone Holder

- Attach the phone holder to the quick release plate.
- Gently pull the spring-loaded top clamp of the phone holder upwards to insert your smartphone. Ensure it is securely seated.
- The phone holder features a cold shoe mount on top, allowing you to attach accessories like LED lights or microphones.

5.3 Leveling the Tripod

The tripod head includes an integrated bubble level. Adjust the tripod legs until the bubble is centered within the circle, indicating a perfectly level setup for your shots.

6. MAINTENANCE

- **Cleaning:** Wipe down the tripod with a soft, dry cloth after each use. For stubborn dirt, use a slightly damp cloth and mild soap, then dry thoroughly. Avoid harsh chemicals.
- **Storage:** Store the tripod in its carry bag in a cool, dry place, away from direct sunlight and extreme

temperatures.

- **Inspection:** Periodically check all screws, knobs, and leg locks for tightness. Ensure all moving parts operate smoothly. Do not force any components.

7. TROUBLESHOOTING

- **Tripod is unstable:** Ensure all leg sections are fully extended and their flip locks are securely closed. Verify that the quick release plate is properly seated and locked onto the head. Check the ground for unevenness.
- **Head movement is stiff:** Check if all locking knobs are fully loosened. If the issue persists, a small amount of silicone-based lubricant can be applied to moving parts, but avoid over-lubrication.
- **Camera/Phone not secure:** Ensure the quick release plate is tightly screwed onto your device. Confirm the quick release plate is fully inserted and locked into the tripod head.

8. SPECIFICATIONS

Feature	Specification
Brand	MOJOGEAR
Model Number	MG-35-T
Size	177 cm
Material	Aluminum
Weight Limit	4 Kilograms
Maximum Height	177 Centimeters
Monopod Extension	Up to 165 Centimeters
Item Dimensions (LxWxH)	56.3 x 9.8 x 9.8 cm
Package Dimensions (LxWxH)	60.4 x 12.2 x 11.8 cm
Package Weight	2.06 Kilograms
Compatible Devices	Smartphone, DSLR Camera, Compact Camera

9. WARRANTY AND SUPPORT

MOJOGEAR products are designed for durability and performance. For any questions, technical support, or warranty claims, please contact MOJOGEAR customer service through the retailer's platform or the official MOJOGEAR website. Please retain your proof of purchase for warranty validation.

Related Documents - MG-35-T

	<p><u>MOJOGEAR Multi Color Mini LED Light (MG-23) User Manual</u></p> <p>User manual for the MOJOGEAR Multi Color Mini LED Light (MG-23), providing instructions on operation, safety, specifications, and warranty for creators.</p>
	<p><u>MOJOGEAR Wireless Phone+Watch Manual and User Guide</u></p> <p>Official manual for the MOJOGEAR MG-PB9 Wireless Phone+Watch power bank, detailing features, specifications, LED indicators, activation, charging instructions, and important safety warnings for wireless and wired charging of smartphones, Apple Watch, and TWS earphones.</p>
	<p><u>MOJOGEAR Multi Color Mini LED Light (MG-23) User Manual and Specifications</u></p> <p>User manual and technical specifications for the MOJOGEAR Multi Color Mini LED Light (MG-23). Learn how to operate, troubleshoot, and understand the features of this portable LED light for photography and videography.</p>
	<p><u>MOJOGEAR Multi Color Mini LED Light User Manual</u></p> <p>User manual for the MOJOGEAR Multi Color Mini LED Light, detailing its features, operation, safety guidelines, and specifications. Ideal for smartphone filmmakers and mobile journalists.</p>
	<p><u>MOJOGEAR Charge+ 65W Fast Charger User Manual</u></p> <p>User manual for the MOJOGEAR Charge+ 65W GaN Fast Charger (MG-C01 PD-546). Provides instructions on how to use, box contents, technical specifications, safety guidelines, and company information. Supports multiple charging ports and fast charging up to 65W.</p>
	<p><u>MOJOGEAR Charge+ 65W Fast Charger User Manual (Model PD-546)</u></p> <p>User manual for the MOJOGEAR Charge+ 65W Fast Charger (Model PD-546), providing instructions on how to use, technical specifications, safety guidelines, and information about MOJOGEAR.</p>