Manuals+

Q & A | Deep Search | Upload

BoomPods BXRBLK

BoomPods BOOMBUDS XR Wireless Earbuds Instruction Manual

Model: BXRBLK

What's in the

Overview Box Setup Operating Maintenance Troubleshooting Specifications

Warranty & Support

1. PRODUCT OVERVIEW

The BoomPods BOOMBUDS XR are wireless in-ear earphones designed for active lifestyles. They feature Bluetooth 5.0 connectivity for stable audio transmission and an IPX7 waterproof rating, making them suitable for various environments including workouts and outdoor activities. The earbuds are engineered for a secure and comfortable fit, and offer customizable sound profiles.



Figure 1.1: BoomPods BOOMBUDS XR Earbuds and Charging Case. The image displays the black earbuds and their compact charging case, highlighting their sleek design.

2. WHAT'S IN THE BOX

Upon unboxing your BoomPods BOOMBUDS XR, verify that all the following components are included:

- BoomPods BOOMBUDS XR in-ear earphones (Left and Right)
- Charging case
- Micro USB charging cable
- Spare ear cups (multiple sizes for optimal fit)



Figure 2.1: BoomPods BOOMBUDS XR Retail Packaging. The image shows the product box, indicating the contents and key features like IPX7 waterproof rating and EQ settings.

3. SETUP GUIDE

3.1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The charging case provides approximately 20 hours of additional playback time, while the earbuds offer up to 4.5 hours on a single charge. A full charge takes approximately 1.5 hours.

- 1. Place the earbuds into their respective slots in the charging case. Ensure they are seated correctly for the charging contacts to align.
- 2. Connect the Micro USB charging cable to the charging port on the case and plug the other end into a USB power source (e.g., wall adapter, computer USB port).
- 3. Indicator lights on the case will show the charging status. Refer to the product's specific LED indicators for detailed information (not provided in source).



Figure 3.1: Charging Case with Earbuds. The image shows the open charging case with the earbuds placed inside, ready for charging.



Figure 3.2: Magnetic Case. This graphic illustrates the magnetic feature of the charging case, ensuring earbuds are securely held in place during charging and transport.

3.2. Pairing with a Device

The BOOMBUDS XR utilize Bluetooth 5.0 for a quick and stable connection.

- 1. Ensure the earbuds are charged and removed from the charging case. They should automatically enter pairing mode.
- 2. On your smartphone or Bluetooth-enabled device, navigate to the Bluetooth settings.
- 3. Search for available devices and select "BOOMBUDS XR" from the list.
- 4. Once connected, the earbuds will indicate successful pairing (e.g., an audio prompt or LED change).




Figure 3.3: Bluetooth 5.0 Connectivity. This graphic highlights the instant and secure connection provided by Bluetooth 5.0 technology.

3.3. Achieving the Perfect Fit

A proper fit is crucial for both comfort and optimal sound quality, especially for bass response and noise isolation. The BOOMBUDS XR come with multiple sizes of ear cups to ensure a secure fit for various ear shapes.

- 1. Experiment with the different sizes of ear cups provided.
- 2. Gently insert the earbud into your ear canal and twist slightly to secure it. The ergonomic design (Ergofit) helps keep them in place during activity.
- 3. Test the fit by moving your head and performing light activities. If the earbuds feel loose or the sound quality is poor, try a different size ear cup.



Figure 3.4: Ergofit Design. This graphic illustrates the ergonomic design of the earbuds, engineered for a secure and comfortable fit within the ear.

4. OPERATING INSTRUCTIONS

4.1. Music and Call Controls

The BOOMBUDS XR feature integrated controls on the earbuds for managing audio playback and calls. These controls include volume adjustment, play/pause, and track skipping.

Action	Control
Play/Pause	Double-click the earbud button.
Next Track	(Specific control not detailed in source, typically triple-click or long press)
Previous Track	(Specific control not detailed in source)
Volume Up	(Specific control not detailed in source, but volume control is present)

Action	Control
Volume Down	(Specific control not detailed in source, but volume control is present)
Answer/End Call	(Specific control not detailed in source)
Activate Voice Assistant (Siri/Google Assistant)	(Specific control not detailed in source)
Power Off	Hold button for five seconds.

Note: For detailed control gestures, refer to the full user manual provided with your product.

4.2. EQ Play Settings

The BOOMBUDS XR allow you to customize your listening experience with three distinct equalizer (EQ) settings:

- Bass Boost: Enhances low-frequency sounds for a more powerful bass.
- Vocal Boost: Optimizes mid-range frequencies to make vocals clearer and more prominent.
- BoomPods Studio: Provides a balanced sound profile, designed for general listening.

To switch between EQ settings, use the designated control on the earbuds (specific control not detailed in source).



Figure 4.1: EQ Play Settings. This graphic illustrates the three available equalizer settings for customized audio output.

5. CARE AND MAINTENANCE

5.1. Waterproofing (IPX7 Rating)

The BOOMBUDS XR are rated IPX7 waterproof, meaning they can withstand immersion in water up to 1 meter for 30 minutes. This makes them resistant to sweat, rain, and splashes, and suitable for use in

showers or by the pool.

Important Note: While the earbuds are waterproof, Bluetooth technology has limitations when transmitting through water. Therefore, continuous audio streaming underwater is not recommended as the connection may be interrupted.



Figure 5.1: IPX7 Waterproofing in Use. The image shows a person showering while wearing the earbuds, demonstrating their water-resistant capabilities.

5.2. Cleaning and Storage

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove the ear cups and clean them separately with mild soap and water if necessary. Ensure they are completely dry before reattaching.
- Avoid using abrasive cleaners, solvents, or aerosol sprays.
- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Keep the charging contacts on both the earbuds and the case clean and free of debris to ensure proper charging.

6. TROUBLESHOOTING

If you encounter issues with your BoomPods BOOMBUDS XR, refer to the following common troubleshooting steps:

Problem	Possible Cause / Solution
---------	---------------------------

Problem	Possible Cause / Solution
Earbuds not charging	 Ensure the charging cable is securely connected to both the case and the power source. Check if the silicone cover around the charging port is obstructing the cable connection. Clean the charging contacts on both the earbuds and inside the case. Try a different Micro USB cable or power adapter.
Earbuds not pairing / connecting	 Ensure Bluetooth is enabled on your device. Make sure the earbuds are out of the charging case and in pairing mode. Forget "BOOMBUDS XR" from your device's Bluetooth list and attempt to repair. Ensure the earbuds are sufficiently charged. Move the earbuds closer to your device.
Poor sound quality / Low volume	 Adjust the volume on both your device and the earbuds. Ensure the ear cups provide a secure and sealed fit in your ear. Try different sizes. Check the EQ settings (Bass Boost, Vocal Boost, BoomPods Studio) to see if a different setting improves sound. Clean any earwax or debris from the earbud nozzles.
Microphone issues / Call quality poor	 Ensure the earbuds are properly connected for calls. Avoid using the microphone in windy environments, as it may pick up excessive background noise. Ensure the microphone port on the earbuds is not obstructed.
Earbuds falling out	 Experiment with all provided ear cup sizes to find the most secure and comfortable fit. Ensure the earbuds are inserted correctly and twisted slightly to lock into place.

7. TECHNICAL SPECIFICATIONS

Feature	Detail
Model Name	BXRBLK
Connectivity Technology	Bluetooth 5, Wireless
Wireless Communication Technology	Bluetooth
Material	Silicone

Feature	Detail
Specific Uses For Product	Sports and Exercise, Studio
Charging Time	1.5 Hours
Compatible Devices	Smartphones
Control Type	Volume Control, Remote with Mic
Item Weight	48 Grams (1.69 ounces)
Water Resistance Level	IPX7 (Water Resistant)
Frequency Range	50Hz-15kHz
Battery Life (Earbuds)	4.5 Hours
Battery Life (with Charging Case)	Up to 20 Hours additional playback
Bluetooth Version	5.0
Special Features	Microphone Included, Sweatproof, USB connectivity, Volume Control, Ergonomic Design, EQ Play (3 settings)
Product Dimensions	0.2 x 3.11 x 1.34 inches
Manufacturer	Boompods
Color	Black
Ear Placement	In Ear
Form Factor	In Ear

8. WARRANTY AND SUPPORT

8.1. Limited Warranty

The BoomPods BOOMBUDS XR are covered by a **2-year limited warranty** from the date of purchase.

This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

For specific terms and conditions of the warranty, please refer to the warranty card included with your product or visit the official BoomPods website.

8.2. Customer Support

For further assistance, technical support, or warranty claims, please contact BoomPods customer service through their official channels. You can typically find contact information on the product packaging, the official BoomPods website, or the brand store on Amazon.

Visit the official **BoomPods Store on Amazon** for more product information and support resources.

Related Documents



Boombuds True Wireless Earphones User Manual | Boompods

User manual for Boombuds True Wireless Earphones by Boompods. Learn about setup, controls, pairing, charging, specifications, and warranty.



Boompods Soundwave: Sustainable True Wireless Earbuds User Guide

Learn about the Boompods Soundwave, sustainably made true wireless earbuds crafted from recycled ocean-bound plastic. This guide covers features, connectivity, touch controls, charging, and technical specifications.



BOOMPODS ECHOBUDS: Wireless Earbuds User Guide & Specifications

Comprehensive guide to BOOMPODS ECHOBUDS wireless earbuds, covering setup, connection, touch controls, reset procedures, and technical specifications. Learn how to pair, charge, and use your earbuds.



Boompods Skim True Wireless Earbuds: User Manual & Features

Discover the Boompods Skim, sustainably made true wireless earbuds. This guide covers setup, touch controls, battery, charging, technical specifications, and regulatory information.