



[Manuals.plus](#) /

> [ALLIMITY](#) /

> ALLIMITY CV98LM Remote Control Instruction Manual for Amazon Fire TV Stick/Box

ALLIMITY CV98LM

ALLIMITY CV98LM Remote Control Instruction Manual

For Amazon Fire TV Stick and Fire TV Box (without voice function)

1. INTRODUCTION

Thank you for choosing the ALLIMITY CV98LM Remote Control. This remote is designed as a replacement or secondary controller for your Amazon Fire TV Stick or Fire TV Box. Please note that this model **does not support voice control functionality**. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new remote control.



Image 1: ALLIMITY CV98LM Remote Control. This image shows the remote control from an angled perspective, highlighting its ergonomic design and button layout.

2. SAFETY INFORMATION

- Always use new alkaline AAA batteries and ensure they are inserted with the correct polarity (+/-).
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Keep the remote control away from water, direct sunlight, and extreme temperatures.

3. PACKAGE CONTENTS

- 1 x ALLIMITY CV98LM Remote Control
- *Note: Batteries are not included and must be purchased separately.*

4. SETUP AND PAIRING

4.1. Battery Installation

Open the battery compartment cover on the back of the remote control. Insert two (2) AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment. Close the battery cover securely.

4.2. Pairing with your Fire TV Device

Follow these steps to pair your ALLIMITY CV98LM remote control with your Amazon Fire TV Stick or Fire TV Box:

1. **Disconnect Power:** Unplug the power supply from your Amazon Fire TV Stick or Fire TV Box. Wait for a few seconds, then plug it back in.
2. **Initiate Pairing:** Once your Fire TV device has restarted, press and hold the **Home button** (the button with a house icon) on your ALLIMITY CV98LM remote control for **60 seconds or longer**. You may need to attempt this step multiple times.
3. **Confirm Pairing:** After holding the Home button, the remote should pair with your device. If successful, you will be able to navigate the Fire TV interface.
4. **Troubleshooting Pairing:** If the remote does not pair, try unplugging and replugging your Fire TV Stick/Box multiple times before repeating the pairing process. Ensure the remote is within close proximity to the Fire TV device during pairing.



Image 2: Pairing Instructions for ALLIMITY CV98LM Remote. This image illustrates the remote control with arrows pointing

to the Home and Play buttons, detailing the steps for pairing, including disconnecting power, holding the Home key for over 60 seconds, and then pressing the Play key. It also provides a warning about using new alkaline batteries.

5. OPERATING THE REMOTE CONTROL

The ALLIMITY CV98LM remote control provides standard navigation and media playback functions for your Fire TV device:

- **Navigation Ring:** Use the circular ring to move Up, Down, Left, and Right within menus.
- **Select Button:** The center button within the navigation ring confirms selections.
- **Back Button:** (Curved arrow icon) Returns to the previous screen or menu.
- **Home Button:** (House icon) Returns to the Fire TV home screen.
- **Menu Button:** (Three horizontal lines icon) Opens context-sensitive menus or options.
- **Play/Pause Button:** (Play/Pause icon) Controls media playback.
- **Fast Forward Button:** (Double arrow pointing right) Skips forward in media.
- **Rewind Button:** (Double arrow pointing left) Skips backward in media.

6. MAINTENANCE

6.1. Battery Replacement

When the remote control's performance degrades or it stops responding, it is time to replace the batteries. Follow the battery installation steps in Section 4.1, ensuring to use two new AAA alkaline batteries.

6.2. Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, aerosols, or abrasive materials, as these can damage the remote's surface or internal components.

7. TROUBLESHOOTING

- **Remote not responding:**
 - Ensure batteries are correctly inserted and are not depleted. Replace with new AAA alkaline batteries if necessary.
 - Verify there are no obstructions between the remote and your Fire TV device.
 - Re-attempt the pairing process as described in Section 4.2. Sometimes, unplugging and replugging the Fire TV device multiple times can help.
- **Intermittent connectivity:**
 - Ensure the remote is within the maximum operating range (up to 10 meters).
 - Check for potential interference from other electronic devices.
- **No voice control:**
 - This remote model (CV98LM) does not support voice functionality. This is a design feature, not a malfunction.

If you continue to experience issues after following these troubleshooting steps, please refer to the support section for further assistance.

8. SPECIFICATIONS

| Feature | Specification |
|---------------------------|-----------------------------------|
| Brand | ALLIMITY |
| Model Name | CV98LM |
| Product Dimensions | 10 x 5 x 1 cm |
| Weight | 40 g |
| Connectivity Technology | Infrared |
| Compatible Devices | Amazon Fire TV Stick, Fire TV Box |
| Maximum Supported Devices | 1 |
| Number of Buttons | 15 |
| Controller Type | Push Button Control |
| Maximum Range | 10 Meters |
| Batteries Required | 2 x AAA (Alkaline recommended) |
| Special Feature | Ergonomic Design |
| Color | Black |

9. WARRANTY INFORMATION

Specific warranty information for the ALLIMITY CV98LM remote control is not provided in the product details. Please retain your proof of purchase and contact your retailer or the manufacturer directly for any warranty-related inquiries.

10. CUSTOMER SUPPORT

For further assistance, technical support, or to report any issues not covered in this manual, please refer to the ALLIMITY manufacturer's official website or contact their customer service department. Contact details are typically available on the product packaging or the seller's platform.