

Belaco BSVC135

Belaco BSVC135 700W 2-in-1 Upright and Handheld Bagless Vacuum Cleaner User Manual

Model: BSVC135

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this appliance and retain them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

General Safety

- This appliance is intended for domestic use only. Do not use outdoors or on wet surfaces.
- Do not allow children to operate the vacuum cleaner. Close supervision is necessary when used near children.
- Do not pick up flammable or combustible materials (lighter fluid, gasoline, kerosene, etc.) or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without the dust tank and filters properly in place.
- Do not use the appliance if it has been dropped, damaged, left outdoors, or dropped into water.
- Always unplug the appliance before cleaning or performing maintenance.

Electrical Safety

- Check that the voltage indicated on the rating label corresponds with the mains voltage in your home.
- Do not handle the plug or appliance with wet hands.
- Do not pull the power cord to unplug the appliance; grasp the plug, not the cord.
- Keep the power cord away from heated surfaces.
- Do not use with a damaged cord or plug. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

2. PRODUCT OVERVIEW AND PARTS IDENTIFICATION

The Belaco BSVC135 is a versatile 2-in-1 vacuum cleaner designed for both upright floor cleaning and handheld spot cleaning. It features a powerful 700W motor and a washable HEPA filter for efficient dust collection.

Parts Identifications




Image Description: A detailed diagram illustrating the various components of the Belaco BSVC135 vacuum cleaner, each numbered for easy identification. Key parts include the handle, power cable hook, aluminum tube, tube latch, On/Off switch, dust tank release button, vacuum head, main unit, HEPA filter, and dust tank.

Parts List:

1. Handle
2. Power Cable Hook
3. Aluminum Tube (Extension Wand)
4. Tube Latch
5. On/Off Switch
6. Dust Tank Release Button
7. Vacuum Head (Floor Nozzle)
8. Main Unit (Motor Housing)
9. HEPA Filter
10. Dust Tank

Included Accessories:

- Crevice Tool: For reaching narrow gaps and corners.
- Dusting Brush: For cleaning delicate surfaces and upholstery.
- Suction Inlet Rubber Flap: (Likely part of the main unit or an attachment for specific suction control).

3. ASSEMBLY AND SETUP

The Belaco BSVC135 can be assembled in two configurations: as an upright stick vacuum or as a handheld vacuum.



Image Description: The Belaco BSVC135 vacuum cleaner shown fully assembled in its upright configuration, alongside a collection of its included cleaning attachments. This image demonstrates the complete product package.

Assembling the Upright Vacuum:

1. **Attach the Vacuum Head:** Align the vacuum head (7) with the main unit (8) and push firmly until it clicks into place.
2. **Insert the Aluminum Tube:** Insert the aluminum tube (3) into the opening on the main unit (8) until it is securely seated.
3. **Attach the Handle:** Slide the handle (1) onto the top of the aluminum tube (3) until it locks. Ensure the power cable hook (2) is facing the correct direction for cable management.
4. **Secure the Power Cable:** Wrap the power cable around the power cable hook (2) and the hook on the main unit to keep it tidy.

Converting to Handheld Vacuum:

1. **Remove the Handle and Tube:** Press the tube latch (4) and pull the handle (1) and aluminum tube (3) away from the main unit (8).

2. **Attach Accessories (Optional):** You can directly attach the crevice tool or dusting brush to the main unit's suction inlet for handheld cleaning.

4. OPERATING INSTRUCTIONS

Powering On/Off:

- Plug the power cord into a suitable electrical outlet.
- Press the On/Off switch (5) located on the main unit to start the vacuum cleaner.
- Press the On/Off switch (5) again to turn off the vacuum cleaner.
- Always unplug the appliance from the power outlet after use.

Using as an Upright Vacuum:

For cleaning floors, carpets, and rugs, use the vacuum in its upright configuration with the vacuum head attached.



Image Description: The Belaco BSV135 vacuum cleaner is depicted in its upright configuration, actively cleaning a patterned rug in a modern living room setting. The image highlights its use for general floor cleaning.

- Ensure the vacuum is fully assembled in upright mode.
- Plug in the appliance and turn it on.
- Guide the vacuum head over the surface to be cleaned. The vacuum is suitable for hard floors, carpets, and rugs.
- The flexible design allows for easy maneuverability around furniture.

Using as a Handheld Vacuum:

For cleaning upholstery, car interiors, stairs, or hard-to-reach areas, convert the vacuum to handheld mode.



Image Description: The Belaco BSVC135 vacuum cleaner is shown in its handheld configuration, effectively cleaning the surface of a white upholstered sofa. This demonstrates its utility for targeted cleaning tasks.

- Convert the vacuum to handheld mode as described in the "Assembly and Setup" section.
- Attach the desired accessory (crevice tool for tight spaces, dusting brush for delicate surfaces).
- Plug in the appliance and turn it on.
- Direct the accessory to the area requiring cleaning.

5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner. Always unplug the appliance before performing any maintenance.

Emptying the Dust Tank:

1. Ensure the vacuum cleaner is turned off and unplugged.
2. Press the dust tank release button (6) to detach the dust tank (10) from the main unit.
3. Position the dust tank over a waste bin.
4. Open the bottom flap of the dust tank (one-key to empty dust) and shake out the collected debris.

5. Close the flap and reattach the dust tank to the main unit, ensuring it clicks securely into place.

Cleaning the HEPA Filter:

The 2-layer HEPA filter (9) is washable and should be cleaned regularly to maintain suction power.



Image Description: A close-up view of the Belaco BSVC135 HEPA filter being cleaned under running water, illustrating the washable feature of the filter for easy maintenance.

1. Ensure the vacuum cleaner is turned off and unplugged.
2. Remove the dust tank (10) as described above.
3. Carefully remove the HEPA filter (9) from the dust tank.
4. Rinse the HEPA filter under cool running water until the water runs clear. Do not use detergents or hot water.
5. Allow the filter to air dry completely for at least 24 hours before reinserting it. Do not use a hairdryer or other heating devices.
6. Once completely dry, place the HEPA filter back into the dust tank and reattach the dust tank to the main unit.

Note: Replace the HEPA filter if it becomes damaged or if suction power significantly decreases even after cleaning.

6. TROUBLESHOOTING

Before contacting customer support, please refer to the following troubleshooting guide for common issues.

Problem	Possible Cause	Solution
Vacuum does not turn on.	Not plugged in; power outlet fault; On/Off switch not pressed.	Check power cord connection; test outlet with another appliance; press On/Off switch firmly.
Low suction power.	Full dust tank; clogged filter; blockage in nozzle/tube.	Empty dust tank; clean HEPA filter; check for and remove any blockages.
Vacuum overheats and shuts off.	Clogged filter; blocked air vents; prolonged use.	Turn off and unplug. Allow to cool for at least 30 minutes. Clean HEPA filter and check for blockages in air vents. Avoid prolonged continuous use.
Unusual noise during operation.	Blockage in the vacuum head or tube; loose part.	Turn off and unplug. Inspect vacuum head and tube for foreign objects. Ensure all parts are securely assembled.

7. SPECIFICATIONS

Technical details for the Belaco BSVC135 vacuum cleaner.

Model Number	BSVC135
Power	700 Watts
Voltage	220 Volts
Dust Tank Capacity	1.2 Litres
Suction Power	130 Watts
Filter Type	2-layer Washable HEPA Filter
Noise Level	78-80 dB
Dimensions (L x W x H)	91 x 25 x 12 cm
Weight	1.81 Kilograms
Usage Function	Dry
Recommended Surface	Hard floor, carpet, sofa

8. WARRANTY AND SUPPORT

Belaco products are manufactured to high-quality standards. For any warranty claims, technical support, or inquiries regarding spare parts, please contact your retailer or the official Belaco customer service. Please retain your proof of purchase for warranty purposes.

Information regarding the availability of specific spare parts is not provided in this manual. Please consult your point of purchase or the manufacturer's website for further details.