

Navaris 49922.02.01

Navaris Double Induction Cooktop Instruction Manual

MODEL: 49922.02.01

Introduction

This manual provides essential information for the safe and efficient operation of your Navaris Double Induction Cooktop. Please read these instructions carefully before use and retain them for future reference.

The Navaris Double Induction Cooktop offers practical and efficient cooking with precise temperature settings from 60°C to 240°C. It features two cooking zones with a total power of 3500W (left zone max 2000W, right zone max 1500W). Key features include a timer (1-180 minutes), child lock, and automatic pot detection for safety and energy efficiency.

Important Safety Instructions

Please observe the following safety precautions to prevent injury or damage to the appliance.

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.

- Do not use appliance for other than intended use.
- This appliance is designed for induction-compatible cookware with a magnetic base. Cookware diameter should be between 12 cm and 26 cm.
- An E01 error code indicates that no cookware is detected or the cookware used is not suitable.
- The appliance features a child lock function to prevent accidental operation.
- The cooktop has an automatic shutdown function after two hours of inactivity for safety and energy saving.

Product Components

The Navaris Double Induction Cooktop includes:

- 1 x Double Induction Cooktop Unit

Setup

Follow these steps to set up your induction cooktop:

1. **Unpacking:** Carefully remove the cooktop from its packaging. Retain packaging for future transport or storage.
2. **Placement:** Place the cooktop on a stable, flat, heat-resistant surface. Ensure there is adequate ventilation around the unit. Do not place it near heat sources or flammable materials.
3. **Power Connection:** Plug the power cord into a standard electrical outlet. Ensure the outlet voltage matches the appliance's requirements. The cable length is approximately 1 meter.
4. **Cookware Check:** Ensure your cookware is induction-compatible. Induction cookware has a magnetic base. Test with a magnet; if it sticks to the bottom of the pot/pan, it is compatible. Suitable diameters for cookware are between 12 cm (4.7 inches) and 26 cm (10.2 inches).



Figure 1: Cookware Compatibility. This image illustrates which types of cookware are compatible with induction cooktops (cast iron, enamelled cast iron, stainless steel) and which are not (aluminum, ceramic, copper, glass). It also shows how to test for compatibility using a magnet and explains that an E01 error indicates incompatible or missing cookware. The suitable diameter for cookware is between 12 cm and 26 cm.



Pot/Pan Ø 12-26cm



Figure 2: Product Dimensions. This image displays the physical dimensions of the cooktop: 59 cm (length) x 37 cm (width) x 7.5 cm (height). The power cable length is 1 meter. It also reiterates the suitable pot/pan diameter range of 12-26 cm.




Figure 3: How Induction Works. This diagram explains the principle of induction cooking, where heat is generated directly within the induction-compatible pot, leading to energy savings and up to 60% faster cooking compared to traditional methods.

Operating Instructions

Your Navaris Double Induction Cooktop features intuitive touch controls for easy operation.

1. **Power On/Off:** Press the **ON/OFF** button to turn the cooktop on or off. The display will illuminate.
2. **Selecting a Cooking Zone:** Each cooking zone has its own set of controls. Select the desired zone by touching its corresponding control panel.
3. **Adjusting Power/Temperature:** Use the **UP** and **DOWN** arrows to adjust the power level or temperature. The temperature range is 60°C to 240°C. The left zone has a maximum power of 2000W, and the right zone has a maximum of 1500W. There are 10 heating levels available.
4. **Timer Function:** Press the **TIMER** button to activate the timer. Use the **UP** and **DOWN** arrows to set the cooking time between 1 and 180 minutes. Once the set time expires, the cooktop will automatically turn off.
5. **Child Lock:** To activate the child lock, press the **LOCK** button. This prevents accidental changes to settings or turning the unit on/off. Press the **LOCK** button again to deactivate.
6. **Automatic Pot Detection:** The cooktop automatically detects if a suitable pot is placed on the cooking zone. If no pot is detected or an incompatible pot is used, an E01 error will be displayed, and the cooktop will not heat.
7. **Automatic Shutdown:** For safety and energy efficiency, the cooktop will automatically shut down after two hours if no operation is detected.



Figure 4: Control Panel Features. This image details the touch control panel, showing the Lock button for child safety, the Timer function adjustable from 1 to 180 minutes, the 10 heating levels for precise cooking, and the automatic switch-off feature.

ENERGY EFFICIENT

With an automatic pot/pan detection and an automatic shutdown function after two hours, save time, money and energy when preparing delicious meals.



Figure 5: Energy Efficient Operation. The cooktop is shown in use with two pots, demonstrating its energy-efficient design with automatic pot/pan detection and an automatic shutdown function after two hours of inactivity.



Figure 6: Navaris Double Induction Cooktop. A clear view of the cooktop's design and layout.



Figure 7: Cooking in Progress. A close-up view of food being cooked on one of the induction zones, demonstrating the cooktop in active use with the digital display showing the power setting.

Maintenance and Cleaning

Proper maintenance ensures the longevity and performance of your cooktop.

1. **Cleaning the Surface:** After each use, allow the cooktop to cool completely. Wipe the glass-ceramic surface with a soft, damp cloth and mild detergent. For stubborn stains, use a specialized ceramic hob cleaner. Avoid abrasive cleaners, scouring pads, or harsh chemicals.
2. **Control Panel:** Wipe the control panel with a soft, dry cloth. Do not use excessive water.
3. **Ventilation Openings:** Ensure the ventilation openings on the underside and sides of the unit are free from dust and debris. Use a soft brush or vacuum cleaner to gently clean them.
4. **Storage:** If storing the cooktop for an extended period, ensure it is clean and dry. Store it in a cool, dry place, preferably in its original packaging.

Troubleshooting

This section addresses common issues you might encounter.

Problem	Possible Cause	Solution
Cooktop does not turn on.	No power supply. Power cord not properly plugged in.	Check if the power cord is securely plugged into a working outlet. Check your household circuit breaker.
"E01" error displayed.	No cookware detected. Cookware is not induction-compatible. Cookware diameter is too small or too large.	Place an induction-compatible pot/pan on the cooking zone. Ensure the cookware has a magnetic base. Use cookware with a diameter between 12 cm and 26 cm.
Cooktop stops heating during operation.	Overheating protection activated. Automatic shutdown after 2 hours.	Remove the pot, turn off the cooktop, and allow it to cool down. Resume operation after a few minutes. This is a safety feature. Restart the cooktop if you wish to continue cooking.
Unusual noise during operation.	Normal fan noise for cooling. Some induction-compatible cookware may produce a slight hum.	This is usually normal. If the noise is excessively loud or unusual, contact customer support.

Technical Specifications

Feature	Detail
Model Number	49922.02.01
Brand	Navaris
Power Source	Electric
Total Power	3500 Watts
Left Heating Element Power	Max 2000 Watts
Right Heating Element Power	Max 1500 Watts
Number of Heating Elements	2
Control Type	Touch (Sensitif)
Burner Type	Induction
Temperature Range	60°C to 240°C
Timer Range	1 to 180 minutes
Cookware Diameter	12 cm to 26 cm
Material	Glass

Feature	Detail
Color	Black
Product Dimensions (L x W x H)	59 x 37 x 7.5 cm (23.2 x 14.6 x 3 inches)
Item Weight	4.34 kg (9.57 lbs)
Special Features	2 cooking zones, Automatic shutdown, Temperature control, Automatic pot detection, Child lock

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Navaris website. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question