

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Ikea](#) /

> [IKEA Navlinge LED Work Lamp 004.049.25 User Manual](#)

## Ikea Navlinge 004.049.25

# IKEA Navlinge LED Work Lamp 004.049.25 User Manual

Model: Navlinge 004.049.25

## INTRODUCTION

---

Thank you for choosing the IKEA Navlinge LED Work Lamp. This manual provides essential information for the safe and efficient use of your new lamp. The Navlinge lamp is designed to provide directional light, ideal for focused tasks such as reading or working. Its adjustable arm and head allow you to easily direct the light where it is needed most. Featuring an integrated LED light source, this lamp offers significant energy savings and a long operational lifetime.

## SAFETY INFORMATION

---

- Always disconnect the lamp from the power supply before cleaning or performing any maintenance.
- Do not use the lamp in wet or damp environments. This lamp is intended for indoor use only.
- Ensure the power cord is not damaged or pinched. Do not place heavy objects on the cord.
- Keep the lamp away from heat sources and direct sunlight to prevent damage.
- The LED light source is pre-mounted. While replaceable as a spare part, do not attempt to replace it yourself unless you have the correct spare part and instructions from IKEA. Contact IKEA customer services for assistance.
- This product is not a toy. Keep out of reach of children.

## PACKAGE CONTENTS

---

Please check the package to ensure all components are present:

- IKEA Navlinge LED Work Lamp unit (with integrated LED light source)
- Power cord with plug

## SETUP

---

1. **Unpack the Lamp:** Carefully remove all components from the packaging.
2. **Position the Lamp:** Place the lamp base on a stable, flat surface such as a desk or table. Ensure there is

enough space for the lamp arm to be adjusted freely.

3. **Connect to Power:** Insert the power plug into a suitable wall outlet.



Image 1: The IKEA Navlinge LED Work Lamp positioned on a desk, ready for use.

## OPERATING INSTRUCTIONS

1. **Turning On/Off:** Locate the push-button switch on the lamp base or cord (depending on model variation). Press the button once to turn the lamp on, and press it again to turn it off.
2. **Adjusting the Light:** The lamp features an adjustable arm and head. Gently bend the flexible arm to position the light source as desired. The lamp head can also be angled to direct the light beam.



Image 2: A close-up of the lamp head, highlighting the integrated LED light source and its directional design.

## MAINTENANCE

- **Cleaning:** Disconnect the lamp from the power supply. Wipe the lamp clean with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the finish.
- **LED Light Source:** The LED light source in this lamp is designed for a long lifespan (approximately 25,000 hours). If replacement becomes necessary, contact IKEA customer services. The LED module is available as a spare part and should only be replaced according to IKEA's instructions.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	No power supply. Faulty power outlet. Lamp switch is off.	Ensure the power plug is fully inserted into a working outlet. Test the outlet with another device. Press the lamp's power button to turn it on.
Light flickers.	Unstable power supply. Internal component issue.	Try plugging the lamp into a different power outlet. If flickering persists, discontinue use and contact IKEA customer services.
Lamp head/arm does not stay in position.	Wear and tear on adjustable mechanism.	The flexible arm is designed for repeated adjustments. If it loses its ability to hold position, contact IKEA customer services for possible solutions or spare parts.

## SPECIFICATIONS

<b>Model Name</b>	Navlinge LED Work Lamp
<b>Model Number</b>	004.049.25
<b>Brand</b>	IKEA
<b>Lamp Type</b>	LED (Light Emitting Diode)
<b>Power Consumption</b>	1.9 W
<b>Luminous Flux</b>	220 Lumen
<b>Light Color</b>	Warm White (2700 Kelvin)
<b>Estimated Life</b>	Approx. 25,000 hours
<b>Product Dimensions (D x W x H)</b>	50.8D x 50.8W x 66H Centimetres
<b>Cord Length</b>	6' 7" (approximately 2 meters)
<b>Shade Material</b>	Polycarbonate plastic
<b>Base Material</b>	ABS plastic, EVA plastic
<b>Tube Material</b>	Steel, Powder coating
<b>Switch Type</b>	Push Button
<b>Batteries Required</b>	No
<b>Intended Use</b>	Reading, focused lighting

## WARRANTY AND SUPPORT

For information regarding warranty, spare parts, or any other support needs, please contact IKEA customer services. You can find contact details on the official IKEA website ([www.ikea.com](http://www.ikea.com)) or by visiting your local IKEA store.

Please retain your proof of purchase for any warranty claims.