

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Ikea](#) /

› [IKEA Navlinge LED Clamp Spotlight User Manual](#)

Ikea 204.498.95

IKEA Navlinge LED Clamp Spotlight User Manual

Model: 204.498.95

INTRODUCTION

This manual provides essential information for the safe and efficient use of your IKEA Navlinge LED Clamp Spotlight. Please read these instructions carefully before installation and operation, and retain them for future reference.



Image: The IKEA Navlinge LED Clamp Spotlight, featuring its adjustable head and clamp mechanism, shown in white.

SAFETY INFORMATION

- Always disconnect the power before cleaning or maintenance.
- Do not use if the cord or plug is damaged.
- Ensure the clamp is securely fastened to a stable surface.

- For indoor use only.
- The light source is built-in LED and can be replaced by qualified personnel if needed. Contact IKEA customer services for spare parts.

SETUP

1. **Unpack:** Carefully remove all components from the packaging. Ensure all parts are present: lamp unit with clamp, power cord.
2. **Choose Location:** Select a suitable surface for clamping. The clamping range is $\frac{1}{3}$ - $1\frac{3}{4}$ inches (approximately 0.85 cm - 4.45 cm).
3. **Attach Lamp:** Open the clamp and firmly attach it to the desired surface. Ensure the clamp is stable and the lamp is secure.
4. **Connect Power:** Plug the power cord into a standard electrical outlet.

OPERATING INSTRUCTIONS

- **Turning On/Off:** The lamp is equipped with a touch switch. Tap the switch to turn the lamp on or off.
- **Adjusting Light Direction:** The lamp arm and head are adjustable. Gently bend the flexible joint and pivot the lamp head to direct the light as desired.

MAINTENANCE

- **Cleaning:** Wipe the lamp with a damp cloth. Use a mild detergent if necessary. Do not use abrasive cleaners or solvents.
- **Light Source Replacement:** The LED light source is built-in. While designed for long life (approx. 25,000 hours), it can be replaced if needed. Contact IKEA customer services for assistance and spare parts. Do not attempt to replace the LED module yourself unless you are qualified.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	No power supply.	Check if the power cord is securely plugged into the outlet. Test the outlet with another device.
Lamp flickers.	Loose connection or faulty power supply.	Ensure the power cord is fully inserted. Try a different outlet. If the problem persists, contact IKEA customer service.
Light output is dim.	Normal wear of LED or dust accumulation.	Clean the lamp head and optical lens. If the lamp is old, the LED may be nearing the end of its lifespan.

SPECIFICATIONS

Model Number	204.498.95
Brand	IKEA
Light Source	Built-in LED

Luminous Flux	220 Lumen
Color Temperature	Warm white (2700 Kelvin)
Power Consumption	1.9 W
Estimated Life	Approx. 25,000 hours
Cord Length	6' 7" (2 meters)
Clamping Range	1/3-1 3/4" (0.85 cm - 4.45 cm)
Materials	Clamp/Shade/Optical lens: Polycarbonate plastic; Flexi joint: Steel, Synthetic rubber
Item Weight	0.35 Kilograms
Switch Type	Touch

WARRANTY AND SUPPORT

For information regarding warranty, spare parts, or customer support, please contact IKEA customer services. You can find contact details at your local IKEA store or on the official IKEA website: [IKEA.com](https://www.ikea.com).

The light bulb is pre-mounted but can be replaced when needed. Available as a spare part. For more information, contact IKEA customer services.

© 2026 IKEA. All rights reserved. Model: 204.498.95