

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Beeasy](#) /

> [Beeasy Digital Watch AW02 User Manual](#)

Beeasy AW02

Beeasy Digital Watch User Manual

MODEL: AW02

Brand: Beeasy

1. Product Overview

The Beeasy Digital Watch (Model AW02) is an ultra-thin, versatile timepiece designed for daily wear and active lifestyles. It features a casual and simple dial design with a super wide-angle display for easy readability. This watch is equipped with multiple functions including dual time zones, alarms, stopwatch, and countdown timer, all within a durable, water-resistant casing.



Front view of the Beeasy Digital Watch, showcasing its clear digital display and sleek design.

Key Features:

- **Ultra-thin Design:** Only 6.6mm case thickness for comfortable daily wear.
- **Backlit Display:** Supports backlighting for visibility in low-light conditions.
- **Multi-functional:** Dual time zone, 12/24 hours switch, automatic calendar, alarm clock (hourly and daily).
- **Timing Functions:** 1/100 second stopwatch and countdown timer (max 23 hours, 59 minutes, 59 seconds).
- **Water Resistance:** Water resistant to 50M / 164FT, suitable for swimming in shallow water and cold showering.



12/24H



Auto calendar



Baklight



2 Time



Alarm Mode



Stopwatch



Countdown




Split Time



Dual Time



Alarm Mode



Stopwatch/Countdown Split Time



Visual representation of the watch's key features including dual time, alarm mode, stopwatch, countdown, and split time.

2. Setup

Setting Time and Date:

To ensure accurate timekeeping, follow these steps to set the correct time and date on your Beeasy Digital Watch. This process involves using the watch's buttons to navigate through settings and adjust values.

Official video guide demonstrating how to set the correct date and time on the Beeasy Digital Watch. This video shows the sequence of button presses to adjust hours, minutes, year, month, and day.

General Steps for Time/Date Adjustment:

1. Press and hold the 'RESET' button for 3 seconds to enter setting mode. The seconds display will start flashing.
2. Press the 'ST/STOP' button to adjust the seconds to zero.
3. Press the 'MODE' button to cycle through the setting options (hours, minutes, year, month, date).
4. Use the 'ST/STOP' button to adjust the flashing value for each setting.
5. Once all settings are correct, press the 'RESET' button to save and exit the setting mode.

3. Operating Modes

Your Beeasy Digital Watch offers several operating modes accessible via the 'MODE' button. Press 'MODE' repeatedly to cycle through the different functions.

Time Mode:

This is the default display mode, showing the current time (hours, minutes, seconds), day of the week, and date. You can switch between 12-hour and 24-hour formats.

Alarm Mode:

Set daily alarms to remind you of important events. The watch also supports an hourly alarm function.

Stopwatch Mode:

Use the 1/100 second stopwatch for precise timing. Press 'ST/STOP' to start/stop and 'RESET' to clear.

Countdown Timer Mode:

Set a countdown timer for up to 23 hours, 59 minutes, and 59 seconds. Ideal for tracking tasks or workouts.

Official video showcasing the alarm and countdown features of the Beeasy Digital Watch.

Dual Time Mode:

Keep track of time in two different time zones simultaneously, useful for travelers or those with international contacts.

Backlight Function:

Press the 'LIGHT' button to illuminate the display for easy reading in dark environments.

4. Maintenance

Proper care will extend the life and maintain the functionality of your Beeasy Digital Watch.

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and mild soap, then dry thoroughly.
- **Water Resistance:** While water resistant to 50M, avoid exposing the watch to hot water and steam (e.g., hot showers, saunas) as this can compromise the seals. It is not suitable for long-time underwater activities such as diving.
- **Battery:** The watch uses 1 Lithium Metal battery. Battery replacement should ideally be performed by a qualified technician to ensure water resistance is maintained.
- **Storage:** When not in use for extended periods, store the watch in a cool, dry place away from direct sunlight and extreme temperatures.

5. Troubleshooting

If you encounter any issues with your Beeasy Digital Watch, please refer to the following common troubleshooting tips:

- **Display is Blank or Faint:** The battery may be low or depleted. Replace the battery.
- **Buttons Unresponsive:** Ensure the watch is not in a locked mode (if applicable, check manual for specific lock features). Try pressing buttons firmly. If unresponsive, a reset might be needed (refer to setup section for reset procedure, if available, or contact support).
- **Time is Inaccurate:** Re-set the time and date as per the 'Setting Time and Date' instructions. If inaccuracy persists, the battery may be weak.
- **Water Inside Display:** If condensation or water appears inside the display, stop using the watch immediately and contact customer support. This indicates a breach in water resistance.

For persistent issues not resolved by these steps, please contact Beeeasy customer support.

6. Specifications

Feature	Detail
Product Dimensions	9.65 x 1.73 x 0.26 inches
Weight	1.3 ounces
Model Number	AW02
Water Resistance	50M / 164FT
Battery Type	1 Lithium Metal battery (required)
Manufacturer	Beeeasy
Country of Origin	China

7. Warranty and Support

Beeeasy provides a **12-month guarantee** for your digital watch, allowing you to eliminate purchase concerns. We are committed to providing a satisfied solution within 24 hours for any problems you may encounter.

For support, inquiries, or to claim your warranty, please contact Beeeasy customer service through the platform where you purchased the product or visit the official Beeeasy store page.

Beeeasy Store: [Visit the Beeeasy Store on Amazon](#)

Related Documents - AW02



[NewTechWood Full Catalog: The Look of Wood Without the Work](#)

Comprehensive catalog of NewTechWood composite products including siding, decking, fencing, railings, interior wall panels, flooring, outdoor furniture, planters, and bird feeders. Features UltraShield® technology for durability and low maintenance.



[Certificado de Distribución de Productos - International Dreamlove S.A.U.](#)

Certificado emitido por International Dreamlove S.A.U. que autoriza a Candle Dropstore S.L. a revender productos, confirmando el cumplimiento de las directivas de materiales sanitarios de la UE y la distribución de marcas oficiales.



[Прайс-лист на оборудование и аксессуары](#)

Актуальный прайс-лист на спортивное оборудование и аксессуары, включая тренажеры, гантели, гири, мячи, эспандеры и многое другое. Действителен с 15.02.2019.