

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Bissell](#) /

› [BISSELL Power Steamer Heavy Duty 3-in-1 Steam Mop and Handheld SteamShot \(Model 2685A\) User Manual](#)

Bissell 2685A

BISSELL Power Steamer Heavy Duty 3-in-1 Steam Mop and Handheld SteamShot (Model 2685A) User Manual

INTRODUCTION

The BISSELL Power Steamer Heavy Duty 3-in-1 Steam Mop and Handheld SteamShot, Model 2685A, is a versatile cleaning appliance designed to utilize high-temperature steam for effective cleaning across various indoor and outdoor surfaces. This device functions as an upright steam mop, an extended reach steam cleaner, and a handheld steam cleaner, providing a chemical-free method to sanitize and remove dirt, grime, grease, and stains.

IMPORTANT SAFETY INFORMATION

Before operating this appliance, it is crucial to read and understand all safety instructions provided in the complete safety manual. Failure to do so may result in electric shock, fire, or serious injury. Always follow basic safety precautions to reduce the risk of injury when using an electrical appliance.

PRODUCT OVERVIEW AND COMPONENTS

The BISSELL Power Steamer 2685A is engineered for heavy-duty cleaning tasks. It offers three distinct cleaning configurations:

- **Upright Steam Mop:** For cleaning sealed hard floor surfaces.
- **Handheld Steam Cleaner:** For targeted cleaning of smaller areas, fixtures, and tight spaces.
- **Extended Reach Steam Cleaner:** Utilizes an extension wand for higher or harder-to-reach areas.

The unit includes 26 attachments to address a wide range of cleaning needs.



Image: The BISSELL Power Steamer shown in its three configurations: upright steam mop, extended reach, and handheld unit. A storage bag is also visible.

Includes 25 Accessories



Image: A comprehensive display of the BISSELL Power Steamer unit and its 25 included accessories, such as brushes, nozzles, and cleaning pads.

SETUP INSTRUCTIONS

1. **Unpacking:** Carefully remove all components from the packaging. Ensure all 26 attachments are present.
2. **Assembly:** The unit requires some assembly. Refer to the detailed assembly instructions in the full user guide for specific steps on connecting the handle, main body, and mop head.
3. **Filling the Water Tank:** Locate the water tank cap. Fill the 11.8 fluid ounce tank with distilled or demineralized water. Do not use cleaning solutions or scented products in the tank, as this can damage the unit. Securely close the cap.
4. **Attaching Accessories:** Select the appropriate attachment for your cleaning task and securely connect it to the handheld unit or extension wand as needed.

OPERATING INSTRUCTIONS

General Operation

- Plug the power cord into a grounded outlet. The unit operates on 110 Volts.
- Allow the unit to heat up. An indicator light will typically signal when the steam is ready.
- Use the variable steam modes and on-demand trigger to control the intensity and amount of steam released for optimal cleaning.

Using as an Upright Steam Mop

Attach the mop head and a clean mop pad. This mode is ideal for cleaning sealed hard floor surfaces such as tile, linoleum, and sealed hardwood. The steam mop is designed to kill 99.9% of germs and bacteria without chemicals.



**Kills 99.9% of germs,
bacteria & viruses¹**

Tested & proven to kill 99.9% of
Coronavirus & Influenza viruses¹

Image: The BISSELL Power Steamer in its upright steam mop configuration, actively cleaning a tiled floor with visible steam. An illustration of bacteria and viruses is shown to highlight its sanitizing capability.

Using as a Handheld Steam Cleaner

Detach the handheld unit from the main body. Select and attach the appropriate nozzle or brush for tasks such as cleaning grout, kitchen surfaces, bathroom fixtures, or auto interiors. The powerful steam helps loosen dirt, grime, and grease effectively.

Handheld Steam Cleaner

Loosens Dirt, Grime,
Grease and More



Image: The BISSELL Power Steamer handheld unit being used to clean a workbench, demonstrating its ability to loosen dirt, grime, and grease with steam.

Heavy-Duty Grade Machine For Indoor and Outdoor Use



Image: The BISSELL Power Steamer handheld unit with a brush attachment, cleaning a barbecue grill, illustrating its heavy-duty capability for indoor and outdoor use.

Using as an Extended Reach Steam Cleaner

Connect the extension wand to the handheld unit. This configuration is useful for cleaning windows, outdoor furniture, decks, or vehicle exteriors. The 25-foot power cord provides ample reach.

Extended Reach Steam Cleaner

with 25 ft. Power Cord & Extension Wand



Image: The BISSELL Power Steamer in its extended reach configuration, being used to clean a car wheel, highlighting its long power cord and extension wand.

MAINTENANCE

- **Emptying the Water Tank:** After each use, unplug the unit and allow it to cool. Empty any remaining water from the tank.
- **Cleaning Pads and Attachments:** Remove and clean all used mop pads and attachments. Most fabric pads are machine washable. Rinse plastic attachments with water.
- **Storage:** Store the unit in a dry, safe place. The included wall mount provides convenient storage. Ensure the unit is completely cool and dry before storing.
- **Descaling:** Periodically descale the unit according to the instructions in the full user manual to prevent mineral buildup, especially if using tap water.

TROUBLESHOOTING

If you encounter issues with your BISSELL Power Steamer, refer to the following common solutions:

- **No Steam:** Ensure the unit is properly plugged in and the water tank is filled. Allow sufficient time for heating. Check for any blockages in nozzles or hoses.

- **Low Steam Output:** This may indicate mineral buildup. Perform a descaling procedure as outlined in the full manual. Ensure attachments are securely fitted.
- **Water Leaking:** Check that the water tank cap is securely tightened and that all attachments are correctly installed.
- **Unit Not Turning On:** Verify the power cord is fully inserted into a working electrical outlet. Check the circuit breaker if necessary.

For more detailed troubleshooting or persistent issues, consult the comprehensive user manual or contact BISSELL customer support.

SPECIFICATIONS

Feature	Specification
Brand	Bissell
Model Name	BISSELL PowerSteamer Heavy Duty 3-in-1, 2685A
Special Feature	Steam on Demand Trigger, Multiple Attachments, Heavy Duty Construction
Surface Recommendation	Multiple Hard Surfaces
Cable Length	25 Feet
Included Components	26 Attachments
Wattage	1500 watts
Item Weight	6.13 Pounds
Tank Volume	11.8 Fluid Ounces
Product Dimensions	14"D x 9.5"W x 46.5"H
Form Factor	Handheld, Upright
Color	Black
Power Source	Corded Electric
Voltage	110 Volts
UPC	011120251876

WARRANTY AND SUPPORT

BISSELL offers various protection plans for this product. You may consider purchasing a 2-Year or 3-Year Protection Plan for extended coverage. For specific warranty details, product registration, or to contact customer support, please visit the official BISSELL website or refer to the documentation included with your product.

You can also find additional resources and support by visiting the [Bissell Store on Amazon](#).

