

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SelfieShow](#) /

› [SelfieShow Selfie Stick Tripod User Manual](#)

SelfieShow Q01

SelfieShow Selfie Stick & Tripod User Manual

Model: Q01

PRODUCT OVERVIEW

The SelfieShow Selfie Stick and Tripod (Model Q01) is a versatile 2-in-1 device designed for capturing photos and videos with ease. It functions as both an extendable selfie stick and a stable tripod, featuring a detachable wireless remote control for convenient operation. Its compact and lightweight design makes it ideal for travel and everyday use.



Figure 1: The SelfieShow Selfie Stick and Tripod in its various configurations, including extended selfie stick and compact tripod mode.

Key Features:

- **All-in-One Design:** Seamlessly transitions between a selfie stick and a tabletop tripod.
- **Extendable & Portable:** Folds down to 7.64 inches (19.4 cm) and extends up to 41.73 inches (106 cm), weighing only 5.3 ounces (150 grams).
- **Detachable Wireless Remote:** Bluetooth-enabled remote for hands-free photo and video capture from up to 33 feet (10 meters) away.
- **Adjustable Phone Holder:** Features a 245° rotation head and 360° rotatable phone clamp, accommodating smartphones 6.5-9.5 cm wide.
- **Wide Compatibility:** Supports most smartphones including iPhone 16/15/14/13/12 series, Samsung Galaxy, Google, OnePlus, and other Android devices, as well as GoPro cameras.
- **Durable Construction:** Made with a stainless steel rod for stability.

SETUP GUIDE

1. **Unfold the Device:** Gently stretch the selfie stick from its compact form.
2. **Prepare the Phone Holder:**
 - Unfold the phone holder arms.
 - Adjust the 245° rotation head to your desired angle by loosening the knob, setting the angle, and tightening the knob.
 - The phone clamp can rotate 360° for horizontal or vertical phone orientation.
3. **Install Your Phone:** Extend the spring-loaded phone clamp and carefully place your smartphone (6.5-9.5 cm wide) into the holder, ensuring a secure grip.
4. **Activate the Remote Control:**
 - The remote control is detachable from the handle. Gently slide it out.
 - Press and hold the remote button for a few seconds to power it on. A blue indicator light will flash, indicating it's in pairing mode.
5. **Pair with Your Phone via Bluetooth:**
 - On your smartphone, go to Bluetooth settings.
 - Look for "SelfieShow" in the list of available devices and select it to pair. The blue indicator light on the remote will turn solid once connected.
 - Once paired, open your phone's camera app. The remote is now ready to take photos.

How to Use The Selfie Stick



Figure 2: Visual instructions for setting up and using the SelfieShow device.

OPERATING INSTRUCTIONS

Using as a Selfie Stick:

- Hold the handle firmly.
- Extend the stainless steel rod to your desired length (up to 41.73 inches / 106 cm).
- Adjust the phone holder's angle and rotation for the perfect shot.
- Press the button on the detachable remote control to capture photos or start/stop video recording.



Figure 3: Examples of the selfie stick in use for capturing moments.

Using as a Tripod:

- From the compact form, open the three legs at the bottom of the handle to form a stable tripod base.
- Place the tripod on a flat, stable surface. For maximum stability, keep the extension rod shorter.
- Extend the rod to the desired height.
- Adjust the phone holder's angle and rotation as needed.
- Use the detachable remote control to take photos or record videos hands-free.

Detachable Phone Holder

Phone clip can be used as a phone stand



Figure 4: The phone holder can also function as a mini stand.

MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use, fold the selfie stick to its most compact size and store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery:** The remote control uses a Lithium Metal battery. Replace it when the indicator light no longer illuminates or pairing becomes difficult. Ensure proper disposal of old batteries according to local regulations.
- **Avoid Over-extension:** Do not force the extension rod beyond its maximum length to prevent damage.
- **Secure Phone:** Always ensure your phone is securely gripped by the holder before extending or positioning the stick/tripod.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote not pairing.	Remote battery low or dead; Bluetooth not enabled on phone; remote not in pairing mode; too far from phone.	Replace remote battery. Ensure phone's Bluetooth is on. Press and hold remote button to enter pairing mode. Move closer to phone (within 10 meters).
Phone not stable on tripod.	Surface is uneven; tripod legs not fully extended; phone not centered; extension rod too long.	Place on a flat, stable surface. Fully extend tripod legs. Ensure phone is centered in the clamp. Shorten the extension rod for increased stability.
Selfie stick not extending/retracting smoothly.	Dust or debris in the rod sections; mechanism is stiff.	Clean the rod sections with a soft cloth. Apply a small amount of silicone lubricant if necessary (avoiding contact with phone holder).
Phone holder not gripping phone securely.	Phone width exceeds limits; spring mechanism worn.	Ensure phone width is within 6.5-9.5 cm. If mechanism is worn, contact customer support.

SPECIFICATIONS

- Model:** Q01
- Material:** Fiberglass (rod), ABS Plastic (handle/holder)
- Folded Length:** 7.64 inches (19.4 cm)
- Extended Length:** 41.73 inches (106 cm)
- Product Dimensions:** 7.64 x 1.57 x 1.3 inches
- Item Weight:** 5.3 ounces (150 grams)
- Weight Limit (Tripod):** 6.6 Pounds
- Phone Holder Width:** 6.5 - 9.5 cm
- Rotation:** 245° (head), 360° (clamp)
- Remote Control:** Detachable Bluetooth remote (Lithium Metal battery required)
- Bluetooth Range:** Up to 33 feet (10 meters)
- Manufacturer:** LDP
- Date First Available:** December 20, 2019

WARRANTY AND SUPPORT

The SelfieShow Selfie Stick and Tripod (Model Q01) comes with a one-year warranty from the date of purchase, covering manufacturing defects. For any product inquiries, technical assistance, or warranty claims, please contact

SelfieShow customer service. Our team is available for 24-hour online support to ensure your satisfaction.

For the fastest service, please have your purchase receipt and product model number (Q01) ready when contacting support.

Online Support: Refer to the official SelfieShow website or your purchase platform for contact details.

© 2025 SelfieShow. All rights reserved.