

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Reebok](#) /

> [Reebok Club C 85 Sneaker User Manual](#)

## Reebok KZK06

# Reebok Club C 85 Sneaker User Manual

Model: KZK06

## 1. PRODUCT OVERVIEW

---

The Reebok Club C 85 Sneaker (Model KZK06) is a classic footwear design featuring a soft garment leather upper. This model incorporates design elements inspired by the Wonder Woman collection, including a graphic sockliner and iridescent details, offering a distinctive aesthetic.

Key features include:

- **Durable and Lightweight Material:** Constructed with a soft garment leather upper for support and a terry lining on the tongue and heel for comfort.
- **Efficient Foot Support:** Features a die-cut EVA midsole for impact absorption and a padded foam sockliner for responsive cushioning.
- **Comfortable and Sturdy Design:** A low-cut silhouette provides freedom of motion.
- **High-Performance Outsole:** Equipped with a high abrasion rubber outsole for durability and traction.



Figure 1: Side view of the Reebok Club C 85 Sneaker, showcasing the leather upper and sole.

## 2. SETUP AND FIRST USE

---

Upon receiving your Reebok Club C 85 sneakers, follow these steps for initial setup:

1. **Unboxing:** Carefully remove the sneakers from their packaging. Inspect them for any visible defects or damage.
2. **Initial Fit Check:** Try on both sneakers to ensure a comfortable and secure fit. The low-cut design should allow for natural ankle movement.
3. **Lacing:** Adjust the laces to achieve a snug fit without being too tight. Ensure the tongue and sockliner are properly positioned for comfort.



Figure 2: Top-down view of the sneaker, illustrating the lacing system and tongue.

### 3. OPERATING INSTRUCTIONS (WEARING)

---

The Reebok Club C 85 sneakers are designed for daily, casual, and athleisure wear. To ensure optimal comfort and longevity:

- **Proper Fit:** Always ensure your foot is comfortably seated within the shoe, with adequate space for your toes.
- **Lace Adjustment:** Re-tie laces as needed throughout the day to maintain a secure fit and prevent discomfort or slipping.
- **Intended Use:** While durable, these sneakers are primarily for casual and light athletic activities. Avoid using them for heavy-duty sports or activities that may cause excessive wear and tear beyond their design intent.



Figure 3: Front-side view of the sneakers, showing the overall profile when worn.

### 4. CARE AND MAINTENANCE

---

Proper care extends the life and appearance of your Reebok Club C 85 sneakers. The upper is made of 100% soft leather, and the sole is rubber.

#### 4.1 Cleaning Instructions

- **Leather Upper:**
  - Wipe the leather surface with a soft, damp cloth to remove dirt and dust.
  - For tougher stains, use a specialized leather cleaner according to the product's instructions.
  - Avoid harsh chemicals or abrasive materials, as these can damage the leather.
  - Allow the sneakers to air dry naturally at room temperature, away from direct heat or sunlight.
  - Consider applying a leather conditioner periodically to keep the leather supple and prevent cracking.
- **Rubber Sole:**
  - Clean the rubber outsole with a brush and mild soap and water.
  - Rinse thoroughly and allow to air dry.
- **Laces:** Remove laces and hand wash them with mild soap and water, then air dry.
- **Insoles:** Remove and air out insoles regularly to prevent odor. If washable, follow specific cleaning

instructions for the insole material.

## **4.2 Storage**

Store your sneakers in a cool, dry place away from direct sunlight and extreme temperatures. Using shoe trees can help maintain their shape.



Figure 4: Close-up of the rubber outsole, showing the non-marking tread pattern.

## 5. TROUBLESHOOTING

---

This section addresses common concerns you might encounter with your sneakers.

Problem	Possible Cause	Solution
<b>Discomfort or Rubbing</b>	Incorrect lacing, improper size, or new shoe break-in period.	Adjust lacing for a more comfortable fit. Ensure correct size. Wear for short periods initially to break them in.
<b>Unpleasant Odor</b>	Moisture buildup, lack of ventilation.	Remove insoles and air out shoes after each use. Use shoe deodorizers or baking soda. Ensure shoes are completely dry before storage.
<b>Stains on Leather</b>	Exposure to dirt, liquids, or other staining agents.	Clean promptly with a soft, damp cloth. For persistent stains, use a leather-specific cleaner. Test cleaners on an inconspicuous area first.

## 6. SPECIFICATIONS

---

Feature	Detail
<b>Model Number</b>	KZK06
<b>Brand</b>	Reebok
<b>Department</b>	Unisex-adult
<b>Fabric Type</b>	100% Soft Leather
<b>Sole Material</b>	Rubber
<b>Shaft Height</b>	Low-top
<b>Package Dimensions</b>	13.43 x 8.98 x 5.12 inches
<b>Item Weight</b>	14.4 ounces
<b>First Available Date</b>	September 17, 2020

## 7. WARRANTY INFORMATION

---

Specific warranty details for the Reebok Club C 85 Sneaker are provided by the manufacturer. Please refer to the official Reebok website or contact their customer service for comprehensive warranty terms and conditions.

Generally, warranties cover manufacturing defects and material flaws under normal use. Damage resulting from misuse, improper care, or accidents is typically not covered.

## 8. CUSTOMER SUPPORT

---

For further assistance, product inquiries, or support, please visit the official Reebok website or contact their customer service department. You can often find FAQs, contact forms, and phone numbers on their support pages.

**Reebok Official Website:** [www.reebok.com](http://www.reebok.com)

When contacting support, please have your product model number (KZK06) and purchase details readily

available.