

[Manuals.plus](#) /

› [M&M SMARTEK](#) /

› M&M Smartek Bayonet Adapter M22 x 1.5 AG User Manual

M&M SMARTEK B082Z9P822

M&M Smartek Bayonet Adapter M22 x 1.5 AG User Manual

Model: B082Z9P822 | Brand: M&M SMARTEK

1. INTRODUCTION

This user manual provides essential information for the safe and effective use of the M&M Smartek Bayonet Adapter M22 x 1.5 AG. This adapter is designed to connect pressure washer guns with an M22 x 1.5 external thread (AG) to pressure washers from brands such as Kinzo, Sistema, Stihl, and Nilfisk. Please read this manual thoroughly before installation and operation.

2. PRODUCT OVERVIEW

The M&M Smartek Bayonet Adapter is a high-quality accessory crafted from solid brass, ensuring durability and resistance to corrosion. Its primary function is to provide a secure and quick connection between your pressure washer and compatible accessories.

- **KEW Bayonet Adapter:** Features a KEW bayonet connector for quick release.
- **M22 x 1.5 External Thread (AG):** Designed for connecting guns with this specific thread size.
- **Nilfisk Quick Release System Compatibility:** Fully compatible with the Nilfisk quick release system for easy attachment and detachment of accessories.
- **Material:** Constructed from solid brass for enhanced longevity and robustness.



Figure 2.1: Overall view of the M&M Smartek Bayonet Adapter, showcasing its brass construction and threaded end.



Figure 2.2: Detailed view of the adapter with key dimensions, including 9.4mm, 12.6mm, 18.5mm, 48.8mm, and G1/4 12mm, indicating its precise measurements for compatibility.



Figure 2.3: Angled view of the adapter, highlighting the bayonet connection and the M22 x 1.5 external thread.

3. SETUP AND INSTALLATION

Follow these steps to properly install the M&M Smartek Bayonet Adapter:

1. **Ensure Safety:** Before beginning, ensure your pressure washer is turned off and disconnected from the power supply and water source. Release any residual pressure in the system.
2. **Identify Connection Points:** Locate the connection point on your pressure washer gun that requires an M22 x 1.5 external thread (AG) adapter. Also, identify the bayonet connection on your pressure washer hose or lance.
3. **Attach to Pressure Washer Gun:** Screw the M22 x 1.5 external thread end of the adapter onto the corresponding internal thread of your pressure washer gun. Tighten securely by hand, then use a wrench if necessary, ensuring not to overtighten.
4. **Connect to Pressure Washer Hose/Lance:** Align the bayonet end of the adapter with the bayonet receiver on your pressure washer hose or lance. Push the adapter firmly into the receiver and twist clockwise until it clicks into place, indicating a secure connection.
5. **Verify Connection:** Gently pull on the adapter to ensure it is securely fastened and does not detach easily. A proper connection will prevent leaks and ensure optimal performance.

This adapter is designed for quick and tool-free attachment and detachment, especially beneficial for rapid accessory changes during cleaning operations.

4. OPERATING INSTRUCTIONS

Once the adapter is securely installed, you can operate your pressure washer as usual. The adapter facilitates the connection of various accessories compatible with the M22 x 1.5 AG thread to your Kinzo, Sistema, Stihl, or Nilfisk pressure washer.

- **Accessory Compatibility:** Use the adapter to connect pressure washer guns or lances that feature an M22 x 1.5 external thread.
- **Quick Changes:** The bayonet and Nilfisk quick-release compatibility allows for swift changes between different accessories without interrupting the water flow or needing to power down the system.
- **Optimal Performance:** Ensure all connections are tight to prevent pressure loss and maintain efficient cleaning performance.

5. MAINTENANCE

Proper maintenance will extend the lifespan of your M&M Smartek Bayonet Adapter:

- **Cleaning:** After each use, rinse the adapter with clean water to remove any dirt, debris, or chemical residues.
- **Inspection:** Regularly inspect the threads and the bayonet mechanism for any signs of wear, damage, or corrosion. Check the O-rings for cracks or flattening; replace if necessary to prevent leaks.
- **Lubrication:** Periodically apply a small amount of silicone grease to the O-rings to maintain their flexibility and ensure a smooth, watertight seal.

- **Storage:** Store the adapter in a clean, dry place away from direct sunlight and extreme temperatures.
- **Avoid Damage:** Do not use tools to overtighten connections, as this can strip threads or damage the brass.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with the adapter.

Problem	Possible Cause	Solution
Water Leakage at Connection	Loose connection Damaged or worn O-ring Debris in connection	Ensure adapter is tightly screwed/clicked into place. Inspect O-rings; replace if cracked or flattened. Clean connection points thoroughly.
Difficulty Attaching/Detaching	Misalignment Dirt or corrosion Lack of lubrication	Ensure proper alignment before pushing and twisting. Clean adapter and receiving end. Apply silicone grease to O-rings and moving parts.
Reduced Pressure	Partial blockage Loose connection causing air intake	Check adapter and connected accessories for blockages. Verify all connections are secure and leak-free.

7. SPECIFICATIONS

Product Dimensions	8 x 4 x 4 cm; 90 grams
Power Source Type	Corded Electric (refers to compatible pressure washer)
Manufacturer	M&M Smartek
ASIN	B082Z9P822
Available on Amazon.it since	December 24, 2019
Brand	M&M SMARTEK
Color	Brass
Compliant Specifications	CSA, CE
UPC	670664782248

8. WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support for your M&M Smartek Bayonet Adapter, please refer to the seller's information on the original purchase platform or contact M&M Smartek directly through their official channels. Keep your proof of purchase for any warranty claims.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B082Z9P822>

More documents and user manuals: <https://manuals.plus/>