

[manuals.plus](#) /

› [VASAGLE](#) /

› [VASAGLE TV Cabinet UDTV46BX Instruction Manual](#)

VASAGLE UDTV46BX

VASAGLE TV Cabinet UDTV46BX Instruction Manual

1. INTRODUCTION

Thank you for choosing the VASAGLE TV Cabinet, model UDTV46BX. This manual provides essential information for the safe assembly, operation, and maintenance of your new TV stand. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image 1.1: The VASAGLE TV Cabinet UTV46BX, showcasing its rustic brown and black industrial design with a television placed on its top surface.

2. SAFETY INFORMATION

- Children are not allowed to climb or play on the product for safety reasons.
- Please attach the product to the wall with the included anti-tipping kit for safety.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum static load capacities specified in the 'Specifications' section.
- Place the TV cabinet on a level surface to prevent instability.

3. PACKAGE CONTENTS

Verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- 1 x TV Stand (all structural components)
- 1 x Accessory Kit (hardware, tools)
- 1 x Anti-Tip Kit (for wall attachment)

4. SPECIFICATIONS

Feature	Detail
Product Size	53.1" L x 15.7" W x 29.9" H (135 x 40 x 76 cm)
Product Weight	91.3 lb (41.5 kg)
Max. Static Load Capacity of Tabletop	66 lb (30 kg)
Max. Static Load Capacity per Shelf	44 lb (20 kg)
Material	Particleboard, Steel
Color	Rustic Brown + Black
Style	Industrial




Image 4.1: Technical drawing illustrating the precise dimensions of the TV cabinet, including length, width, and height, as well as internal shelf spacing.



Image 4.2: Visual guide demonstrating the compatibility of the TV cabinet with various television sizes, specifically 32-inch, 40-inch, 55-inch, and 60-inch TVs.

5. SETUP AND ASSEMBLY

Assembly of the VASAGLE TV Cabinet requires careful attention to the included step-by-step instructions. It is recommended to have a clear, spacious area for assembly. All necessary tools and hardware are provided in the accessory kit.

5.1 Key Assembly Features

- **Adjustable Feet:** The media console is equipped with adjustable feet to compensate for uneven floor surfaces, ensuring stability.
- **Cable Management:** Integrated cable holes on the back panel help organize and hide audio/video cables, maintaining a tidy appearance.
- **Anti-Tipping Kit:** For enhanced safety, especially in households with children, secure the TV cabinet to the wall using the provided anti-tipping kit.



Image 5.1: A detailed view of the cable management holes located on the rear panel of the TV cabinet, designed for routing and concealing electronic cables.

Your browser does not support the video tag.

Video 5.1: An official product video from VASAGLE demonstrating the features and functionality of the TV cabinet, including its design and storage capabilities.

6. OPERATING INSTRUCTIONS

The VASAGLE TV Cabinet is designed for versatile storage and display. Utilize its features to organize your entertainment area efficiently.

6.1 Sliding Barn Doors

The two barn doors slide smoothly along a metal track, allowing you to conceal or reveal different sections of the cabinet as needed. This provides flexibility in displaying decorative items or hiding electronic components and clutter.



Image 6.1: A detailed view of the metal track and roller mechanism that enables the smooth operation of the sliding barn doors.

6.2 Adjustable Storage Shelves

The cabinet features two adjustable shelves behind the sliding doors, along with two open compartments and a large shelf under the tabletop. These shelves can be repositioned to accommodate items of various sizes, such as gaming consoles, media players, books, or decorative pieces.



Image 6.2: An interior perspective of the TV cabinet, highlighting the adjustable shelves and open compartments suitable for organizing various media and decorative items.

7. MAINTENANCE

To ensure the longevity and appearance of your VASAGLE TV Cabinet, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surfaces with a dry, soft cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent moisture damage to the particleboard.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain structural integrity.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.

8. TROUBLESHOOTING

8.1 Unevenness

If the TV cabinet appears wobbly or uneven, adjust the leveling feet located at the bottom of the stand. Rotate each foot clockwise or counter-clockwise until the cabinet is stable and level on your floor.

8.2 Sliding Doors Not Moving Smoothly

Ensure the metal track is clean and free of debris. Check that the rollers on the barn doors are properly seated on the track. If the issue persists, verify that the door hardware was installed correctly during assembly, referring back to the assembly instructions.

9. WARRANTY AND SUPPORT

For any questions, concerns, or issues regarding your VASAGLE TV Cabinet, please refer to the warranty information provided with your purchase or contact VASAGLE customer support. Details for customer support can typically be found on the product packaging or the brand's official website.

You can also visit the [VASAGLE Store on Amazon](#) for additional product information and support resources.