

Evenflo 35012434C

Evenflo GoTime LX Booster Car Seat User Manual

Model: 35012434C | Brand: Evenflo

INTRODUCTION

This manual provides essential instructions for the safe and proper use, installation, and maintenance of your Evenflo GoTime LX Booster Car Seat. Please read all instructions and warnings thoroughly before using this product. Keep this manual for future reference.

The Evenflo GoTime LX Booster Car Seat is designed for children weighing 40 to 120 lb (18.1 to 54.4 kg) and measuring 44 to 57 inches (111.8 to 144.8 cm) in height, with a minimum age of 4 years. It offers two modes of forward-facing use: high-back booster and no-back booster.

SETUP AND ASSEMBLY

Before assembly, ensure all components are present and undamaged. Refer to the parts list included with your product packaging. Consult your vehicle owner's manual to determine proper placement of the child restraint in your vehicle and familiarize yourself with your vehicle's components.

1. Unpacking and Initial Inspection

- Carefully remove all components from the packaging.
- Inspect the booster seat for any signs of damage or missing parts. Do not use if damaged.

2. Assembling the High-Back Booster

The booster seat arrives with the backrest detached from the base. To assemble:

1. Align the backrest with the base. The connection points are typically located at the bottom rear of the backrest and the rear of the booster base.
2. Slide the backrest onto the base until it clicks securely into place. Ensure there is no gap and the connection is firm.
3. Verify the backrest is locked by gently pulling upwards.



Image: Front view of the Evenflo GoTime LX Booster Car Seat in high-back mode, showing the seat, backrest, and integrated cup holders.



Image: Side view of the Evenflo GoTime LX Booster Car Seat, illustrating the deep design and side impact protection features.

3. Adjusting Headrest Height

The headrest can be adjusted to 7 positions to accommodate your child's growth and ensure proper vehicle belt fit.

1. Locate the height adjustment handle, typically at the top of the backrest.
2. Squeeze the handle and simultaneously raise or lower the headrest to the desired position.
3. Release the handle to lock the headrest in place. Ensure the shoulder belt guide is positioned correctly above your child's shoulder.



Image: Illustration showing the adjustable headrest of the Evenflo GoTime LX Booster Car Seat moving through its height positions.

OPERATING INSTRUCTIONS

1. Securing Your Child in High-Back Booster Mode

Always use the vehicle's lap and shoulder belt system with the booster seat.

1. Place the booster seat firmly against the vehicle's seat back.
2. Have your child sit in the booster seat.
3. Route the vehicle's lap belt under the armrests and across your child's upper thighs. The lap belt should fit low and snug across the hips, not the stomach.
4. Thread the vehicle's shoulder belt through the red shoulder belt guide on the booster's headrest. The shoulder belt should lie flat across your child's chest and collarbone, not on the neck or off the shoulder.
5. Buckle the vehicle's seat belt and pull it snug.



Image: A child properly secured in the Evenflo GoTime LX Booster Car Seat using the vehicle's lap and shoulder belt system.

2. Converting to No-Back Booster Mode

When your child is ready, the backrest can be removed to convert the GoTime LX into a no-back booster. This mode is suitable for children meeting the minimum weight and height requirements for a no-back booster as specified in the full product manual.

1. Ensure the booster seat is not installed in the vehicle.
2. Locate the release mechanism for the backrest, typically at the connection point between the backrest and the base.
3. Follow the instructions in your full manual to disengage the backrest from the base. This usually involves pressing a button or lifting a lever while pulling the backrest away.
4. Once the backrest is removed, the base functions as a no-back booster.



Image: The Evenflo GoTime LX Booster Car Seat with the backrest detached from the booster base, illustrating the conversion to no-back booster mode.

3. Using the Integrated Cup Holders

The booster seat features two integrated cup holders for convenience. These are designed to hold beverages or small snacks.

- Ensure items placed in cup holders do not interfere with the child's movement or the proper functioning of the seat belt.
- Avoid placing hot liquids in the cup holders.

MAINTENANCE AND CARE

Regular cleaning and maintenance will help prolong the life of your booster seat and ensure its continued safety.

Cleaning Instructions

- **Seat Pad:** The padded seat is removable and machine-washable. Use cold water on a gentle cycle. Tumble dry on low heat or air dry. Do not use bleach.

- **Plastic Parts:** Wipe plastic parts with a damp cloth and mild soap. Air dry. Do not use abrasive cleaners.
- **Webbing:** Wipe webbing with a damp cloth. Do not machine wash or immerse webbing in water, as this may weaken the material.

Storage

When not in use, store the booster seat in a cool, dry place away from direct sunlight. Do not place heavy objects on the booster seat during storage.

TROUBLESHOOTING

If you encounter issues with your Evenflo GoTime LX Booster Car Seat, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Backrest not securely attaching to base.	Improper alignment or obstruction.	Ensure the backrest is correctly aligned with the base's connection points. Check for any debris preventing a secure click. Apply firm, even pressure until it locks.
Vehicle seat belt does not fit properly.	Headrest height incorrect or belt twisted.	Adjust the headrest height so the shoulder belt guide is just above your child's shoulder. Ensure the vehicle belt is not twisted and lies flat.
Booster seat feels wobbly in the vehicle.	Not properly secured by vehicle belt or vehicle seat design.	Ensure the vehicle's lap and shoulder belt are pulled snug. The booster seat relies on the vehicle's belt to hold it and the child securely. Some vehicle seats may have contours that affect stability; ensure the booster is as flat as possible.

If you cannot resolve an issue, please contact Evenflo customer service for assistance.

SPECIFICATIONS

Feature	Detail
Model Number	35012434C
Product Dimensions	15.2 x 19.49 x 28.19 inches (38.6 x 49.5 x 71.6 cm)
Item Weight	7.1 pounds (3.2 kg)
Minimum Child Weight (Forward-Facing)	40 Pounds (18.1 kg)
Maximum Child Weight (Forward-Facing)	120 Pounds (54.4 kg)
Minimum Child Height	44 Inches (111.8 cm)

Feature	Detail
Maximum Child Height	57 Inches (144.8 cm)
Material Composition	33% Cotton, 34% Polypropylene, 33% Polyester
Installation Type	Vehicle Seat Belt
Reclining Positions	7 (for headrest height adjustment)



Image: Diagram illustrating the key dimensions (height, width, depth) of the Evenflo GoTime LX Booster Car Seat.

WARRANTY INFORMATION

Evenflo products are covered by a limited warranty. Specific warranty details, including coverage period and terms, are typically provided with the product at the time of purchase or can be found on the official Evenflo website. Please retain your proof of purchase for warranty claims.

For detailed warranty information, please visit the [Evenflo Support Website](#).

CUSTOMER SUPPORT

For further assistance, questions, or to utilize the live video installation support, please contact Evenflo's ParentLink Customer Service.

- **Live Video Installation Support:** Evenflo offers live video support with a certified car seat safety technician to assist with proper vehicle installation. This service helps ensure correct usage and provides confidence in your child's safety.
- **Contact Information:** Refer to the contact details provided on the Evenflo website or product registration card.

You can typically find more information and contact options on the official Evenflo website: www.evenflo.com.

© 2025 Evenflo. All rights reserved. This manual is for informational purposes only.

Related Documents - 35012434C

 <p>evenflo Maestro™ Sport Child Restraint System Owner's Manual Keep instructions for future use.</p> <p>Exclusive RightFit™ Belt Path</p> <p>5-point Harness* 10 to 22.5 kg (22 to 50 lbs) 71 to 127 cm (28 to 50 in.) At least 2 years old</p> <p>Booster* 18 to 49.8 kg (40 to 110 lbs) 110 to 145 cm (44 to 57 in.) At least 4 years old</p> <p><small>* See page 4-5 for complete requirements. ** See page 2 for complete requirements. For more information, call 1-800-233-5921. WARNING: To reduce the risk of serious injury or death in a vehicle crash, always read the instructions prior to installing and using this child restraint.</small></p> <p>© 2008 Evenflo Company, Inc. 25109429 7/08</p>	<p><u>Evenflo Maestro Sport Child Restraint System Owner's Manual</u></p> <p>Owner's manual for the Evenflo Maestro Sport Child Restraint System, detailing its features, installation, and usage for both 5-point harness and booster modes. Includes safety warnings and care instructions.</p>
 <p>evenflo Chase Select™ /LX™ Child Restraint System Owner's Manual Keep for future use.</p> <p>Exclusive RightFit™ Belt Path</p> <p>Child Harness 5-point Harness* 10 to 18 kg (22 to 40 lbs) 71 to 127 cm (28 to 50 in.) At least 2 years old</p> <p>Booster 18 to 49.8 kg (40 to 110 lbs) 110 to 145 cm (44 to 57 in.) At least 4 years old</p> <p><small>* See page 2 for complete requirements. ** See page 2 for complete requirements. For more information, call 1-800-233-5921. WARNING: To reduce the risk of serious injury or death in a vehicle crash, always read the instructions prior to installing and using this child restraint.</small></p> <p>© 2017 Evenflo Company Inc. 25102061 1/17</p>	<p><u>Evenflo Chase Select™/LX™ Child Restraint System Owner's Manual</u></p> <p>This owner's manual provides essential information for the Evenflo Chase Select™/LX™ Child Restraint System. It details installation, usage, and safety guidelines for both 5-point harness and booster modes, ensuring optimal protection for children. Learn about specific weight, height, and age requirements, important warnings, and how to properly secure your child.</p>

The image shows the front cover of a car seat owner's manual. At the top, the Evenflo logo is displayed with a stylized 'e' and 'f' inside a circle. Below the logo, the text 'All 1Stages Slim' is written in a large, bold, sans-serif font. Underneath that, it says '4-in-1 Car Seat Owner's Manual' and 'Keep instructions for future use'. On the right side of the cover, there is a QR code and the word 'EN' in a red box. The bottom half of the cover features three line drawings of the car seat in different configurations: 'REAR-FACING' (upright), 'FORWARD-FACING WITH HARNESS' (slanted forward), and 'HIGH-BACK BOOSTER BACKLESS BOOSTER' (upright with a different harness). The entire cover is white with black text and line drawings.

[Evenflo All4Stages Slim 4-in-1 Car Seat Owner's Manual](#)

Comprehensive owner's manual for the Evenflo All4Stages Slim 4-in-1 Car Seat, detailing rear-facing, forward-facing with harness, and booster modes. Includes safety warnings, installation instructions, and child usage requirements.

[Evenflo Chase Select LX Child Restraint System: Owner's Manual and Safety Guide](#)

Comprehensive owner's manual for the Evenflo Chase Select LX Child Restraint System, detailing installation, usage, safety guidelines, and maintenance for both 5-point harness and booster modes. Includes child requirements, warnings, and care instructions.

[GUCHO Airport Car Seat Roller: Secure Attachment Guide](#)

Comprehensive guide on securely attaching child car seats to the GUCHO Airport Car Seat Roller, including compatibility details and essential safety warnings for travel.

Nissan LEAF Child Restraint System Compatibility Guide 2011-2012

Find compatible child restraint systems (CRS) for your 2011-2012 Nissan LEAF. This guide provides fitting information for rear-facing, forward-facing, and booster seats, along with installation tips and a manufacturer directory.